

Opis produktu

1723-836-500

Cover frame 3gang polished brass decor ivory white - Busch-Dynasty



Ogólne informacje

| | |
|---------------------|--|
| Typ produktu | 1723-836-500 |
| Kod zamówieniowy | 2CKA001754A4572 |
| Oznaczenie typu ABB | Cover Frame 3gang xxx - Busch-Dynasty |
| Numer EAN | 4011395194928 |
| Opis katalogowy | Cover frame 3gang polished brass decor ivory white - Busch-Dynasty |
| Opis | For vertical or horizontal installation. |

Installation

| | |
|--------------------------|------------------------|
| Instrukcje i podręczniki | No document needed |
| Typ montażu | Flush Mounted |
| Rodzaj mocowania | Clamp |
| Orientacja montażu | Horizontal Vertical |

Dane techniczne

| | |
|---------------------------------------|--------------------|
| Arkusze danych, informacja techniczna | No document needed |
| Liczba | 3 |

Design

| | |
|--------------------------------|----------------------------------|
| Design Range | Busch-Dynasty 63x63 |
| Wykończenie pokrywy | Galvanized Glossy |
| Material | Metal |
| Zapewnione miejsce na etykiety | No |
| Kolor | polished brass decor ivory white |

Material Compliance

| | |
|---------------------------|--|
| Dane RoHS | 2CKA200000E2893 |
| Status RoHS | Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019 |
| Deklaracja REACH | 2CKA309999E9999 |
| REACH Information | False - does not contains substances > 0.1 mass percentage |
| Szablon raportowania CMRT | 9AKK108468A3363 |

Normy środowiskowe

| | |
|-----------------|------|
| Stopień ochrony | IP20 |
|-----------------|------|

Wymiary

| | |
|---------------------------|---------|
| Szerokość netto | 106 mm |
| Wysokość netto | 248 mm |
| Głębokość / długość netto | 12 mm |
| Masa netto | 413.5 g |

Certyfikaty i deklaracje (Numer dokumentu)

| | |
|-------------------------|-----------------------|
| Deklaracja zgodności UE | No declaration needed |
|-------------------------|-----------------------|

Klasyfikacje

| | |
|----------------|---|
| ETIM 9 | EC000007 - Cover frame for domestic switching devices |
| eClass | V11.0 : 27144001 |
| Kategoria WEEE | Product Not in WEEE Scope |

Accessories

| Identifier | Description | Type | Quantity | Unit Of Measure |
|-----------------|---|------------|----------|-----------------|
| 2CKA001582A0346 | Cover plate with labelling field Busch-Infoline® Single push button studio white - 63x63 | 1571 CN-84 | 1 | sztuka |

| | | | | |
|-----------------|---|-----------------------|---|--------|
| 2CKA001582A0348 | Cover plate with labelling field Busch-Infoline® Single push button Przeźroczystry studio white - 63x63 | 1572 CN-84 | 1 | sztuka |
| 2CKA001582A0350 | Cover plate with labelling field Busch-Infoline® Central cover plate studio white - 63x63 | 1573 CN-84 | 1 | sztuka |
| 2CKA001582A0353 | Cover plate with labelling field Busch-Infoline® Central cover plate studio white - 63x63 | 1575 CN-84 | 1 | sztuka |
| 2CKA001582A0355 | Cover plate with labelling field Busch-Infoline® Central cover plate studio white - 63x63 | 1576 CN-84 | 1 | sztuka |
| 2CKA001731A1923 | Cover Busch-Infolicht® studio white - 63x63 | 1716-84 | 1 | sztuka |
| 2CKA001731A1916 | Rocker None for Pull-cord switch, Pull cord studio white - 63x63 | 1720-84 | 1 | sztuka |
| 2CKA001710A3808 | Cover plate with legend Level switch Turn button studio white - 63x63 | 1740 DR/03-84 | 1 | sztuka |
| 2CKA001710A3512 | Cover plate Symbol "2-1-3" for Level switch, Turn button studio white - 63x63 | 1740 DRL-84- 503 | 1 | sztuka |
| 2CKA001710A3172 | Cover plate with legend Symbol "arrows" for Venetian blind, Turn button studio white - 63x63 | 1740-84 | 1 | sztuka |
| 2CKA001710A3161 | Cover plate Blind cap 1 gang with Mounting plate studio white - 63x63 | 1742-84 | 1 | sztuka |
| 2CKA001710A3991 | Cable Outlet / Blank Plate / Adapter Ring Blind cap 0 gang studio white - 63x63 | 1742-84-500 | 1 | sztuka |
| 2CKA001724A4368 | Cover plate SAT 4 gang studio white - 63x63 | 1743/10-04-84 | 1 | sztuka |
| 2CKA001724A4377 | Cover plate TV / Radio / 2x SAT 4 gang studio white - 63x63 | 1743-04-84 | 1 | sztuka |
| 2CKA001724A4332 | Data / Telecommunication / Antenna SAT 3 gang studio white - 63x63 | 1743-84-500 | 1 | sztuka |
| 2CKA001710A3173 | Cover plate Busch-Infoline® telephone connector boxes (VDo) Central cover plate studio white - 63x63 | 1745-84 | 1 | sztuka |
| 2CKA001710A3993 | Data / Telecommunication / Antenna Telecommunication inserts 0 gang studio white - 63x63 | 1746/10-84- 500 | 1 | sztuka |
| 2CKA001710A3167 | Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang studio white - 63x63 | 1746-84 | 1 | sztuka |
| 2CKA001710A4096 | Intermediate Ring for cover plates Busch- Balance® SI studio white - 63x63 | 1747 BSI-84 | 1 | sztuka |
| 2CKA001710A3863 | Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI studio white - 63x63 | 1747 SI-84 | 1 | sztuka |
| 2CKA001710A3861 | Intermediate Ring studio white - 63x63 | 1747-84 | 1 | sztuka |
| 2CKA001710A3163 | Cover plate Cable outlet studio white - 63x63 | 1749-84 | 1 | sztuka |
| 2CKA001723A0240 | Cover plate Loudspeaker 2 gang studio white - 63x63 | 1751-84 | 1 | sztuka |
| 2CKA001710A3175 | Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key studio white - 63x63 | 1755 SL/PZ-84 -101 | 1 | sztuka |
| 2CKA001724A2761 | Cover plate with labelling field For data connection housing 2 gang studio white - 63x63 | 1758-84 | 1 | sztuka |
| 2CKA001731A1877 | Rocker with labelling field for Switch/push button, Single push button with Pilot lamp studio white - 63x63 | 1764 NLI-84 | 1 | sztuka |
| 2CKA001710A3992 | Data / Telecommunication / Antenna TAE 0 gang studio white - 63x63 | 1766-84-500 | 1 | sztuka |
| 2CKA001753A0258 | Cover plate with legend 1 ... 15 Min for Time switch, Toggle studio white - 63x63 | 1770-84-103 | 1 | sztuka |
| 2CKA001753A0301 | Cover plate with legend 10 ... 120 Min for Time switch, Toggle studio white - 63x63 | 1771-84-103 | 1 | sztuka |
| 2CKA001751A2980 | Multimedia Devices studio white | 1785 ENO-84 | 1 | sztuka |
| 2CKA001751A3099 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white - 63x63 | 1785 JA/02-84 | 1 | sztuka |

| | | | | |
|-----------------|---|----------------|---|--------|
| 2CKA001751A3088 | Mechanical Controls Symbol "arrows" for Venetian blind, Two-part rocker studio white - 63x63 | 1785 JA-84-500 | 1 | sztuka |
| 2CKA001751A3128 | Mechanical Controls None for Switch/push button, Two-part rocker studio white - 63x63 | 1785 K-84-500 | 1 | sztuka |
| 2CKA001751A2992 | Rocker with legend DND, MUR for Switch/push button, Two-part rocker studio white - 63x63 | 1785/11-84 | 1 | sztuka |
| 2CKA001751A3076 | Mechanical Controls Without imprint for Switch/push button, Two-part rocker studio white - 63x63 | 1785-84-500 | 1 | sztuka |
| 2CKA001751A2968 | Multimedia Devices studio white | 1786 ENO-84 | 1 | sztuka |
| 2CKA001751A3098 | Rocker with legend Symbol "arrows" for Venetian blind, Single rocker studio white - 63x63 | 1786 JA/02-84 | 1 | sztuka |
| 2CKA001751A2998 | Rocker with legend DND for Switch/push button, Single rocker studio white - 63x63 | 1786/11-84 | 1 | sztuka |
| 2CKA001751A3074 | Mechanical Controls Without imprint for Switch/push button, Single rocker studio white - 63x63 | 1786-84-500 | 1 | sztuka |
| 2CKA001751A2750 | Rocker None for Switch/push button, Single rocker studio white - 63x63 | 1788-84 | 1 | sztuka |
| 2CKA001751A2751 | Rocker with legend Heizung for Switch/push button, Single rocker studio white - 63x63 | 1789 H-84 | 1 | sztuka |
| 2CKA001751A2754 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker studio white - 63x63 | 1789 KI-84 | 1 | sztuka |
| 2CKA001751A3084 | Mechanical Controls Symbol "light" for Switch/push button, Single rocker studio white - 63x63 | 1789 LI-84-500 | 1 | sztuka |
| 2CKA001751A3151 | Mechanical Controls for Switch/push button, Single rocker studio white - 63x63 | 1789 N-84-500 | 1 | sztuka |
| 2CKA001751A3161 | Mechanical Controls Various symbols for Switch/push button, Single rocker studio white - 63x63 | 1789 ST-84-500 | 1 | sztuka |
| 2CKA001751A2755 | Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white - 63x63 | 1789 TR-84 | 1 | sztuka |
| 2CKA001751A3091 | Mechanical Controls Without imprint for Switch/push button, Single rocker studio white - 63x63 | 1789-84-500 | 1 | sztuka |
| 2CKA001710A4111 | Cover plate studio white - 63x63 | 1790-590-84 | 1 | sztuka |
| 2CKA001710A4112 | Cover plate studio white - 63x63 | 1790-591-84 | 1 | sztuka |
| 2CKA001710A4113 | Cover plate studio white - 63x63 | 1790-592-84 | 1 | sztuka |
| 2CKA001710A4114 | Cover plate studio white - 63x63 | 1790-593-84 | 1 | sztuka |
| 2CKA001710A4115 | Cover plate studio white - 63x63 | 1790-594-84 | 1 | sztuka |
| 2CKA001710A4116 | Cover plate studio white - 63x63 | 1790-595-84 | 1 | sztuka |
| 2CKA001710A3698 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white - 63x63 | 1794 TA-84 | 1 | sztuka |
| 2CKA001710A4017 | Cover plate Various symbols for Thermostat Turn button studio white - 63x63 | 1795 HK-84 | 1 | sztuka |
| 2CKA001710A4049 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white - 63x63 | 1795 HKEA-84 | 1 | sztuka |
| 2CKA001710A3725 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white - 63x63 | 1795 TA-84 | 1 | sztuka |
| 2CKA001710A3569 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white - 63x63 | 1795-84 | 1 | sztuka |
| 2CKA001753A0311 | Cover plate for Pull-cord switch, Pull cord studio white - 63x63 | 1796-84 | 1 | sztuka |
| 2CKA001710A3990 | Data / Telecommunication / Antenna Modular Jack 2 gang studio white - 63x63 | 1800-84-500 | 1 | sztuka |
| 2CKA001710A1551 | Data / Telecommunication / Antenna UAE/IAE (ISDN) 2 gang studio white - 63x63 | 1803-02-84-500 | 1 | sztuka |

| | | | | |
|-----------------|--|--------------------|---|--------|
| 2CKA001710A1550 | Data / Telecommunication / Antenna UAE/IAE (ISDN) 1 gang studio white - 63x63 | 1803-84-500 | 1 | sztuka |
| 2CKA002013A5407 | Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter studio white - 63x63 | 20 EUAB-84 | 1 | sztuka |
| 2CKA002011A6207 | Socket Outlets Without imprint studio white - 63x63 | 20 EUC-84-500 | 1 | sztuka |
| 2CKA002013A5418 | Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter studio white - 63x63 | 20 EUCBDR-84 | 1 | sztuka |
| 2CKA002013A5467 | SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green green - 63x63 | 20 EUCBL-13-84-101 | 1 | sztuka |
| 2CKA002013A5288 | SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green orange - 63x63 | 20 EUCBL-14-84 | 1 | sztuka |
| 2CKA002013A5286 | SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green studio white - 63x63 | 20 EUCBL-84 | 1 | sztuka |
| 2CKA002013A5294 | Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White studio white - 63x63 | 20 EUCBLI-84 | 1 | sztuka |
| 2CKA002013A5268 | SCHUKO® Socket insert with legend EDV Safety Shutter studio white - 63x63 | 20 EUCKS/DV-84 | 1 | sztuka |
| 2CKA002013A5372 | Socket insert Without imprint Safety Shutter Protective contact (SCHUKO) studio white - 63x63 | 20 EUCKS-84-500 | 1 | sztuka |
| 2CKA002013A5441 | 20 EUCRB-84-500 Socket Outlet | 20 EUCRB-84-500 | 1 | sztuka |
| 2CKA002018A1509 | Socket Outlets Without imprint with Hinged Lid studio white - 63x63 | 20 EUK-84-500 | 1 | sztuka |
| 2CKA002018A1520 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid studio white - 63x63 | 20 EUKB-84 | 1 | sztuka |
| 2CKA002018A1529 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid studio white - 63x63 | 20 EUKBR-84 | 1 | sztuka |
| 2CKA002018A1540 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid studio white - 63x63 | 20 EUKNB-84 | 1 | sztuka |
| 2CKA002018A1551 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid studio white - 63x63 | 20 EUKNBL-84 | 1 | sztuka |
| 2CKA002018A1563 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking studio white - 63x63 | 20 EUKNBSL-84 | 1 | sztuka |
| 2CKA002018A1564 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking studio white - 63x63 | 20 EUKNBSL-84-101 | 1 | sztuka |
| 2CKA002011A6209 | Socket Outlets Without imprint studio white - 63x63 | 20 EUN-84-500 | 1 | sztuka |
| 2CKA001510A0005 | Cover Busch-iceLight Reflector Ambient / orientation lightning / White studio white - 63x63 | 2068/11-84 | 1 | sztuka |
| 2CKA001510A0008 | Cover Busch-iceLight Reflector Ambient / orientation lightning, Infolight studio white - 63x63 | 2068/14-84 | 1 | sztuka |
| 2CKA001510A0017 | Cover Busch-iceLight Ambient lightning studio white - 63x63 | 2068/22-84 | 1 | sztuka |
| 2CKA001510A0015 | Busch-iceLight set with Night light; LED studio white - future linear | 2069/11-84 | 1 | sztuka |
| 2CKA002495A0086 | Equipotential socket insert Socket outlet 2-position studio white - 63x63 | 2095 UC-84 | 1 | sztuka |
| 2CKA002190A0215 | 2190 EUC-84 Socket Outl. S/F 1g | 2190 EUC-84 | 1 | sztuka |

| | | | | |
|-----------------|--|--------------------|---|--------|
| 2CKA002013A5477 | SCHUKO® socket insert Without imprint Safety Shutter studio white - 63x63 | 23 EUCB-84 | 1 | sztuka |
| 2CKA002013A5451 | SCHUKO® socket insert Without imprint Safety Shutter studio white - 63x63 | 2300 EUCB-84 | 1 | sztuka |
| 2CKA002113A0511 | 2300 UCRKS-84-503 Socket Outl. S | 2300 UCRKS-84-503 | 1 | sztuka |
| 2CKA002011A3833 | Busch-Protector® SCHUKO® socket insert Without imprint studio white - 63x63 | 2310 EUGL/VA-84-11 | 1 | sztuka |
| 2CKA002099A0198 | 2397 UCKS-84-505 Center PI, SF for 2300 | 2397 UCKS-84-505 | 1 | sztuka |
| 2CKA002013A5361 | 2398 CKS-84 Cover plate shuttered | 2398 CKS-84 | 1 | sztuka |
| 2CKA002099A0214 | Socket insert Without imprint Safety Shutter Earthing pin studio white - 63x63 | 2399 UCKS-84 | 1 | sztuka |
| 2CKA002099A0192 | 2399 UCKS-84-505 Center PI, SF for 23M | 2399 UCKS-84-505 | 1 | sztuka |
| 2CKA001751A3180 | Electronic Controls Symbol "bell" for Switch/push button Single rocker studio white - 63x63 | 2520 KI-84-500 | 1 | sztuka |
| 2CKA001751A3199 | Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white - 63x63 | 2520 TR-84 | 1 | sztuka |
| 2CKA001724A4256 | Cover plate Bore hole 1 gang studio white - 63x63 | 2533-84 | 1 | sztuka |
| 2CKA001710A3646 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button studio white - 63x63 | 2542 DR/01-84 | 1 | sztuka |
| 2CKA001710A3651 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button studio white - 63x63 | 2542 DR/02-84 | 1 | sztuka |
| 2CKA001724A4385 | Cover plate Call unit studio white - 63x63 | 2548-020 F-84 | 1 | sztuka |
| 2CKA001724A4387 | Cover plate Czerwony studio white - 63x63 | 2548-022 A-84 | 1 | sztuka |
| 2CKA001724A4388 | Cover plate Doctor Niebieski studio white - 63x63 | 2548-022 AR-84 | 1 | sztuka |
| 2CKA001724A4389 | Cover plate Call module Czerwony studio white - 63x63 | 2548-022 B-84 | 1 | sztuka |
| 2CKA001724A4390 | Cover plate Pull-cord switch studio white - 63x63 | 2548-046 A-84 | 1 | sztuka |
| 2CKA001724A4391 | Cover plate Call module Czerwony studio white - 63x63 | 2548-071 D-84 | 1 | sztuka |
| 2CKA001724A4392 | Cover plate Call module Czerwony studio white - 63x63 | 2548-071 E-84 | 1 | sztuka |
| 2CKA001724A4393 | Cover plate Call / reset Red / Green studio white - 63x63 | 2548-642 B-84 | 1 | sztuka |
| 2CKA001724A4395 | Cover plate Reset Zielony studio white - 63x63 | 2548-642 C-84 | 1 | sztuka |
| 2CKA001724A4402 | Cover plate XLR 1 gang studio white - 63x63 | 2553-84 | 1 | sztuka |
| 2CKA001753A0394 | Cover plate Modular Jack 2 gang studio white - 63x63 | 2561-02-84 | 1 | sztuka |
| 2CKA001753A0403 | Cover plate Modular Jack 1 gang studio white - 63x63 | 2561-84 | 1 | sztuka |
| 2CKA003116A0662 | FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA studio white - 63x63 | 3120 EUCB-84 | 1 | sztuka |
| 2CKA003117A0006 | Buschmat RCD - Insert RCD 30 mA studio white - 63x63 | 3151 UC-84 | 1 | sztuka |
| 2CKA006155A0121 | 6108/61-840-500 Coverplate f. CE | 6108/61-840-500 | 1 | sztuka |
| 2CKA006115A0486 | 6108/61-84-500 Coverplate f. CE | 6108/61-84-500 | 1 | sztuka |
| 2CKA006155A0114 | 6109/03-840-500 Coverplate f. RTC | 6109/03-840-500 | 1 | sztuka |
| 2CKA006155A0063 | 6109/03-84-500 Coverplate f. RTC | 6109/03-84-500 | 1 | sztuka |
| 2CKA006132A0407 | 6122/10-840-500 BW standard | 6122/10-840-500 | 1 | sztuka |
| 2CKA006132A0379 | Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° studio white | 6122/10-84-500 | 1 | sztuka |

| | | | | |
|-----------------|---|-----------------|---|--------|
| 2CKA006115A0183 | 6125/01-84-500 Control element 1g w. BAU | 6125/01-84-500 | 1 | sztuka |
| 2CKA006115A0452 | 6125/02-840-500 cont.-element KNX 1g | 6125/02-840-500 | 1 | sztuka |
| 2CKA006115A0219 | 6125/02-84-500 Control element 1/2gang | 6125/02-84-500 | 1 | sztuka |
| 2CKA006116A0174 | 6126/01-84-500 Control element 2g w. BAU | 6126/01-84-500 | 1 | sztuka |
| 2CKA006116A0227 | 6126/02-840-500 cont.-element KNX 2g | 6126/02-840-500 | 1 | sztuka |
| 2CKA006116A0209 | 6126/02-84-500 Control element 2/4gang | 6126/02-84-500 | 1 | sztuka |
| 2CKA006117A0200 | 6127/01-84-500 Control element 4g w. BAU | 6127/01-84-500 | 1 | sztuka |
| 2CKA006117A0252 | 6127/02-840-500 cont.-element KNX 4g | 6127/02-840-500 | 1 | sztuka |
| 2CKA006117A0235 | 6127/02-84-500 Control element 4/8gang | 6127/02-84-500 | 1 | sztuka |
| 2CKA006134A0342 | 6128/28-840-500 RTC Control element 2/4g | 6128/28-840-500 | 1 | sztuka |
| 2CKA006134A0334 | 6128/28-84-500 RTC Control element 2/4g | 6128/28-84-500 | 1 | sztuka |
| 2CKA006135A0146 | 6129/01-84-500 Control element 3/6g w. IR | 6129/01-84-500 | 1 | sztuka |
| 2CKA006430A0400 | 6430-84-102-500 Control Cover | 6430-84-102-500 | 1 | sztuka |
| 2CKA006430A0306 | Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate studio white - 63x63 | 6435-84 | 1 | sztuka |
| 2CKA006400A0059 | Cover plate PowerDock 1 gang studio white - 63x63 | 6477-84 | 1 | sztuka |
| 2CKA006400A0047 | Multimedia Devices studio white - solo | 6480/11-84-500 | 1 | sztuka |
| 2CKA006400A0045 | Multimedia Devices studio white - future linear | 6480-84-500 | 1 | sztuka |
| 2CKA006599A3009 | 6540-84-102-500 Center Pl. SF Dimmer | 6540-84-102-500 | 1 | sztuka |
| 2CKA006599A2835 | Cover plate None for Cooling Central cover plate studio white - 63x63 | 6541-84 | 1 | sztuka |
| 2CKA006599A3010 | 6543-84-101-500 Dimmer Control Cover | 6543-84-101-500 | 1 | sztuka |
| 2CKA006599A2908 | Control Element None for Dimmer Two-part button with Neon lamp studio white - 63x63 | 6545-84 | 1 | sztuka |
| 2CKA006730A0038 | Electronic Controls 1 channel Radio Control studio white - 63x63 | 6731-84-500 | 1 | sztuka |
| 2CKA006730A0039 | Electronic Controls 2 channel Radio Control studio white - 63x63 | 6732-84-500 | 1 | sztuka |
| 2CKA006730A0040 | 6733-84-500 RF-Switch Sensor 4-fold | 6733-84-500 | 1 | sztuka |
| 2CKA006800A2834 | Electronic Controls studio white - 63x63 | 6815-84-101-500 | 1 | sztuka |
| 2CKA008200A0255 | Cover plate with legend Radio 0 gang studio white - 63x63 | 8252-84-101-500 | 1 | sztuka |
| 2CKA008200A0081 | Cover plate Loudspeaker studio white - 63x63 | 8253-84 | 1 | sztuka |
| 2CKA008300A0225 | 83260-84-515 Cover plates, Indoor St. | 83260-84-515 | 1 | sztuka |
| 2CKA006220A0244 | CP-FCC-84 C-plate Fan Coil | CP-FCC-84 | 1 | sztuka |
| 2CKA006220A0181 | CP-RTC-84 C-plate RT sensor unit | CP-RTC-84 | 1 | sztuka |
| 2CKA006220A0384 | CP-RTC-840 c-plate temp. | CP-RTC-840 | 1 | sztuka |
| 2CKA006220A0214 | MD-F-1.0.1-84 Movement detector | MD-F-1.0.1-84 | 1 | sztuka |
| 2CKA006220A0385 | MD-F-1.0.1-840 WD 180 sens | MD-F-1.0.1-840 | 1 | sztuka |

| | | | | |
|-----------------|---|-------------------|---|--------|
| 2CKA006220A0217 | MSA-F-1.1.1-84 Mov. detector/actuator 1g | MSA-F-1.1.1-84 | 1 | sztuka |
| 2CKA006220A0386 | MSA-F-1.1.1-840 WD 180 sens actuator | MSA-F-1.1.1-840 | 1 | sztuka |
| 2CKA006220A0086 | MSA-F-1.1.1-84-WL WL-Mov. detector/act. 1g | MSA-F-1.1.1-84-WL | 1 | sztuka |
| 2CKA006220A0139 | SR-1-84 rocker 1gang | SR-1-84 | 1 | sztuka |
| 2CKA006220A0371 | Electronic Controls antique brass - 63x63 | SR-1-840 | 1 | sztuka |
| 2CKA006220A0154 | SR-2-84 rocker 2gang | SR-2-84 | 1 | sztuka |
| 2CKA006220A0376 | Electronic Controls antique brass - 63x63 | SR-2-840 | 1 | sztuka |
| 2CKA006220A0145 | SRB-1-84 rocker 1gang, blinds | SRB-1-84 | 1 | sztuka |
| 2CKA006220A0373 | Electronic Controls antique brass - 63x63 | SRB-1-840 | 1 | sztuka |
| 2CKA006220A0160 | SRB-2-84 rocker 2g, blinds | SRB-2-84 | 1 | sztuka |
| 2CKA006220A0378 | Electronic Controls antique brass - 63x63 | SRB-2-840 | 1 | sztuka |
| 2CKA006220A0151 | SRD-1-84 rocker 1gang, dimming | SRD-1-84 | 1 | sztuka |
| 2CKA006220A0375 | Electronic Controls antique brass - 63x63 | SRD-1-840 | 1 | sztuka |
| 2CKA006220A0166 | SRD-2-L-84 rocker 2g, left, dimming | SRD-2-L-84 | 1 | sztuka |
| 2CKA006220A0380 | Electronic Controls antique brass - 63x63 | SRD-2-L-840 | 1 | sztuka |
| 2CKA006220A0260 | SRD-2-R-84 rocker 2g, right, dimming | SRD-2-R-84 | 1 | sztuka |
| 2CKA006220A0383 | Electronic Controls antique brass - 63x63 | SRD-2-R-840 | 1 | sztuka |
| 2CKA006220A0142 | SRL-1-84 rocker 1gang, lighting | SRL-1-84 | 1 | sztuka |
| 2CKA006220A0372 | Electronic Controls antique brass - 63x63 | SRL-1-840 | 1 | sztuka |
| 2CKA006220A0157 | SRL-2-L-84 rocker 2g, left, lighting | SRL-2-L-84 | 1 | sztuka |
| 2CKA006220A0377 | Electronic Controls antique brass - 63x63 | SRL-2-L-840 | 1 | sztuka |
| 2CKA006220A0169 | SRL-2-R-84 rocker 2g, right, lighting | SRL-2-R-84 | 1 | sztuka |
| 2CKA006220A0381 | Electronic Controls antique brass - 63x63 | SRL-2-R-840 | 1 | sztuka |
| 2CKA006220A0148 | SRS-1-84 rocker 1gang, scene | SRS-1-84 | 1 | sztuka |
| 2CKA006220A0374 | Electronic Controls antique brass - 63x63 | SRS-1-840 | 1 | sztuka |
| 2CKA006220A0163 | SRS-2-L-84 rocker 2gang, left, scene | SRS-2-L-84 | 1 | sztuka |
| 2CKA006220A0379 | Electronic Controls antique brass - 63x63 | SRS-2-L-840 | 1 | sztuka |
| 2CKA006220A0175 | SRS-2-R-84 rocker 2g, right, scene | SRS-2-R-84 | 1 | sztuka |
| 2CKA006220A0382 | Electronic Controls antique brass - 63x63 | SRS-2-R-840 | 1 | sztuka |
| 2CKA001751A3170 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, with LED 1NO studio white - 63x63 | 2029 UC-84 | 1 | sztuka |
| 2CKA001719A0220 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring studio white - 63x63 | 2518-WD-84 | 1 | sztuka |
| 2CKA006710A0011 | Kits 4 chan. Zigbee studio white - future linear | 6716 UJ-84-500 | 1 | sztuka |
| 2CKA006730A0136 | Control Element None for Dimmer Two-part button studio white - 63x63 | 6736 FoH-84 | 1 | sztuka |
| 2CKA001032A0523 | Room Temperature Controller set studio white - future linear | 1098 UJ-84 | 1 | sztuka |
| 2CKA001799A0984 | 1701 P-84 SM box, 1-gang, Philips | 1701 P-84 | 1 | sztuka |
| 2CKA001799A0982 | Mounting Box 1 gang studio white - future linear | 1701-84-500 | 1 | sztuka |
| 2CKA001799A0902 | Mounting Box 2 gang studio white - future linear | 1702-84 | 1 | sztuka |
| 2CKA001799A0918 | Mounting Box 3 gang studio white - future linear | 1703-84 | 1 | sztuka |
| 2CKA001751A3209 | Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang studio white - 63x63 | 1785/11 K-84 | 1 | sztuka |
| 2CKA001710A4127 | Cover plate with legend Card, Symbol "arrows" Hotel card studio white - 63x63 | 1792 RFID-84 | 1 | sztuka |
| 2CKA001710A4201 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white - 63x63 | 1794 R-84 | 1 | sztuka |

| | | | | |
|-----------------|--|---------------------|---|--------|
| 2CKA001710A4202 | Cover plate Characters 1 ... 6 for Thermostat Turn button studio white - solo | 1794 R-84-500 | 1 | sztuka |
| 2CKA002011A6274 | Socket insert None Protective contact (SCHUKO) with USB AA studio white - 63x63 | 20 EUCB2USB-84-500 | 1 | sztuka |
| 2CKA002011A6281 | Socket insert None Protective contact (SCHUKO) with USB AA antique brass anthracite - 63x63 | 20 EUCB2USB-845-500 | 1 | sztuka |
| 2CKA002017A1891 | Socket None Earthing pin with USB AA studio white - 63x63 | 20 MUCB2USB-84-500 | 1 | sztuka |
| 2CKA002017A0885 | Flush Mounted Inserts CSN-Norm 250 V | 2017-0-0885 | 1 | sztuka |
| 2CKA001751A3231 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, studio white - 63x63 | 2029/12 UC-84 | 1 | sztuka |
| 2CKA001751A3220 | Rocker with legend DND, MUR for Switch/push button Two-part rocker studio white - 63x63 | 2058-24-84 | 1 | sztuka |
| 2CKA001751A3240 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang studio white - 63x63 | 2059 UC-84 | 1 | sztuka |
| 2CKA001761A1495 | Cable Entry studio white - future linear | 2087-84 | 1 | sztuka |
| 2CKA001761A1500 | Cable Entry studio white - future linear | 2088-84 | 1 | sztuka |
| 2CKA001751A3190 | Mechanical Controls Symbol "light" for Switch/push button, Single rocker studio white - 63x63 | 2520 LI-84-500 | 1 | sztuka |
| 2CKA001724A4383 | Cover plate Call unit studio white - 63x63 | 2548-020 D-84 | 1 | sztuka |
| 2CKA001724A4384 | Cover plate Call unit studio white - 63x63 | 2548-020 E-84 | 1 | sztuka |
| 2CKA001724A4386 | Cover plate Call unit studio white - 63x63 | 2548-021 G-84 | 1 | sztuka |
| 2CKA001724A4394 | Cover plate Duty room unit White / Green studio white - 63x63 | 2548-642 BD-84 | 1 | sztuka |
| 2CKA001724A4396 | Cover plate Reset Żółty studio white - 63x63 | 2548-642 D-84 | 1 | sztuka |
| 2CKA001751A3258 | Rocker for Switch/push button Single rocker studio white - 63x63 | 2570-10-84 | 1 | sztuka |
| 2CKA001751A3269 | Rocker for Switch/push button Two-part rocker studio white - 63x63 | 2570-20-84 | 1 | sztuka |
| 2CKA001751A3280 | Rocker for Switch/push button Three-part rocker studio white - 63x63 | 2570-30-84 | 1 | sztuka |
| 2CKA006132A0263 | Solo Horizontal 0 ... 180 ° studio white | 6122/02-84-500 | 1 | sztuka |
| 2CKA006134A0222 | 6124-84-101 Room Thermostat with Display | 6124-84-101 | 1 | sztuka |
| 2CKA006134A0223 | 6124-84-500-101 Room Thermostat with Display | 6124-84-500-101 | 1 | sztuka |
| 2CKA006134A0212 | 6128-84-500-101 RoomThermostat/Switch Sensor | 6128-84-500-101 | 1 | sztuka |
| 2CKA006200A0196 | 62762 UJ-84-WL-500 WD 180 flex set comfort WL | 62762 UJ-84-WL-500 | 1 | sztuka |
| 2CKA006200A0172 | 62762-84-WL-500 WD 180 flex conf. sens. WL | 62762-84-WL-500 | 1 | sztuka |
| 2CKA006200A0240 | 62764-84-WL-500 WD 180 flex multi sens. WL | 62764-84-WL-500 | 1 | sztuka |
| 2CKA006200A0295 | Kits 1gang studio white - future linear | 62851 UJ-84-WL-500 | 1 | sztuka |
| 2CKA006800A2951 | Kits Movement sensor 1gang studio white - future linear | 64761 UJ-84-500 | 1 | sztuka |
| 2CKA006800A2934 | Busch-Watchdog Cover plate Movement sensor antique brass - 63x63 | 64761-840-500 | 1 | sztuka |
| 2CKA006800A2927 | Electronic Controls Movement sensor studio white - 63x63 | 64761-84-500 | 1 | sztuka |
| 2CKA006800A2988 | Kits Movement sensor 1gang studio white - future linear | 64762 UJ-84-500 | 1 | sztuka |
| 2CKA006800A2964 | 64762-84-500 WD 180 flex comfort sensor | 64762-84-500 | 1 | sztuka |

| | | | | |
|-----------------|---|--------------------|---|--------|
| 2CKA006800A3025 | Kits Movement sensor 1gang studio white - future linear | 64764 UJ-84-500 | 1 | sztuka |
| 2CKA006800A3008 | Busch-Watchdog Cover plate Movement sensor antique brass - 63x63 | 64764-840-500 | 1 | sztuka |
| 2CKA006800A3001 | 64764-84-500 WD 180 flex, multi sensor | 64764-84-500 | 1 | sztuka |
| 2CKA006800A2889 | Electronic Controls Movement sensor studio white - 63x63 | 64765-84-500 | 1 | sztuka |
| 2CKA006730A0154 | Smart switch set 4 chan. Bluetooth studio white - future linear | 6716/01 UJ-84 | 1 | sztuka |
| 2CKA006730A0156 | Kits 4 chan. Bluetooth studio white - future linear | 6716/01 UJ-84-500 | 1 | sztuka |
| 2CKA006730A0158 | Kits 4 channel Bluetooth studio white - future linear | 6716/01 UJ-84-510 | 1 | sztuka |
| 2CKA006730A0145 | Rocker None for Dimmer Single rocker studio white - 63x63 | 6735 BT-84 | 1 | sztuka |
| 2CKA006730A0082 | Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control studio white - 63x63 | 6735/01-84 | 1 | sztuka |
| 2CKA006730A0164 | Electronic Controls None for Dimmer Single rocker studio white - 63x63 | 6735/10-84 | 1 | sztuka |
| 2CKA006730A0070 | Control Element for Switch/dimmer 1gang Radio Control studio white - 63x63 | 6735-84 | 1 | sztuka |
| 2CKA006730A0086 | Wall sensor 2 channel 2gang Radio Control studio white - 63x63 | 6736/01-84 | 1 | sztuka |
| 2CKA006730A0165 | Electronic Controls None for Dimmer Two-part button studio white - 63x63 | 6736/10-84 | 1 | sztuka |
| 2CKA006730A0074 | Control Element for Switch/dimmer 2gang Radio Control studio white - 63x63 | 6736-84 | 1 | sztuka |
| 2CKA006730A0090 | Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control studio white - 63x63 | 6737/01-84 | 1 | sztuka |
| 2CKA006730A0078 | Control Element for Switch/dimmer 4gang Radio Control studio white - 63x63 | 6737-84 | 1 | sztuka |
| 2CKA006800A2101 | 6800-84-104 Watchdog Comfort Sensor 180 | 6800-84-104 | 1 | sztuka |
| 2CKA008200A0234 | Busch-Radio set DAB+ studio white - future linear | 8220 UJ-84-101-500 | 1 | sztuka |
| 2CKA008200A0156 | Multimedia Devices Radio receiver studio white - future linear | 8240-84-500 | 1 | sztuka |
| 2CKA008200A0224 | Cover plate Multimedia 3 gang studio white - 63x63 | 8256-84 | 1 | sztuka |
| 2CKA008200A0237 | Busch-Radio set DAB+ studio white - future linear | 8270 UJ-84-101-500 | 1 | sztuka |
| 2CKA001731A1976 | Cover Busch-Infolicht® grey metallic - 63x63 | 1716-803 | 1 | sztuka |
| 2CKA001731A1921 | Cover Busch-Infolicht® anthracite - 63x63 | 1716-81 | 1 | sztuka |
| 2CKA001731A1950 | Cover Busch-Infolicht® aluminium silver - 63x63 | 1716-83 | 1 | sztuka |
| 2CKA001731A1955 | Cover Busch-Infolicht® stainless steel - Pure Stainless Steel | 1716-866 | 1 | sztuka |
| 2CKA001731A1978 | Cover Busch-Infolicht® studio white matt - 63x63 | 1716-884 | 1 | sztuka |
| 2CKA001731A1980 | Cover Busch-Infolicht® black matt - 63x63 | 1716-885 | 1 | sztuka |
| 2CKA001731A1914 | Rocker None for Pull-cord switch, Pull cord anthracite - 63x63 | 1720-81 | 1 | sztuka |
| 2CKA001731A1915 | Rocker None for Pull-cord switch, Pull cord ivory white - 63x63 | 1720-82 | 1 | sztuka |
| 2CKA001731A1949 | Rocker for Pull-cord switch, Pull cord aluminium silver - 63x63 | 1720-83 | 1 | sztuka |
| 2CKA001731A1954 | Rocker None for Pull-cord switch, Pull cord stainless steel - Pure Stainless Steel | 1720-866 | 1 | sztuka |
| 2CKA001731A1979 | Rocker None for Pull-cord switch, Pull cord studio white matt - 63x63 | 1720-884 | 1 | sztuka |

| | | | | |
|-----------------|--|------------------|---|--------|
| 2CKA001731A1981 | Rocker None for Pull-cord switch, Pull cord black matt - 63x63 | 1720-885 | 1 | sztuka |
| 2CKA001710A4119 | Cover plate with legend Level switch Turn button grey metallic - 63x63 | 1740 DR/03-803 | 1 | sztuka |
| 2CKA001710A4120 | Cover plate with legend Level switch Turn button anthracite - 63x63 | 1740 DR/03-81 | 1 | sztuka |
| 2CKA001710A3807 | Cover plate with legend Level switch Turn button ivory white - 63x63 | 1740 DR/03-82 | 1 | sztuka |
| 2CKA001710A3811 | Cover plate with legend Level switch Turn button aluminium silver - 63x63 | 1740 DR/03-83 | 1 | sztuka |
| 2CKA001710A3812 | Cover plate with legend Level switch Turn button stainless steel - Pure Stainless Steel | 1740 DR/03-866 | 1 | sztuka |
| 2CKA001710A3870 | Cover plate with legend Level switch Turn button studio white matt - 63x63 | 1740 DR/03-884 | 1 | sztuka |
| 2CKA001710A3892 | Cover plate with legend Level switch Turn button black matt - 63x63 | 1740 DR/03-885 | 1 | sztuka |
| 2CKA001710A4121 | Mechanical Controls Symbol "2-1-3" for Level switch, Turn button grey metallic - 63x63 | 1740 DRL-803-503 | 1 | sztuka |
| 2CKA001710A4122 | Mechanical Controls Symbol "2-1-3" for Level switch, Turn button anthracite - 63x63 | 1740 DRL-81-503 | 1 | sztuka |
| 2CKA001710A3511 | Mechanical Controls Symbol "2-1-3" for Level switch, Turn button ivory white - 63x63 | 1740 DRL-82-503 | 1 | sztuka |
| 2CKA001710A4123 | Mechanical Controls Symbol "2-1-3" for Level switch, Turn button aluminium silver - 63x63 | 1740 DRL-83-503 | 1 | sztuka |
| 2CKA001710A3771 | Mechanical Controls Symbol "2-1-3" for Level switch, Turn button stainless steel - Pure Stainless Steel | 1740 DRL-866-503 | 1 | sztuka |
| 2CKA001710A3871 | Mechanical Controls Symbol "2-1-3" for Level switch, Turn button studio white matt - 63x63 | 1740 DRL-884-503 | 1 | sztuka |
| 2CKA001710A3893 | Mechanical Controls Symbol "2-1-3" for Level switch, Turn button black matt - 63x63 | 1740 DRL-885-503 | 1 | sztuka |
| 2CKA001710A3840 | Cover plate with legend Symbol "arrows" for Venetian blind, Turn button grey metallic - 63x63 | 1740-803 | 1 | sztuka |
| 2CKA001710A3623 | Cover plate with legend Symbol "arrows" for Venetian blind, Turn button anthracite - 63x63 | 1740-81 | 1 | sztuka |
| 2CKA001710A3154 | Cover plate with legend Symbol "arrows" for Venetian blind, Turn button ivory white - 63x63 | 1740-82 | 1 | sztuka |
| 2CKA001710A3661 | Cover plate with legend Symbol "arrows" for Venetian blind, Turn button aluminium silver - 63x63 | 1740-83 | 1 | sztuka |
| 2CKA001710A3748 | Cover plate with legend Symbol "arrows" for Venetian blind, Turn button stainless steel - Pure Stainless Steel | 1740-866 | 1 | sztuka |
| 2CKA001710A3872 | Cover plate with legend Symbol "arrows" for Venetian blind, Turn button studio white matt - 63x63 | 1740-884 | 1 | sztuka |
| 2CKA001710A3894 | Cover plate with legend Symbol "arrows" for Venetian blind, Turn button black matt - 63x63 | 1740-885 | 1 | sztuka |
| 2CKA001710A3843 | Cover plate Blind cap 1 gang with Mounting plate grey metallic - 63x63 | 1742-803 | 1 | sztuka |
| 2CKA001710A3612 | Cover plate Blind cap 1 gang with Mounting plate anthracite - 63x63 | 1742-81 | 1 | sztuka |
| 2CKA001710A3143 | Cover plate Blind cap 1 gang with Mounting plate ivory white - 63x63 | 1742-82 | 1 | sztuka |
| 2CKA001710A3664 | Cover plate Blind cap 1 gang with Mounting plate aluminium silver - 63x63 | 1742-83 | 1 | sztuka |
| 2CKA001710A3751 | Cover plate Blind cap 1 gang with Mounting plate stainless steel - Pure Stainless Steel | 1742-866 | 1 | sztuka |
| 2CKA001710A3873 | Cover plate Blind cap 1 gang with Mounting plate studio white matt - 63x63 | 1742-884 | 1 | sztuka |
| 2CKA001710A3895 | Cover plate Blind cap 1 gang with Mounting plate black matt - 63x63 | 1742-885 | 1 | sztuka |

| | | | | |
|-----------------|---|----------------|---|--------|
| 2CKA001724A4364 | Cover plate SAT 4 gang grey metallic - 63x63 | 1743/10-04-803 | 1 | sztuka |
| 2CKA001724A4365 | Cover plate SAT 4 gang anthracite - 63x63 | 1743/10-04-81 | 1 | sztuka |
| 2CKA001724A4366 | Cover plate SAT 4 gang ivory white - 63x63 | 1743/10-04-82 | 1 | sztuka |
| 2CKA001724A4367 | Cover plate SAT 4 gang aluminium silver - 63x63 | 1743/10-04-83 | 1 | sztuka |
| 2CKA001724A4369 | Cover plate SAT 4 gang stainless steel - Pure Stainless Steel | 1743/10-04-866 | 1 | sztuka |
| 2CKA001724A4370 | Cover plate TV / Radio / 2x SAT 4 gang studio white matt - 63x63 | 1743/10-04-884 | 1 | sztuka |
| 2CKA001724A4371 | Cover plate SAT 4 gang black matt - 63x63 | 1743/10-04-885 | 1 | sztuka |
| 2CKA001724A4373 | Cover plate TV / Radio / 2x SAT 4 gang grey metallic - 63x63 | 1743-04-803 | 1 | sztuka |
| 2CKA001724A4374 | Cover plate SAT 4 gang anthracite - 63x63 | 1743-04-81 | 1 | sztuka |
| 2CKA001724A4375 | Cover plate TV / Radio / 2x SAT 4 gang ivory white - 63x63 | 1743-04-82 | 1 | sztuka |
| 2CKA001724A4376 | Cover plate SAT 4 gang aluminium silver - 63x63 | 1743-04-83 | 1 | sztuka |
| 2CKA001724A4378 | Cover plate SAT 4 gang stainless steel - Pure Stainless Steel | 1743-04-866 | 1 | sztuka |
| 2CKA001724A4379 | Cover plate TV / Radio / 2x SAT 4 gang studio white matt - 63x63 | 1743-04-884 | 1 | sztuka |
| 2CKA001724A4380 | Cover plate SAT 4 gang black matt - 63x63 | 1743-04-885 | 1 | sztuka |
| 2CKA001724A4291 | Cover plate SAT 3 gang grey metallic - 63x63 | 1743-803 | 1 | sztuka |
| 2CKA001724A4252 | Cover plate SAT 3 gang anthracite - 63x63 | 1743-81 | 1 | sztuka |
| 2CKA001724A2758 | Cover plate SAT 3 gang ivory white - 63x63 | 1743-82 | 1 | sztuka |
| 2CKA001724A4262 | Cover plate SAT 3 gang aluminium silver - 63x63 | 1743-83 | 1 | sztuka |
| 2CKA001724A4271 | Cover plate SAT 3 gang stainless steel - Pure Stainless Steel | 1743-866 | 1 | sztuka |
| 2CKA001724A4293 | Cover plate SAT 3 gang studio white matt - 63x63 | 1743-884 | 1 | sztuka |
| 2CKA001724A4298 | Cover plate SAT 3 gang black matt - 63x63 | 1743-885 | 1 | sztuka |
| 2CKA001710A3855 | Cover plate telephone connector boxes (VDo) grey metallic - 63x63 | 1745-803 | 1 | sztuka |
| 2CKA001710A3624 | Cover plate telephone connector boxes (VDo) anthracite - 63x63 | 1745-81 | 1 | sztuka |
| 2CKA001710A3155 | Cover plate telephone connector boxes (VDo) ivory white - 63x63 | 1745-82 | 1 | sztuka |
| 2CKA001710A3675 | Cover plate telephone connector boxes (VDo) aluminium silver - 63x63 | 1745-83 | 1 | sztuka |
| 2CKA001710A3766 | Cover plate telephone connector boxes (VDo) stainless steel - Pure Stainless Steel | 1745-866 | 1 | sztuka |
| 2CKA001710A3874 | Cover plate telephone connector boxes (VDo) studio white matt - 63x63 | 1745-884 | 1 | sztuka |
| 2CKA001710A3896 | Cover plate telephone connector boxes (VDo) black matt - 63x63 | 1745-885 | 1 | sztuka |
| 2CKA001710A3857 | Cover plate Telecommunication inserts 50 x 50 mm grey metallic - 63x63 | 1746/10-803 | 1 | sztuka |
| 2CKA001710A3628 | Cover plate Telecommunication inserts 50 x 50 mm anthracite - 63x63 | 1746/10-81 | 1 | sztuka |
| 2CKA001710A3521 | Cover plate Telecommunication inserts 50 x 50 mm ivory white - 63x63 | 1746/10-82 | 1 | sztuka |
| 2CKA001710A3677 | Cover plate Telecommunication inserts 50 x 50 mm aluminium silver - 63x63 | 1746/10-83 | 1 | sztuka |
| 2CKA001710A3768 | Cover plate Telecommunication inserts 50 x 50 mm stainless steel - Pure Stainless Steel | 1746/10-866 | 1 | sztuka |
| 2CKA001710A3875 | Cover plate Telecommunication inserts 50 x 50 mm studio white matt - 63x63 | 1746/10-884 | 1 | sztuka |
| 2CKA001710A3897 | Cover plate Telecommunication inserts 50 x 50 mm black matt - 63x63 | 1746/10-885 | 1 | sztuka |

| | | | | |
|-----------------|--|--------------|---|--------|
| 2CKA001710A3858 | Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang grey metallic - 63x63 | 1746-803 | 1 | sztuka |
| 2CKA001710A3618 | Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang anthracite - 63x63 | 1746-81 | 1 | sztuka |
| 2CKA001710A3149 | Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang ivory white - 63x63 | 1746-82 | 1 | sztuka |
| 2CKA001710A3678 | Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang aluminium silver - 63x63 | 1746-83 | 1 | sztuka |
| 2CKA001710A3769 | Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang stainless steel - Pure Stainless Steel | 1746-866 | 1 | sztuka |
| 2CKA001710A3876 | Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang studio white matt - 63x63 | 1746-884 | 1 | sztuka |
| 2CKA001710A3898 | Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang black matt - 63x63 | 1746-885 | 1 | sztuka |
| 2CKA001710A4092 | Intermediate Ring for cover plates Busch-Balance® SI grey metallic - 63x63 | 1747 BSI-803 | 1 | sztuka |
| 2CKA001710A4093 | Intermediate Ring for cover plates Busch-Balance® SI anthracite - 63x63 | 1747 BSI-81 | 1 | sztuka |
| 2CKA001710A4094 | Intermediate Ring for cover plates Busch-Balance® SI ivory white - 63x63 | 1747 BSI-82 | 1 | sztuka |
| 2CKA001710A4095 | Intermediate Ring for cover plates Busch-Balance® SI aluminium silver - 63x63 | 1747 BSI-83 | 1 | sztuka |
| 2CKA001710A4097 | Intermediate Ring for cover plates Busch-Balance® SI stainless steel - Pure Stainless Steel | 1747 BSI-866 | 1 | sztuka |
| 2CKA001710A4098 | Intermediate Ring for cover plates Busch-Balance® SI studio white matt - 63x63 | 1747 BSI-884 | 1 | sztuka |
| 2CKA001710A4099 | Intermediate Ring for cover plates Busch-Balance® SI black matt - 63x63 | 1747 BSI-885 | 1 | sztuka |
| 2CKA001710A3862 | Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI ivory white - 63x63 | 1747 SI-82 | 1 | sztuka |
| 2CKA001710A3860 | Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI ivory white - 63x63 | 1747-82 | 1 | sztuka |
| 2CKA001710A3844 | Cover plate Cable outlet with Mounting plate grey metallic - 63x63 | 1749-803 | 1 | sztuka |
| 2CKA001710A3614 | Cover plate Cable outlet with Mounting plate anthracite - 63x63 | 1749-81 | 1 | sztuka |
| 2CKA001710A3145 | Cover plate Cable outlet with Mounting plate ivory white - 63x63 | 1749-82 | 1 | sztuka |
| 2CKA001710A3665 | Cover plate Cable outlet with Mounting plate aluminium silver - 63x63 | 1749-83 | 1 | sztuka |
| 2CKA001710A3752 | Cover plate Cable outlet with Mounting plate stainless steel - Pure Stainless Steel | 1749-866 | 1 | sztuka |
| 2CKA001710A3878 | Cover plate Cable outlet with Mounting plate studio white matt - 63x63 | 1749-884 | 1 | sztuka |
| 2CKA001710A3900 | Cover plate Cable outlet with Mounting plate black matt - 63x63 | 1749-885 | 1 | sztuka |
| 2CKA001710A3679 | Cover plate BNC/TNC 2 gang aluminium silver - 63x63 | 1750-83 | 1 | sztuka |
| 2CKA001723A0257 | Cover plate Loudspeaker 2 gang grey metallic - 63x63 | 1751-803 | 1 | sztuka |
| 2CKA001723A0253 | Cover plate Loudspeaker 2 gang anthracite - 63x63 | 1751-81 | 1 | sztuka |
| 2CKA001723A0239 | Cover plate Loudspeaker 2 gang ivory white - 63x63 | 1751-82 | 1 | sztuka |
| 2CKA001723A0254 | Cover plate Loudspeaker 2 gang aluminium silver - 63x63 | 1751-83 | 1 | sztuka |
| 2CKA001723A0255 | Cover plate Loudspeaker 2 gang stainless steel - Pure Stainless Steel | 1751-866 | 1 | sztuka |

| | | | | |
|-----------------|--|--------------------|---|--------|
| 2CKA001723A0260 | Cover plate Loudspeaker 2 gang studio white matt - 63x63 | 1751-884 | 1 | sztuka |
| 2CKA001723A0259 | Cover plate Loudspeaker 2 gang black matt - 63x63 | 1751-885 | 1 | sztuka |
| 2CKA001710A3841 | Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key grey metallic - 63x63 | 1755 SL/PZ-803-101 | 1 | sztuka |
| 2CKA001710A3626 | Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key anthracite - 63x63 | 1755 SL/PZ-81-101 | 1 | sztuka |
| 2CKA001710A3157 | Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key ivory white - 63x63 | 1755 SL/PZ-82-101 | 1 | sztuka |
| 2CKA001710A3662 | Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key aluminium silver - 63x63 | 1755 SL/PZ-83-101 | 1 | sztuka |
| 2CKA001710A3749 | Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key stainless steel - Pure Stainless Steel | 1755 SL/PZ-866-101 | 1 | sztuka |
| 2CKA001710A3925 | Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key studio white matt - 63x63 | 1755 SL/PZ-884-101 | 1 | sztuka |
| 2CKA001710A3902 | Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key black matt - 63x63 | 1755 SL/PZ-885-101 | 1 | sztuka |
| 2CKA001724A4292 | Cover plate with labelling field For data connection housing 2 gang grey metallic - 63x63 | 1758-803 | 1 | sztuka |
| 2CKA001724A4253 | Cover plate with labelling field For data connection housing 2 gang anthracite - 63x63 | 1758-81 | 1 | sztuka |
| 2CKA001724A2759 | Cover plate with labelling field For data connection housing 2 gang ivory white - 63x63 | 1758-82 | 1 | sztuka |
| 2CKA001724A4263 | Cover plate with labelling field For data connection housing 2 gang aluminium silver - 63x63 | 1758-83 | 1 | sztuka |
| 2CKA001724A4272 | Cover plate with labelling field For data connection housing 2 gang stainless steel - Pure Stainless Steel | 1758-866 | 1 | sztuka |
| 2CKA001724A4307 | Cover plate with labelling field For data connection housing 2 gang studio white matt - 63x63 | 1758-884 | 1 | sztuka |
| 2CKA001724A4299 | Cover plate with labelling field For data connection housing 2 gang black matt - 63x63 | 1758-885 | 1 | sztuka |
| 2CKA001731A3997 | Rocker with labelling field Symbol "bell" for Switch/push button, Single push button grey metallic - 63x63 | 1764 NLI/KI-803 | 1 | sztuka |
| 2CKA001731A3998 | Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single push button with Pilot lamp anthracite - 63x63 | 1764 NLI/KI-81 | 1 | sztuka |
| 2CKA001731A3999 | Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single push button with Pilot lamp ivory white - 63x63 | 1764 NLI/KI-82 | 1 | sztuka |
| 2CKA001731A4000 | Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single push button with Pilot lamp aluminium silver - 63x63 | 1764 NLI/KI-83 | 1 | sztuka |
| 2CKA001731A4003 | Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single push button with Pilot lamp stainless steel - Pure Stainless Steel | 1764 NLI/KI-866 | 1 | sztuka |
| 2CKA001731A4004 | Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single push button with Pilot lamp studio white matt - 63x63 | 1764 NLI/KI-884 | 1 | sztuka |
| 2CKA001731A4005 | Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single push button with Pilot lamp black matt - 63x63 | 1764 NLI/KI-885 | 1 | sztuka |
| 2CKA001731A4011 | Rocker with labelling field for Switch/push button, Single push button with Pilot lamp red - 63x63 | 1764 NLI-12-82-101 | 1 | sztuka |
| 2CKA001731A4007 | Rocker with labelling field for Switch/push button, Single push button with Pilot lamp green - 63x63 | 1764 NLI-13-82 | 1 | sztuka |
| 2CKA001731A1975 | Rocker with labelling field for Switch/push button, Single rocker grey metallic - 63x63 | 1764 NLI-803 | 1 | sztuka |

| | | | | |
|-----------------|---|---------------|---|--------|
| 2CKA001731A1552 | Rocker with labelling field for Switch/push button, Single push button with Pilot lamp anthracite - 63x63 | 1764 NLI-81 | 1 | sztuka |
| 2CKA001731A1876 | Rocker with labelling field for Switch/push button, Single push button with Pilot lamp ivory white - 63x63 | 1764 NLI-82 | 1 | sztuka |
| 2CKA001731A1948 | Rocker with labelling field for Switch/push button, Single push button with Pilot lamp aluminium silver - 63x63 | 1764 NLI-83 | 1 | sztuka |
| 2CKA001731A1953 | Rocker with labelling field for Switch/push button, Single push button with Pilot lamp stainless steel - Pure Stainless Steel | 1764 NLI-866 | 1 | sztuka |
| 2CKA001731A1985 | Rocker with labelling field for Switch/push button, Single push button with Pilot lamp studio white matt - 63x63 | 1764 NLI-884 | 1 | sztuka |
| 2CKA001731A1982 | Rocker with labelling field for Switch/push button, Single push button with Pilot lamp black matt - 63x63 | 1764 NLI-885 | 1 | sztuka |
| 2CKA001710A3854 | Cover plate TAE 1 gang grey metallic - 63x63 | 1766-803 | 1 | sztuka |
| 2CKA001710A3613 | Cover plate TAE 1 gang anthracite - 63x63 | 1766-81 | 1 | sztuka |
| 2CKA001710A3144 | Cover plate TAE 1 gang ivory white - 63x63 | 1766-82 | 1 | sztuka |
| 2CKA001710A3659 | Cover plate TAE 1 gang aluminium silver - 63x63 | 1766-83 | 1 | sztuka |
| 2CKA001710A3765 | Cover plate TAE 1 gang stainless steel - Pure Stainless Steel | 1766-866 | 1 | sztuka |
| 2CKA001710A3926 | Cover plate TAE 1 gang studio white matt - 63x63 | 1766-884 | 1 | sztuka |
| 2CKA001710A3903 | Cover plate TAE 1 gang black matt - 63x63 | 1766-885 | 1 | sztuka |
| 2CKA001753A0254 | Cover plate 1 ... 15 Min for Time switch, Toggle grey metallic - 63x63 | 1770-803-103 | 1 | sztuka |
| 2CKA001753A0255 | Cover plate with legend 1 ... 15 Min for Time switch, Toggle anthracite - 63x63 | 1770-81-103 | 1 | sztuka |
| 2CKA001753A0256 | Cover plate with legend 1 ... 15 Min for Time switch, Toggle white - 63x63 | 1770-82-103 | 1 | sztuka |
| 2CKA001753A0257 | Cover plate with legend 1 ... 15 Min for Time switch, Toggle aluminium - 63x63 | 1770-83-103 | 1 | sztuka |
| 2CKA001753A0259 | Cover plate with legend 1 ... 15 Min for Time switch, Toggle stainless steel - Pure Stainless Steel | 1770-866-103 | 1 | sztuka |
| 2CKA001753A0260 | Cover plate with legend 1 ... 15 Min for Time switch, Toggle studio white matt - 63x63 | 1770-884-103 | 1 | sztuka |
| 2CKA001753A0261 | Cover plate with legend 1 ... 15 Min for Time switch, Toggle black matt - 63x63 | 1770-885-103 | 1 | sztuka |
| 2CKA001753A0264 | Cover plate Time indication for Time switch, Turn button grey metallic - 63x63 | 1771-803-103 | 1 | sztuka |
| 2CKA001753A0265 | Cover plate with legend 10 ... 120 Min for Time switch, Toggle anthracite - 63x63 | 1771-81-103 | 1 | sztuka |
| 2CKA001753A0266 | Cover plate with legend 10 ... 120 Min for Time switch, Toggle white - 63x63 | 1771-82-103 | 1 | sztuka |
| 2CKA001753A0267 | Cover plate with legend 10 ... 120 Min for Time switch, Toggle aluminium - 63x63 | 1771-83-103 | 1 | sztuka |
| 2CKA001753A0302 | Cover plate with legend 10 ... 120 Min for Time switch, Toggle stainless steel - Pure Stainless Steel | 1771-866-103 | 1 | sztuka |
| 2CKA001753A0303 | Cover plate with legend 10 ... 120 Min for Time switch, Toggle studio white matt - 63x63 | 1771-884-103 | 1 | sztuka |
| 2CKA001753A0304 | Cover plate with legend 10 ... 120 Min for Time switch, Toggle black matt - 63x63 | 1771-885-103 | 1 | sztuka |
| 2CKA001751A2977 | Multimedia Devices anthracite | 1785 ENO-81 | 1 | sztuka |
| 2CKA001751A2978 | Multimedia Devices ivory white | 1785 ENO-82 | 1 | sztuka |
| 2CKA001751A2979 | Multimedia Devices aluminium silver | 1785 ENO-83 | 1 | sztuka |
| 2CKA001751A3101 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker ivory white - carat | 1785 JA/02-82 | 1 | sztuka |

| | | | | |
|-----------------|--|----------------|---|--------|
| 2CKA001751A3097 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker aluminium silver - 63x63 | 1785 JA/02-83 | 1 | sztuka |
| 2CKA001751A3103 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white matt - 63x63 | 1785 JA/02-884 | 1 | sztuka |
| 2CKA001751A3105 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker black matt - 63x63 | 1785 JA/02-885 | 1 | sztuka |
| 2CKA001751A3020 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker grey metallic - 63x63 | 1785 JA-803 | 1 | sztuka |
| 2CKA001751A2934 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker anthracite - 63x63 | 1785 JA-81 | 1 | sztuka |
| 2CKA001751A2748 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker ivory white - 63x63 | 1785 JA-82 | 1 | sztuka |
| 2CKA001751A2944 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker aluminium silver - 63x63 | 1785 JA-83 | 1 | sztuka |
| 2CKA001751A2964 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker stainless steel - Pure Stainless Steel | 1785 JA-866 | 1 | sztuka |
| 2CKA001751A3022 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white matt - 63x63 | 1785 JA-884 | 1 | sztuka |
| 2CKA001751A3036 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker black matt - 63x63 | 1785 JA-885 | 1 | sztuka |
| 2CKA001751A3126 | Mechanical Controls None for Switch/push button, Two-part rocker aluminium silver - 63x63 | 1785 K-83-500 | 1 | sztuka |
| 2CKA001751A3204 | Rocker with legend DND, MUR for Switch/push button, Single rocker grey metallic - 63x63 | 1785/11-803 | 1 | sztuka |
| 2CKA001751A3205 | Rocker with legend DND, MUR for Switch/push button, Two-part rocker anthracite - 63x63 | 1785/11-81 | 1 | sztuka |
| 2CKA001751A2991 | Rocker with legend DND, MUR for Switch/push button, Two-part rocker ivory white - 63x63 | 1785/11-82 | 1 | sztuka |
| 2CKA001751A2995 | Rocker with legend DND, MUR for Switch/push button, Two-part rocker aluminium silver - 63x63 | 1785/11-83 | 1 | sztuka |
| 2CKA001751A2996 | Rocker with legend DND, MUR for Switch/push button, Two-part rocker stainless steel - Pure Stainless Steel | 1785/11-866 | 1 | sztuka |
| 2CKA001751A3023 | Rocker with legend DND, MUR for Switch/push button, Two-part rocker studio white matt - 63x63 | 1785/11-884 | 1 | sztuka |
| 2CKA001751A3037 | Rocker with legend DND, MUR for Switch/push button, Two-part rocker black matt - 63x63 | 1785/11-885 | 1 | sztuka |
| 2CKA001751A3018 | Rocker for Switch/push button, Two-part rocker grey metallic - 63x63 | 1785-803 | 1 | sztuka |
| 2CKA001751A2930 | Rocker None for Switch/push button, Two-part rocker anthracite - 63x63 | 1785-81 | 1 | sztuka |
| 2CKA001751A2744 | Rocker for Switch/push button, Two-part rocker ivory white - 63x63 | 1785-82 | 1 | sztuka |
| 2CKA001751A2942 | Rocker None for Switch/push button, Two-part rocker aluminium silver - 63x63 | 1785-83 | 1 | sztuka |
| 2CKA001751A3092 | Mechanical Controls Without imprint for Switch/push button, Two-part rocker aluminium silver - 63x63 | 1785-83-500 | 1 | sztuka |
| 2CKA001751A3087 | Mechanical Controls Without imprint for Switch/push button, Two-part rocker stainless steel - Pure Stainless Steel | 1785-866-500 | 1 | sztuka |
| 2CKA001751A3024 | Rocker for Switch/push button, Two-part rocker studio white matt - 63x63 | 1785-884 | 1 | sztuka |
| 2CKA001751A3038 | Rocker None for Switch/push button, Two-part rocker black matt - 63x63 | 1785-885 | 1 | sztuka |
| 2CKA001751A2965 | Multimedia Devices anthracite | 1786 ENO-81 | 1 | sztuka |
| 2CKA001751A2966 | Multimedia Devices ivory white | 1786 ENO-82 | 1 | sztuka |
| 2CKA001751A2967 | Multimedia Devices aluminium silver | 1786 ENO-83 | 1 | sztuka |
| 2CKA001751A3100 | Rocker with legend Symbol "arrows" for Venetian blind, Single rocker ivory white - carat | 1786 JA/02-82 | 1 | sztuka |

| | | | | |
|-----------------|--|----------------|---|--------|
| 2CKA001751A3096 | Rocker with legend Symbol "arrows" for Switch/push button, aluminium silver - 63x63 | 1786 JA/02-83 | 1 | sztuka |
| 2CKA001751A3102 | Rocker with legend Symbol "arrows" for Venetian blind, Single rocker studio white matt - 63x63 | 1786 JA/02-884 | 1 | sztuka |
| 2CKA001751A3104 | Rocker with legend Symbol "arrows" black matt - 63x63 | 1786 JA/02-885 | 1 | sztuka |
| 2CKA001751A3207 | Rocker with legend DND for Switch/push button, Single rocker anthracite - 63x63 | 1786/11-81 | 1 | sztuka |
| 2CKA001751A2997 | Rocker with legend DND for Switch/push button, Single rocker ivory white - 63x63 | 1786/11-82 | 1 | sztuka |
| 2CKA001751A3001 | Rocker with legend DND for Switch/push button, Single rocker aluminium silver - 63x63 | 1786/11-83 | 1 | sztuka |
| 2CKA001751A3002 | Rocker with legend DND for Switch/push button, Single rocker stainless steel - Pure Stainless Steel | 1786/11-866 | 1 | sztuka |
| 2CKA001751A3026 | Rocker with legend DND for Switch/push button, Single rocker studio white matt - 63x63 | 1786/11-884 | 1 | sztuka |
| 2CKA001751A3040 | Rocker with legend DND for Switch/push button, Single rocker black matt - 63x63 | 1786/11-885 | 1 | sztuka |
| 2CKA001751A3145 | Rocker None for Switch/push button, Single rocker red - 63x63 | 1786-12-82 | 1 | sztuka |
| 2CKA001751A3093 | Mechanical Controls Without imprint for Switch/push button, Single rocker grey metallic - 63x63 | 1786-803-500 | 1 | sztuka |
| 2CKA001751A3079 | Mechanical Controls Without imprint for Switch/push button, Single rocker anthracite - 63x63 | 1786-81-500 | 1 | sztuka |
| 2CKA001751A3083 | Mechanical Controls Without imprint for Switch/push button, Single rocker ivory white - 63x63 | 1786-82-500 | 1 | sztuka |
| 2CKA001751A3075 | Mechanical Controls Without imprint for Switch/push button, Single rocker aluminium silver - 63x63 | 1786-83-500 | 1 | sztuka |
| 2CKA001751A3077 | Mechanical Controls Without imprint for Switch/push button, Single rocker stainless steel - Pure Stainless Steel | 1786-866-500 | 1 | sztuka |
| 2CKA001751A3089 | Mechanical Controls Without imprint for Switch/push button, Single rocker studio white matt - 63x63 | 1786-884-500 | 1 | sztuka |
| 2CKA001751A3094 | Mechanical Controls Without imprint for Switch/push button, Single rocker black matt - 63x63 | 1786-885-500 | 1 | sztuka |
| 2CKA001751A3017 | Rocker for Switch/push button, Single rocker grey metallic - 63x63 | 1788-803 | 1 | sztuka |
| 2CKA001751A2927 | Rocker None for Switch/push button, Single rocker anthracite - 63x63 | 1788-81 | 1 | sztuka |
| 2CKA001751A2742 | Rocker None for Switch/push button, Single rocker ivory white - 63x63 | 1788-82 | 1 | sztuka |
| 2CKA001751A2954 | Rocker with legend Characters 0 and 1 for Switch/push button, Single rocker aluminium silver - 63x63 | 1788-83 | 1 | sztuka |
| 2CKA001751A2961 | Rocker None for Switch/push button, Single rocker stainless steel - Pure Stainless Steel | 1788-866 | 1 | sztuka |
| 2CKA001751A3028 | Rocker None for Switch/push button, Single rocker studio white matt - 63x63 | 1788-884 | 1 | sztuka |
| 2CKA001751A3042 | Rocker None for Switch/push button, Single rocker black matt - 63x63 | 1788-885 | 1 | sztuka |
| 2CKA001751A3019 | Rocker with legend Heizung for Switch/push button, Single rocker grey metallic - 63x63 | 1789 H-803 | 1 | sztuka |
| 2CKA001751A2929 | Rocker with legend Heizung for Switch/push button, Single rocker anthracite - 63x63 | 1789 H-81 | 1 | sztuka |
| 2CKA001751A2743 | Rocker with legend Heizung for Switch/push button, Single rocker ivory white - 63x63 | 1789 H-82 | 1 | sztuka |

| | | | | |
|-----------------|--|-------------|---|--------|
| 2CKA001751A2955 | Rocker with legend Heizung for Switch/push button, Single rocker aluminium silver - 63x63 | 1789 H-83 | 1 | sztuka |
| 2CKA001751A2963 | Rocker with legend Heizung for Switch/push button, Single rocker stainless steel - Pure Stainless Steel | 1789 H-866 | 1 | sztuka |
| 2CKA001751A3029 | Rocker with legend Heizung for Switch/push button, Single rocker studio white matt - 63x63 | 1789 H-884 | 1 | sztuka |
| 2CKA001751A3043 | Rocker with legend Heizung for Switch/push button, Single rocker black matt - 63x63 | 1789 H-885 | 1 | sztuka |
| 2CKA001751A3015 | Rocker for Switch/push button, Single rocker grey metallic - 63x63 | 1789 KI-803 | 1 | sztuka |
| 2CKA001751A2932 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker anthracite - 63x63 | 1789 KI-81 | 1 | sztuka |
| 2CKA001751A2746 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker ivory white - 63x63 | 1789 KI-82 | 1 | sztuka |
| 2CKA001751A2952 | Rocker with legend Symbol "key/door" for Switch/push button, Single rocker aluminium silver - 63x63 | 1789 KI-83 | 1 | sztuka |
| 2CKA001751A2959 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel | 1789 KI-866 | 1 | sztuka |
| 2CKA001751A3030 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker studio white matt - 63x63 | 1789 KI-884 | 1 | sztuka |
| 2CKA001751A3044 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker black matt - 63x63 | 1789 KI-885 | 1 | sztuka |
| 2CKA001751A3014 | Rocker with legend Symbol "light" for Switch/push button, Single rocker grey metallic - 63x63 | 1789 LI-803 | 1 | sztuka |
| 2CKA001751A2931 | Rocker with legend Symbol "light" for Switch/push button, Single rocker anthracite - 63x63 | 1789 LI-81 | 1 | sztuka |
| 2CKA001751A2745 | Rocker with legend Symbol "light" for Switch/push button, Single rocker ivory white - 63x63 | 1789 LI-82 | 1 | sztuka |
| 2CKA001751A2951 | Rocker with legend Symbol "light" for Switch/push button, Single rocker aluminium silver - 63x63 | 1789 LI-83 | 1 | sztuka |
| 2CKA001751A2958 | Rocker with legend Symbol "light" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel | 1789 LI-866 | 1 | sztuka |
| 2CKA001751A3031 | Rocker with legend Symbol "light" for Switch/push button, Single rocker studio white matt - 63x63 | 1789 LI-884 | 1 | sztuka |
| 2CKA001751A3045 | Rocker with legend Symbol "light" for Switch/push button, Single rocker black matt - 63x63 | 1789 LI-885 | 1 | sztuka |
| 2CKA001751A3146 | Rocker for Switch/push button, Single rocker grey metallic - 63x63 | 1789 N-803 | 1 | sztuka |
| 2CKA001751A3147 | Rocker None for Switch/push button, Single rocker anthracite - 63x63 | 1789 N-81 | 1 | sztuka |
| 2CKA001751A3148 | Rocker None for Switch/push button, Single rocker ivory white - 63x63 | 1789 N-82 | 1 | sztuka |
| 2CKA001751A3149 | Rocker for Switch/push button, Single rocker aluminium silver - 63x63 | 1789 N-83 | 1 | sztuka |
| 2CKA001751A3152 | Rocker None for Switch/push button, Single rocker stainless steel - Pure Stainless Steel | 1789 N-866 | 1 | sztuka |
| 2CKA001751A3153 | Rocker None for Switch/push button, Single rocker studio white matt - 63x63 | 1789 N-884 | 1 | sztuka |
| 2CKA001751A3154 | Rocker None for Switch/push button, Single rocker black matt - 63x63 | 1789 N-885 | 1 | sztuka |
| 2CKA001751A3156 | Rocker for Switch/push button, Single rocker grey metallic - 63x63 | 1789 ST-803 | 1 | sztuka |
| 2CKA001751A3157 | Rocker with legend Symbol "plug" for Switch/push button, Single rocker anthracite - 63x63 | 1789 ST-81 | 1 | sztuka |
| 2CKA001751A3158 | Rocker with legend Symbol "plug" for Switch/push button, Single rocker ivory white - 63x63 | 1789 ST-82 | 1 | sztuka |
| 2CKA001751A3159 | Rocker with legend Symbol "plug" for Switch/push button, Single rocker aluminium silver - 63x63 | 1789 ST-83 | 1 | sztuka |

| | | | | |
|-----------------|---|-------------|---|--------|
| 2CKA001751A3162 | Rocker with legend Symbol "plug" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel | 1789 ST-866 | 1 | sztuka |
| 2CKA001751A3163 | Rocker with legend Symbol "plug" for Switch/push button, Single rocker studio white matt - 63x63 | 1789 ST-884 | 1 | sztuka |
| 2CKA001751A3164 | Rocker with legend Symbol "plug" for Switch/push button, Single rocker black matt - 63x63 | 1789 ST-885 | 1 | sztuka |
| 2CKA001751A3016 | Rocker with legend Symbol "key" for Switch/push button, Single rocker grey metallic - 63x63 | 1789 TR-803 | 1 | sztuka |
| 2CKA001751A2933 | Rocker with legend Symbol "key" for Switch/push button, Single rocker anthracite - 63x63 | 1789 TR-81 | 1 | sztuka |
| 2CKA001751A2747 | Rocker with legend Symbol "key" for Switch/push button, Single rocker ivory white - 63x63 | 1789 TR-82 | 1 | sztuka |
| 2CKA001751A2953 | Rocker with legend Symbol "key" for Switch/push button, Single rocker aluminium silver - 63x63 | 1789 TR-83 | 1 | sztuka |
| 2CKA001751A2960 | Rocker with legend Symbol "key" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel | 1789 TR-866 | 1 | sztuka |
| 2CKA001751A3032 | Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white matt - 63x63 | 1789 TR-884 | 1 | sztuka |
| 2CKA001751A3046 | Rocker with legend Symbol "key" for Switch/push button, Single rocker black matt - 63x63 | 1789 TR-885 | 1 | sztuka |
| 2CKA001751A3013 | Rocker for Switch/push button, Single rocker grey metallic - 63x63 | 1789-803 | 1 | sztuka |
| 2CKA001751A2928 | Rocker for Switch/push button, Single rocker anthracite - 63x63 | 1789-81 | 1 | sztuka |
| 2CKA001751A2813 | Rocker for Switch/push button, Single rocker ivory white - 63x63 | 1789-82 | 1 | sztuka |
| 2CKA001751A2945 | Rocker None for Switch/push button, Single rocker aluminium silver - 63x63 | 1789-83 | 1 | sztuka |
| 2CKA001751A2957 | Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel | 1789-866 | 1 | sztuka |
| 2CKA001751A3033 | Rocker for Switch/push button, Single rocker studio white matt - 63x63 | 1789-884 | 1 | sztuka |
| 2CKA001751A3047 | Rocker for Switch/push button, Single rocker black matt - 63x63 | 1789-885 | 1 | sztuka |
| 2CKA001710A4124 | Cover plate with legend Card, Symbol "arrows" for Switch/push button, Hotel card grey metallic - 63x63 | 1792-803 | 1 | sztuka |
| 2CKA001710A3639 | Cover plate with legend Card, Symbol "arrows" Hotel card anthracite - 63x63 | 1792-81 | 1 | sztuka |
| 2CKA001710A3640 | Cover plate with legend Card, Symbol "arrows" Hotel card ivory white - 63x63 | 1792-82 | 1 | sztuka |
| 2CKA001710A3670 | Cover plate with legend Card, Symbol "arrows" Hotel card aluminium silver - 63x63 | 1792-83 | 1 | sztuka |
| 2CKA001710A3757 | Cover plate with legend Card, Symbol "arrows" Hotel card stainless steel - Pure Stainless Steel | 1792-866 | 1 | sztuka |
| 2CKA001710A3928 | Cover plate with legend Card, Symbol "arrows" Hotel card studio white matt - 63x63 | 1792-884 | 1 | sztuka |
| 2CKA001710A3905 | Cover plate with legend Card, Symbol "arrows" Hotel card black matt - 63x63 | 1792-885 | 1 | sztuka |
| 2CKA001710A3849 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button grey metallic - 63x63 | 1794 TA-803 | 1 | sztuka |
| 2CKA001710A3695 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - 63x63 | 1794 TA-81 | 1 | sztuka |
| 2CKA001710A3696 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button ivory white - 63x63 | 1794 TA-82 | 1 | sztuka |
| 2CKA001710A3697 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium silver - 63x63 | 1794 TA-83 | 1 | sztuka |
| 2CKA001710A3761 | Cover plate with legend Symbol "1" for Thermostat Turn button stainless steel - Pure Stainless Steel | 1794 TA-866 | 1 | sztuka |

| | | | | |
|-----------------|---|---------------|---|--------|
| 2CKA001710A3883 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white matt - 63x63 | 1794 TA-884 | 1 | sztuka |
| 2CKA001710A3906 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button black matt - 63x63 | 1794 TA-885 | 1 | sztuka |
| 2CKA001710A3847 | Cover plate with legend Symbol "1" for Thermostat Turn button grey metallic - 63x63 | 1794-803 | 1 | sztuka |
| 2CKA001710A3629 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - 63x63 | 1794-81 | 1 | sztuka |
| 2CKA001710A3668 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium silver - 63x63 | 1794-83 | 1 | sztuka |
| 2CKA001710A3884 | Cover plate Various symbols for Thermostat Turn button studio white matt - 63x63 | 1794-884 | 1 | sztuka |
| 2CKA001710A3907 | Cover plate Various symbols for Thermostat Turn button black matt - 63x63 | 1794-885 | 1 | sztuka |
| 2CKA001710A4012 | Cover plate with legend Symbol "1" for Thermostat Turn button grey metallic - 63x63 | 1795 HK-803 | 1 | sztuka |
| 2CKA001710A4015 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button ivory white - 63x63 | 1795 HK-82 | 1 | sztuka |
| 2CKA001710A4018 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button stainless steel - Pure Stainless Steel | 1795 HK-866 | 1 | sztuka |
| 2CKA001710A4044 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch grey metallic - 63x63 | 1795 HKEA-803 | 1 | sztuka |
| 2CKA001710A4045 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch anthracite - 63x63 | 1795 HKEA-81 | 1 | sztuka |
| 2CKA001710A4047 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch ivory white - 63x63 | 1795 HKEA-82 | 1 | sztuka |
| 2CKA001710A4048 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch aluminium silver - 63x63 | 1795 HKEA-83 | 1 | sztuka |
| 2CKA001710A4050 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel | 1795 HKEA-866 | 1 | sztuka |
| 2CKA001710A4051 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white matt - 63x63 | 1795 HKEA-884 | 1 | sztuka |
| 2CKA001710A4052 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch black matt - 63x63 | 1795 HKEA-885 | 1 | sztuka |
| 2CKA001710A3850 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch grey metallic - 63x63 | 1795 TA-803 | 1 | sztuka |
| 2CKA001710A3722 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch anthracite - 63x63 | 1795 TA-81 | 1 | sztuka |
| 2CKA001710A3723 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch ivory white - 63x63 | 1795 TA-82 | 1 | sztuka |
| 2CKA001710A3724 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch aluminium silver - 63x63 | 1795 TA-83 | 1 | sztuka |
| 2CKA001710A3762 | Cover plate with legend Symbol "1" for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel | 1795 TA-866 | 1 | sztuka |
| 2CKA001710A3885 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white matt - 63x63 | 1795 TA-884 | 1 | sztuka |
| 2CKA001710A3908 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch black matt - 63x63 | 1795 TA-885 | 1 | sztuka |

| | | | | |
|-----------------|---|-------------|---|--------|
| 2CKA001710A3848 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch grey metallic - 63x63 | 1795-803 | 1 | sztuka |
| 2CKA001710A3630 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch anthracite - 63x63 | 1795-81 | 1 | sztuka |
| 2CKA001710A3568 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch ivory white - 63x63 | 1795-82 | 1 | sztuka |
| 2CKA001710A3669 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch aluminium silver - 63x63 | 1795-83 | 1 | sztuka |
| 2CKA001710A3756 | Cover plate with legend Symbol "1" for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel | 1795-866 | 1 | sztuka |
| 2CKA001710A3886 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white matt - 63x63 | 1795-884 | 1 | sztuka |
| 2CKA001710A3909 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch black matt - 63x63 | 1795-885 | 1 | sztuka |
| 2CKA001753A0307 | Cover plate Pull cord grey metallic - 63x63 | 1796-803 | 1 | sztuka |
| 2CKA001753A0309 | Cover plate for Pull-cord switch, Pull cord ivory white - 63x63 | 1796-82 | 1 | sztuka |
| 2CKA001753A0310 | Cover plate for Pull-cord switch, Pull cord aluminium silver - 63x63 | 1796-83 | 1 | sztuka |
| 2CKA001753A0312 | Cover plate for Pull-cord switch, Pull cord stainless steel - Pure Stainless Steel | 1796-866 | 1 | sztuka |
| 2CKA001753A0313 | Cover plate for Pull-cord switch, Pull cord studio white matt - 63x63 | 1796-884 | 1 | sztuka |
| 2CKA001753A0314 | Cover plate with legend Symbol "bell" for Switch/push button, Pull cord black matt - 63x63 | 1796-885 | 1 | sztuka |
| 2CKA001710A3856 | Cover plate with labelling field Modular Jack 2 gang grey metallic - 63x63 | 1800-803 | 1 | sztuka |
| 2CKA001710A3627 | Cover plate with labelling field Modular Jack 2 gang anthracite - 63x63 | 1800-81 | 1 | sztuka |
| 2CKA001710A3158 | Cover plate with labelling field Modular Jack 2 gang ivory white - 63x63 | 1800-82 | 1 | sztuka |
| 2CKA001710A3676 | Cover plate with labelling field Modular Jack 2 gang aluminium silver - 63x63 | 1800-83 | 1 | sztuka |
| 2CKA001710A3767 | Cover plate with labelling field Modular Jack 2 gang stainless steel - Pure Stainless Steel | 1800-866 | 1 | sztuka |
| 2CKA001710A3887 | Cover plate with labelling field Modular Jack 2 gang studio white matt - 63x63 | 1800-884 | 1 | sztuka |
| 2CKA001710A3910 | Cover plate with labelling field Modular Jack 2 gang black matt - 63x63 | 1800-885 | 1 | sztuka |
| 2CKA001710A3853 | Cover plate with labelling field UAE/IAE (ISDN) 2 gang grey metallic - 63x63 | 1803-02-803 | 1 | sztuka |
| 2CKA001710A3615 | Cover plate with labelling field UAE/IAE (ISDN) 2 gang anthracite - 63x63 | 1803-02-81 | 1 | sztuka |
| 2CKA001710A3146 | Cover plate with labelling field UAE/IAE (ISDN) 2 gang ivory white - 63x63 | 1803-02-82 | 1 | sztuka |
| 2CKA001710A3610 | Cover plate with labelling field UAE/IAE (ISDN) 2 gang aluminium silver - 63x63 | 1803-02-83 | 1 | sztuka |
| 2CKA001710A3764 | Cover plate with labelling field UAE/IAE (ISDN) 2 gang stainless steel - Pure Stainless Steel | 1803-02-866 | 1 | sztuka |
| 2CKA001710A3888 | Cover plate with labelling field UAE/IAE (ISDN) 2 gang studio white matt - 63x63 | 1803-02-884 | 1 | sztuka |
| 2CKA001710A3911 | Cover plate with labelling field UAE/IAE (ISDN) 2 gang black matt - 63x63 | 1803-02-885 | 1 | sztuka |
| 2CKA001710A3852 | Cover plate with labelling field UAE/IAE (ISDN) 1 gang grey metallic - 63x63 | 1803-803 | 1 | sztuka |

| | | | | |
|-----------------|--|-------------------|---|--------|
| 2CKA001710A3616 | Cover plate with labelling field UAE/IAE (ISDN) 1 gang anthracite - 63x63 | 1803-81 | 1 | sztuka |
| 2CKA001710A3147 | Cover plate with labelling field UAE/IAE (ISDN) 1 gang ivory white - 63x63 | 1803-82 | 1 | sztuka |
| 2CKA001710A3674 | Cover plate with labelling field UAE/IAE (ISDN) 1 gang aluminium silver - 63x63 | 1803-83 | 1 | sztuka |
| 2CKA001710A3763 | Cover plate with labelling field UAE/IAE (ISDN) 1 gang stainless steel - Pure Stainless Steel | 1803-866 | 1 | sztuka |
| 2CKA001710A3889 | Cover plate with labelling field UAE/IAE (ISDN) 1 gang studio white matt - 63x63 | 1803-884 | 1 | sztuka |
| 2CKA001710A3912 | Cover plate with labelling field UAE/IAE (ISDN) 1 gang black matt - 63x63 | 1803-885 | 1 | sztuka |
| 2CKA002013A5404 | Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter anthracite - 63x63 | 20 EUAB-81 | 1 | sztuka |
| 2CKA002013A5405 | Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter ivory white - 63x63 | 20 EUAB-82 | 1 | sztuka |
| 2CKA002013A5406 | Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter aluminium silver - 63x63 | 20 EUAB-83 | 1 | sztuka |
| 2CKA002013A5408 | Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter stainless steel - Pure Stainless Steel | 20 EUAB-866 | 1 | sztuka |
| 2CKA002013A5409 | Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter studio white matt - 63x63 | 20 EUAB-884 | 1 | sztuka |
| 2CKA002013A5410 | Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter black matt - 63x63 | 20 EUAB-885 | 1 | sztuka |
| 2CKA002011A6260 | SCHUKO® Socket insert with legend SV green - 63x63 | 20 EUC-13-82-101 | 1 | sztuka |
| 2CKA002011A3723 | SCHUKO® Socket insert with legend ZSV orange - 63x63 | 20 EUC-14-82 | 1 | sztuka |
| 2CKA002011A6216 | Socket Outlets Without imprint grey metallic - 63x63 | 20 EUC-803-500 | 1 | sztuka |
| 2CKA002011A6215 | Socket Outlets Without imprint anthracite - 63x63 | 20 EUC-81-500 | 1 | sztuka |
| 2CKA002011A6214 | Socket Outlets Without imprint ivory white - 63x63 | 20 EUC-82-500 | 1 | sztuka |
| 2CKA002011A6213 | Socket Outlets Without imprint aluminium silver - 63x63 | 20 EUC-83-500 | 1 | sztuka |
| 2CKA002011A6212 | Socket Outlets Without imprint stainless steel - Pure Stainless Steel | 20 EUC-866-500 | 1 | sztuka |
| 2CKA002011A6208 | Socket Outlets Without imprint studio white matt - 63x63 | 20 EUC-884-500 | 1 | sztuka |
| 2CKA002011A6211 | Socket Outlets Without imprint black matt - 63x63 | 20 EUC-885-500 | 1 | sztuka |
| 2CKA002013A5472 | SCHUKO® Socket insert with legend SV Safety Shutter green - 63x63 | 20 EUCB-13-82-102 | 1 | sztuka |
| 2CKA002013A5413 | SCHUKO® Socket insert with legend ZSV Safety Shutter orange - 63x63 | 20 EUCB-14-82-10 | 1 | sztuka |
| 2CKA002013A5414 | Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter grey metallic - 63x63 | 20 EUCBDR-803 | 1 | sztuka |
| 2CKA002013A5415 | Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter anthracite - 63x63 | 20 EUCBDR-81 | 1 | sztuka |
| 2CKA002013A5416 | Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter ivory white - 63x63 | 20 EUCBDR-82 | 1 | sztuka |
| 2CKA002013A5417 | Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter aluminium silver - 63x63 | 20 EUCBDR-83 | 1 | sztuka |

| | | | | |
|-----------------|---|-----------------------|---|--------|
| 2CKA002013A5419 | Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter stainless steel - Pure Stainless Steel | 20 EUCBDR-866 | 1 | sztuka |
| 2CKA002013A5420 | Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter studio white matt - 63x63 | 20 EUCBDR-884 | 1 | sztuka |
| 2CKA002013A5421 | Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter black matt - 63x63 | 20 EUCBDR-885 | 1 | sztuka |
| 2CKA002013A5456 | SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green grey metallic - 63x63 | 20 EUCBL-803 | 1 | sztuka |
| 2CKA002013A5457 | SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green anthracite - 63x63 | 20 EUCBL-81 | 1 | sztuka |
| 2CKA002013A5284 | SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green ivory white - 63x63 | 20 EUCBL-82 | 1 | sztuka |
| 2CKA002013A5285 | SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green aluminium silver - 63x63 | 20 EUCBL-83 | 1 | sztuka |
| 2CKA002013A5289 | SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green stainless steel - Pure Stainless Steel | 20 EUCBL-866 | 1 | sztuka |
| 2CKA002013A5336 | SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green studio white matt - 63x63 | 20 EUCBL-884 | 1 | sztuka |
| 2CKA002013A5330 | SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green black matt - 63x63 | 20 EUCBL-885 | 1 | sztuka |
| 2CKA002013A5458 | Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White grey metallic - 63x63 | 20 EUCBLI-803 | 1 | sztuka |
| 2CKA002013A5459 | Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White anthracite - 63x63 | 20 EUCBLI-81 | 1 | sztuka |
| 2CKA002013A5292 | Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White ivory white - 63x63 | 20 EUCBLI-82 | 1 | sztuka |
| 2CKA002013A5293 | Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White aluminium silver - 63x63 | 20 EUCBLI-83 | 1 | sztuka |
| 2CKA002013A5460 | Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White stainless steel - Pure Stainless Steel | 20 EUCBLI-866 | 1 | sztuka |
| 2CKA002013A5326 | Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White studio white matt - 63x63 | 20 EUCBLI-884 | 1 | sztuka |
| 2CKA002013A5331 | Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White black matt - 63x63 | 20 EUCBLI-885 | 1 | sztuka |
| 2CKA002013A5463 | SCHUKO® socket insert Safety Shutter red - 63x63 | 20 EUCKS/DV-12-82-101 | 1 | sztuka |
| 2CKA002013A5462 | SCHUKO® Socket insert with legend EDV Safety Shutter grey metallic - 63x63 | 20 EUCKS/DV-803 | 1 | sztuka |
| 2CKA002013A5266 | SCHUKO® Socket insert with legend EDV Safety Shutter anthracite - 63x63 | 20 EUCKS/DV-81 | 1 | sztuka |
| 2CKA002013A5267 | SCHUKO® Socket insert with legend EDV Safety Shutter ivory white - 63x63 | 20 EUCKS/DV-82 | 1 | sztuka |
| 2CKA002013A5273 | SCHUKO® Socket insert with legend EDV Safety Shutter aluminium silver - 63x63 | 20 EUCKS/DV-83 | 1 | sztuka |

| | | | | |
|-----------------|---|--------------|---|--------|
| 2CKA002013A5277 | SCHUKO® Socket insert with legend EDV Safety 20 EUCKS/DV- Shutter stainless steel - Pure Stainless Steel | 866 | 1 | sztuka |
| 2CKA002013A5327 | SCHUKO® Socket insert with legend EDV Safety 20 EUCKS/DV- Shutter studio white matt - 63x63 | 884 | 1 | sztuka |
| 2CKA002013A5332 | SCHUKO® Socket insert with legend EDV Safety 20 EUCKS/DV- Shutter black matt - 63x63 | 885 | 1 | sztuka |
| 2CKA002013A5464 | SCHUKO® socket insert Without imprint Safety 20 EUCKS-12- Shutter red - 63x63 | 82-101 | 1 | sztuka |
| 2CKA002013A5470 | SCHUKO® socket insert Without imprint Safety 20 EUCKS-13- Shutter green - 63x63 | 82-101 | 1 | sztuka |
| 2CKA002013A5324 | SCHUKO® socket insert Without imprint Safety 20 EUCKS-14- Shutter orange - 63x63 | 82 | 1 | sztuka |
| 2CKA002013A5297 | SCHUKO® socket insert Without imprint Safety 20 EUCKS-803 Shutter grey metallic - 63x63 | | 1 | sztuka |
| 2CKA002013A5265 | SCHUKO® socket insert Without imprint Safety 20 EUCKS-81 Shutter anthracite - 63x63 | | 1 | sztuka |
| 2CKA002013A5376 | Socket Outlets Without imprint Safety Shutter 20 EUCKS-82- ivory white - 63x63 | 500 | 1 | sztuka |
| 2CKA002013A5375 | Socket Outlets Without imprint Safety Shutter 20 EUCKS-83- aluminium silver - 63x63 | 500 | 1 | sztuka |
| 2CKA002013A5374 | Socket Outlets Without imprint Safety Shutter 20 EUCKS-866 stainless steel - Pure Stainless Steel | -500 | 1 | sztuka |
| 2CKA002013A5373 | Socket insert Without imprint Safety Shutter 20 EUCKS-884 Protective contact (SCHUKO) studio white matt - 63x63 | -500 | 1 | sztuka |
| 2CKA002013A5333 | SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) black matt - 63x63 | 20 EUCKS-885 | 1 | sztuka |
| 2CKA002013A5423 | SCHUKO® Socket insert with labelling field 20 EUCNB-12- Without imprint Safety Shutter red - 63x63 | 82 | 1 | sztuka |
| 2CKA002013A5424 | SCHUKO® Socket insert with labelling field 20 EUCNB-13- Without imprint Safety Shutter green - 63x63 | 82 | 1 | sztuka |
| 2CKA002013A5425 | SCHUKO® Socket insert with labelling field 20 EUCNB-14- Without imprint Safety Shutter orange - 63x63 | 82 | 1 | sztuka |
| 2CKA002013A5426 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter grey metallic - 63x63 | 20 EUCNB-803 | 1 | sztuka |
| 2CKA002013A5427 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter anthracite - 63x63 | 20 EUCNB-81 | 1 | sztuka |
| 2CKA002013A5428 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter ivory white - 63x63 | 20 EUCNB-82 | 1 | sztuka |
| 2CKA002013A5429 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter aluminium silver - 63x63 | 20 EUCNB-83 | 1 | sztuka |
| 2CKA002013A5432 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter stainless steel - Pure Stainless Steel | 20 EUCNB-866 | 1 | sztuka |
| 2CKA002013A5433 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter studio white matt - 63x63 | 20 EUCNB-884 | 1 | sztuka |
| 2CKA002013A5434 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter black matt - 63x63 | 20 EUCNB-885 | 1 | sztuka |
| 2CKA002013A5436 | SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) grey metallic - 63x63 | 20 EUCRB-803 | 1 | sztuka |
| 2CKA002013A5437 | SCHUKO® socket insert Without imprint Safety Shutter anthracite - 63x63 | 20 EUCRB-81 | 1 | sztuka |
| 2CKA002013A5438 | SCHUKO® socket insert Without imprint Safety Shutter ivory white - 63x63 | 20 EUCRB-82 | 1 | sztuka |
| 2CKA002013A5439 | SCHUKO® socket insert Without imprint Safety Shutter aluminium silver - 63x63 | 20 EUCRB-83 | 1 | sztuka |
| 2CKA002013A5442 | SCHUKO® socket insert Without imprint Safety Shutter stainless steel - Pure Stainless Steel | 20 EUCRB-866 | 1 | sztuka |

| | | | | |
|-----------------|---|----------------|---|--------|
| 2CKA002013A5443 | SCHUKO® socket insert Without imprint Safety Shutter studio white matt - 63x63 | 20 EUCRB-884 | 1 | sztuka |
| 2CKA002013A5444 | SCHUKO® socket insert Without imprint Safety Shutter black matt - 63x63 | 20 EUCRB-885 | 1 | sztuka |
| 2CKA002018A1493 | SCHUKO® socket insert Without imprint with Hinged Lid grey metallic - 63x63 | 20 EUK-803 | 1 | sztuka |
| 2CKA002018A1486 | SCHUKO® socket insert Without imprint with Hinged Lid anthracite - 63x63 | 20 EUK-81 | 1 | sztuka |
| 2CKA002018A1465 | SCHUKO® socket insert Without imprint with Hinged Lid ivory white - 63x63 | 20 EUK-82 | 1 | sztuka |
| 2CKA002018A1487 | SCHUKO® socket insert Without imprint with Hinged Lid aluminium silver - 63x63 | 20 EUK-83 | 1 | sztuka |
| 2CKA002018A1490 | SCHUKO® socket insert Without imprint with Hinged Lid stainless steel - Pure Stainless Steel | 20 EUK-866 | 1 | sztuka |
| 2CKA002018A1494 | SCHUKO® socket insert Without imprint with Hinged Lid studio white matt - 63x63 | 20 EUK-884 | 1 | sztuka |
| 2CKA002018A1495 | SCHUKO® socket insert Without imprint with Hinged Lid black matt - 63x63 | 20 EUK-885 | 1 | sztuka |
| 2CKA002018A1516 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid grey metallic - 63x63 | 20 EUKB-803 | 1 | sztuka |
| 2CKA002018A1517 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid anthracite - 63x63 | 20 EUKB-81 | 1 | sztuka |
| 2CKA002018A1518 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid ivory white - 63x63 | 20 EUKB-82 | 1 | sztuka |
| 2CKA002018A1519 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid aluminium silver - 63x63 | 20 EUKB-83 | 1 | sztuka |
| 2CKA002018A1521 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid stainless steel - Pure Stainless Steel | 20 EUKB-866 | 1 | sztuka |
| 2CKA002018A1522 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid studio white matt - 63x63 | 20 EUKB-884 | 1 | sztuka |
| 2CKA002018A1523 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid black matt - 63x63 | 20 EUKB-885 | 1 | sztuka |
| 2CKA002018A1525 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid grey metallic - 63x63 | 20 EUKBR-803 | 1 | sztuka |
| 2CKA002018A1526 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid anthracite - 63x63 | 20 EUKBR-81 | 1 | sztuka |
| 2CKA002018A1527 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid ivory white - 63x63 | 20 EUKBR-82 | 1 | sztuka |
| 2CKA002018A1528 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid aluminium silver - 63x63 | 20 EUKBR-83 | 1 | sztuka |
| 2CKA002018A1530 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid studio white matt - 63x63 | 20 EUKBR-884 | 1 | sztuka |
| 2CKA002018A1531 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid black matt - 63x63 | 20 EUKBR-885 | 1 | sztuka |
| 2CKA002018A1533 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid red - 63x63 | 20 EUKNB-12-82 | 1 | sztuka |
| 2CKA002018A1534 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid green - 63x63 | 20 EUKNB-13-82 | 1 | sztuka |
| 2CKA002018A1535 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid orange - 63x63 | 20 EUKNB-14-82 | 1 | sztuka |
| 2CKA002018A1536 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid grey metallic - 63x63 | 20 EUKNB-803 | 1 | sztuka |
| 2CKA002018A1537 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid anthracite - 63x63 | 20 EUKNB-81 | 1 | sztuka |
| 2CKA002018A1538 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid ivory white - 63x63 | 20 EUKNB-82 | 1 | sztuka |

| | | | | |
|-----------------|--|------------------------|---|--------|
| 2CKA002018A1539 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid aluminium silver - 63x63 | 20 EUKNB-83 | 1 | sztuka |
| 2CKA002018A1541 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid studio white matt - 63x63 | 20 EUKNB-884 | 1 | sztuka |
| 2CKA002018A1542 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid black matt - 63x63 | 20 EUKNB-885 | 1 | sztuka |
| 2CKA002018A1544 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid red - 63x63 | 20 EUKNBL-12 -82 | 1 | sztuka |
| 2CKA002018A1545 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid green - 63x63 | 20 EUKNBL-13 -82 | 1 | sztuka |
| 2CKA002018A1546 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid orange - 63x63 | 20 EUKNBL-14 -82 | 1 | sztuka |
| 2CKA002018A1547 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid grey metallic - 63x63 | 20 EUKNBL- 803 | 1 | sztuka |
| 2CKA002018A1548 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid anthracite - 63x63 | 20 EUKNBL-81 | 1 | sztuka |
| 2CKA002018A1552 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid studio white matt - 63x63 | 20 EUKNBL- 884 | 1 | sztuka |
| 2CKA002018A1553 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid black matt - 63x63 | 20 EUKNBL- 885 | 1 | sztuka |
| 2CKA002018A1557 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking anthracite - 63x63 | 20 EUKNBSL- 81 | 1 | sztuka |
| 2CKA002018A1558 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking anthracite - 63x63 | 20 EUKNBSL- 81-101 | 1 | sztuka |
| 2CKA002018A1559 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking ivory white - 63x63 | 20 EUKNBSL- 82 | 1 | sztuka |
| 2CKA002018A1560 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking ivory white - 63x63 | 20 EUKNBSL- 82-101 | 1 | sztuka |
| 2CKA002018A1561 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking aluminium silver - 63x63 | 20 EUKNBSL- 83 | 1 | sztuka |
| 2CKA002018A1562 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking aluminium silver - 63x63 | 20 EUKNBSL- 83-101 | 1 | sztuka |
| 2CKA002018A1565 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking studio white matt - 63x63 | 20 EUKNBSL- 884 | 1 | sztuka |
| 2CKA002018A1566 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking studio white matt - 63x63 | 20 EUKNBSL- 884-101 | 1 | sztuka |
| 2CKA002018A1567 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking black matt - 63x63 | 20 EUKNBSL- 885 | 1 | sztuka |

| | | | | |
|-----------------|---|------------------------|---|--------|
| 2CKA002018A1568 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking black matt - 63x63 | 20 EUKNBSL- 885-101 | 1 | sztuka |
| 2CKA002011A3876 | SCHUKO® Socket insert with labelling field Without imprint grey metallic - 63x63 | 20 EUN-803 | 1 | sztuka |
| 2CKA002011A3802 | SCHUKO® Socket insert with labelling field Without imprint anthracite - 63x63 | 20 EUN-81 | 1 | sztuka |
| 2CKA002011A3726 | SCHUKO® Socket insert with labelling field Without imprint ivory white - 63x63 | 20 EUN-82 | 1 | sztuka |
| 2CKA002011A3810 | SCHUKO® Socket insert with labelling field Without imprint aluminium silver - 63x63 | 20 EUN-83 | 1 | sztuka |
| 2CKA002011A3851 | SCHUKO® Socket insert with labelling field Without imprint stainless steel - Pure Stainless Steel | 20 EUN-866 | 1 | sztuka |
| 2CKA002011A3881 | SCHUKO® Socket insert with labelling field Without imprint studio white matt - 63x63 | 20 EUN-884 | 1 | sztuka |
| 2CKA002011A3884 | SCHUKO® Socket insert with labelling field Without imprint black matt - 63x63 | 20 EUN-885 | 1 | sztuka |
| 2CKA002495A0084 | Equipotential socket insert Socket outlet 2- position anthracite - 63x63 | 2095 UC-81 | 1 | sztuka |
| 2CKA002495A0085 | Equipotential socket insert Socket outlet 2- position ivory white - 63x63 | 2095 UC-82 | 1 | sztuka |
| 2CKA002495A0089 | Equipotential socket insert Socket outlet 2- position aluminium silver - 63x63 | 2095 UC-83 | 1 | sztuka |
| 2CKA002495A0090 | Equipotential socket insert Socket outlet 2- position stainless steel - Pure Stainless Steel | 2095 UC-866 | 1 | sztuka |
| 2CKA002495A0091 | Equipotential socket insert Socket outlet 2- position studio white matt - 63x63 | 2095 UC-884 | 1 | sztuka |
| 2CKA002495A0092 | Equipotential socket insert Socket outlet 2- position black matt - 63x63 | 2095 UC-885 | 1 | sztuka |
| 2CKA002190A0213 | Socket Outlets Without imprint British Standard ivory - carat | 2190 EUC-82 | 1 | sztuka |
| 2CKA002013A5475 | SCHUKO® socket insert Without imprint Safety Shutter ivory white - 63x63 | 23 EUCB-82 | 1 | sztuka |
| 2CKA002013A5449 | SCHUKO® socket insert Without imprint Safety Shutter ivory white - 63x63 | 2300 EUCB-82 | 1 | sztuka |
| 2CKA002113A0510 | Socket Outlets Without imprint Safety Shutter ivory white - 63x63 | 2300 UCRKS- 82-503 | 1 | sztuka |
| 2CKA002011A3831 | Busch-Protector® SCHUKO® socket insert Without imprint ivory white - 63x63 | 2310 EUGL/VA -82-11 | 1 | sztuka |
| 2CKA002099A0197 | 2397 UCKS-82-505 Center PI, SF for 2300 | 2397 UCKS-82 -505 | 1 | sztuka |
| 2CKA002013A5359 | 2398 CKS-82 Cover plate shuttered | 2398 CKS-82 | 1 | sztuka |
| 2CKA002099A0211 | Socket Outlets Without imprint Safety Shutter ivory white - 63x63 | 2399 UCKS-82 | 1 | sztuka |
| 2CKA002099A0191 | Socket Outlets Without imprint Safety Shutter ivory white - 63x63 | 2399 UCKS-82 -505 | 1 | sztuka |
| 2CKA001719A0218 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring ivory white - 63x63 | 2518-WD-82 | 1 | sztuka |
| 2CKA001751A3177 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker ivory white - 63x63 | 2520 KI-82 | 1 | sztuka |
| 2CKA001751A3187 | Rocker with legend Symbol "light" for Switch/push button, Single rocker ivory white - 63x63 | 2520 LI-82 | 1 | sztuka |
| 2CKA001724A4255 | Cover plate Bore hole 1 gang ivory white - 63x63 | 2533-82 | 1 | sztuka |
| 2CKA001710A3645 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button ivory white - 63x63 | 2542 DR/01-82 | 1 | sztuka |
| 2CKA001710A3650 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button ivory white - 63x63 | 2542 DR/02-82 | 1 | sztuka |
| 2CKA001724A4400 | Cover plate XLR 1 gang ivory white - 63x63 | 2553-82 | 1 | sztuka |

| | | | | |
|-----------------|--|-----------------|---|--------|
| 2CKA001753A0392 | Cover plate Modular Jack ivory white - 63x63 | 2561-02-82 | 1 | sztuka |
| 2CKA001753A0401 | Cover plate Modular Jack 1 gang ivory white - 63x63 | 2561-82 | 1 | sztuka |
| 2CKA003116A0661 | FI-Schukomat SCHUKO® socket insert Without imprint Safety Shutter ivory white - 63x63 | 3120 EUCB-82 | 1 | sztuka |
| 2CKA003117A0005 | Buschmat RCD - Insert RCD 30 mA ivory white - 63x63 | 3151 UC-82 | 1 | sztuka |
| 2CKA006115A0484 | 6108/61-82-500 Coverplate f. CE | 6108/61-82-500 | 1 | sztuka |
| 2CKA006155A0061 | 6109/03-82-500 Coverplate f. RTC | 6109/03-82-500 | 1 | sztuka |
| 2CKA006132A0377 | Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° ivory white | 6122/10-82-500 | 1 | sztuka |
| 2CKA006115A0206 | 6125/01-82-500 Control element 1g w. BAU | 6125/01-82-500 | 1 | sztuka |
| 2CKA006115A0217 | 6125/02-82-500 Control element 1/2gang | 6125/02-82-500 | 1 | sztuka |
| 2CKA006116A0196 | 6126/01-82-500 Control element 2g w. BAU | 6126/01-82-500 | 1 | sztuka |
| 2CKA006116A0207 | 6126/02-82-500 Control element 2/4gang | 6126/02-82-500 | 1 | sztuka |
| 2CKA006117A0222 | 6127/01-82-500 Control element 4g w. BAU | 6127/01-82-500 | 1 | sztuka |
| 2CKA006117A0233 | 6127/02-82-500 Control element 4/8gang | 6127/02-82-500 | 1 | sztuka |
| 2CKA006134A0332 | 6128/28-82-500 RTC Control element 2/4g | 6128/28-82-500 | 1 | sztuka |
| 2CKA006135A0157 | 6129/01-82-500 Control element 3/6g w. IR | 6129/01-82-500 | 1 | sztuka |
| 2CKA006430A0327 | Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind One-part rocker ivory white - 63x63 | 6430-82-102 | 1 | sztuka |
| 2CKA006430A0304 | Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate ivory white - 63x63 | 6435-82 | 1 | sztuka |
| 2CKA006470A0003 | Cover plate None for Proximity switch One-part button ivory white - 63x63 | 6476-82 | 1 | sztuka |
| 2CKA006400A0057 | Cover plate PowerDock 1 gang white - 63x63 | 6477-82 | 1 | sztuka |
| 2CKA006599A2951 | Cover plate None for Dimmer Turn button with Neon lamp ivory white - 63x63 | 6540-82-102 | 1 | sztuka |
| 2CKA006599A2832 | Cover plate None for Cooling Central cover plate ivory white - 63x63 | 6541-82 | 1 | sztuka |
| 2CKA006599A2831 | Control Element None for Switch/dimmer Single push button ivory white - 63x63 | 6543-82-101 | 1 | sztuka |
| 2CKA006599A2907 | Control Element None for Dimmer Two-part button with Neon lamp ivory white - 63x63 | 6545-82 | 1 | sztuka |
| 2CKA006730A0032 | Electronic Controls 1 channel Radio Control ivory white - 63x63 | 6731-82-500 | 1 | sztuka |
| 2CKA006730A0033 | Electronic Controls 2 channel Radio Control ivory white - 63x63 | 6732-82-500 | 1 | sztuka |
| 2CKA006730A0034 | Electronic Controls 4 channel Radio Control ivory white - 63x63 | 6733-82-500 | 1 | sztuka |
| 2CKA006730A0134 | Control Element None for Dimmer Two-part button beige - 63x63 | 6736 FoH-82 | 1 | sztuka |
| 2CKA006800A2830 | Electronic Controls ivory white - 63x63 | 6815-82-101-500 | 1 | sztuka |
| 2CKA008200A0079 | Cover plate Loudspeaker ivory white - 63x63 | 8253-82 | 1 | sztuka |
| 2CKA006220A0532 | CP-FCC-82 C-plate Fan Coil | CP-FCC-82 | 1 | sztuka |
| 2CKA006220A0529 | CP-RTC-82 C-plate RT sensor unit | CP-RTC-82 | 1 | sztuka |
| 2CKA006220A0530 | MD-F-1.0.1-82 Movement detector | MD-F-1.0.1-82 | 1 | sztuka |

| | | | | |
|-----------------|---|------------------------|---|--------|
| 2CKA006200A0084 | MSA-F-1.1.1-82-WL WL-Mov. detector/act. 1g | MSA-F-1.1.1-82-WL | 1 | sztuka |
| 2CKA006220A0516 | Electronic Controls ivory white - solo | SR-1-82 | 1 | sztuka |
| 2CKA006220A0521 | Electronic Controls ivory white - solo | SR-2-82 | 1 | sztuka |
| 2CKA006220A0518 | Electronic Controls ivory white - solo | SRB-1-82 | 1 | sztuka |
| 2CKA006220A0523 | Electronic Controls ivory white - solo | SRB-2-82 | 1 | sztuka |
| 2CKA006220A0520 | Electronic Controls ivory white - solo | SRD-1-82 | 1 | sztuka |
| 2CKA006220A0525 | Electronic Controls ivory white - solo | SRD-2-L-82 | 1 | sztuka |
| 2CKA006220A0526 | Electronic Controls ivory white - solo | SRD-2-R-82 | 1 | sztuka |
| 2CKA006220A0517 | Electronic Controls ivory white - solo | SRL-1-82 | 1 | sztuka |
| 2CKA006220A0522 | Electronic Controls ivory white - solo | SRL-2-L-82 | 1 | sztuka |
| 2CKA006220A0527 | Electronic Controls ivory white - solo | SRL-2-R-82 | 1 | sztuka |
| 2CKA006220A0519 | Electronic Controls ivory white - solo | SRS-1-82 | 1 | sztuka |
| 2CKA006220A0524 | Electronic Controls ivory white - solo | SRS-2-L-82 | 1 | sztuka |
| 2CKA006220A0528 | Electronic Controls ivory white - solo | SRS-2-R-82 | 1 | sztuka |
| 2CKA002190A0224 | Socket Outlets Without imprint British Standard grey metallic - Busch-axcent | 2190 EUC-803 | 1 | sztuka |
| 2CKA002190A0216 | Socket Outlets Without imprint British Standard anthracite - 63x63 | 2190 EUC-81 | 1 | sztuka |
| 2CKA002190A0214 | Socket Outlets Without imprint British Standard aluminium silver - 63x63 | 2190 EUC-83 | 1 | sztuka |
| 2CKA002190A0217 | Socket Outlets Without imprint British Standard stainless steel - Pure Stainless Steel | 2190 EUC-866 | 1 | sztuka |
| 2CKA002190A0218 | Socket Outlets Without imprint British Standard studio white matt - 63x63 | 2190 EUC-884 | 1 | sztuka |
| 2CKA002013A5474 | SCHUKO® socket insert Without imprint Safety Shutter anthracite - 63x63 | 23 EUCB-81 | 1 | sztuka |
| 2CKA002013A5476 | SCHUKO® socket insert Without imprint Safety Shutter aluminium silver - 63x63 | 23 EUCB-83 | 1 | sztuka |
| 2CKA002013A5478 | SCHUKO® socket insert Without imprint Safety Shutter stainless steel - Pure Stainless Steel | 23 EUCB-866 | 1 | sztuka |
| 2CKA002013A5479 | SCHUKO® socket insert Without imprint Safety Shutter studio white matt - 63x63 | 23 EUCB-884 | 1 | sztuka |
| 2CKA002013A5480 | SCHUKO® socket insert Without imprint Safety Shutter black matt - 63x63 | 23 EUCB-885 | 1 | sztuka |
| 2CKA002013A5447 | SCHUKO® socket insert Without imprint Safety Shutter grey metallic - 63x63 | 2300 EUCB-803 | 1 | sztuka |
| 2CKA002013A5448 | SCHUKO® socket insert Without imprint Safety Shutter anthracite - 63x63 | 2300 EUCB-81 | 1 | sztuka |
| 2CKA002013A5450 | SCHUKO® socket insert Without imprint Safety Shutter aluminium silver - 63x63 | 2300 EUCB-83 | 1 | sztuka |
| 2CKA002013A5452 | SCHUKO® socket insert Without imprint Safety Shutter stainless steel - Pure Stainless Steel | 2300 EUCB-866 | 1 | sztuka |
| 2CKA002013A5453 | SCHUKO® socket insert Without imprint Safety Shutter studio white matt - 63x63 | 2300 EUCB-884 | 1 | sztuka |
| 2CKA002013A5454 | SCHUKO® socket insert Without imprint Safety Shutter black matt - 63x63 | 2300 EUCB-885 | 1 | sztuka |
| 2CKA002113A5339 | Socket Outlets Without imprint Safety Shutter anthracite - 63x63 | 2300 UCRKS-81-503 | 1 | sztuka |
| 2CKA002113A5337 | Socket Outlets Without imprint Safety Shutter studio white matt - 63x63 | 2300 UCRKS-884-503 | 1 | sztuka |
| 2CKA002113A5340 | Socket Outlets Without imprint Safety Shutter black matt - 63x63 | 2300 UCRKS-885-503 | 1 | sztuka |
| 2CKA002011A6257 | Busch-Protector® SCHUKO® socket insert Without imprint red - 63x63 | 2310 EUGL/VA-12-82-101 | 1 | sztuka |
| 2CKA002011A3830 | Busch-Protector® SCHUKO® socket insert Without imprint anthracite - 63x63 | 2310 EUGL/VA-81-11 | 1 | sztuka |

| | | | | |
|-----------------|--|---------------------|---|--------|
| 2CKA002011A3832 | Busch-Protector® SCHUKO® socket insert Without imprint aluminium silver - 63x63 | 2310 EUGL/VA-83-11 | 1 | sztuka |
| 2CKA002011A3877 | Busch-Protector® SCHUKO® socket insert Without imprint grey metallic - 63x63 | 2310 EUGL/VA-803-11 | 1 | sztuka |
| 2CKA002011A3853 | Busch-Protector® SCHUKO® socket insert Without imprint stainless steel - Pure Stainless Steel | 2310 EUGL/VA-866-11 | 1 | sztuka |
| 2CKA002011A3882 | Busch-Protector® SCHUKO® socket insert Without imprint studio white matt - 63x63 | 2310 EUGL/VA-884-11 | 1 | sztuka |
| 2CKA002011A3885 | Busch-Protector® SCHUKO® socket insert Without imprint black matt - 63x63 | 2310 EUGL/VA-885-11 | 1 | sztuka |
| 2CKA002013A5356 | 2398 CKS-803 Cover plate shuttered | 2398 CKS-803 | 1 | sztuka |
| 2CKA002013A5357 | 2398 CKS-81 Cover plate shuttered | 2398 CKS-81 | 1 | sztuka |
| 2CKA002013A5360 | 2398 CKS-83 Cover plate shuttered | 2398 CKS-83 | 1 | sztuka |
| 2CKA002013A5363 | 2398 CKS-884 Cover plate shuttered | 2398 CKS-884 | 1 | sztuka |
| 2CKA002013A5364 | 2398 CKS-885 Cover plate shuttered | 2398 CKS-885 | 1 | sztuka |
| 2CKA002099A0253 | Socket Outlets Without imprint Safety Shutter grey metallic - 63x63 | 2399 UCKS-803 | 1 | sztuka |
| 2CKA002099A0216 | Socket Outlets Without imprint Safety Shutter anthracite - 63x63 | 2399 UCKS-81 | 1 | sztuka |
| 2CKA002099A0241 | Socket Outlets Without imprint Safety Shutter aluminium silver - 63x63 | 2399 UCKS-83 | 1 | sztuka |
| 2CKA002099A0243 | Socket Without imprint Safety Shutter stainless steel - Pure Stainless Steel | 2399 UCKS-866 | 1 | sztuka |
| 2CKA002099A0255 | Socket Outlets Without imprint Safety Shutter studio white matt - 63x63 | 2399 UCKS-884 | 1 | sztuka |
| 2CKA001751A3175 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker grey metallic - 63x63 | 2520 KI-803 | 1 | sztuka |
| 2CKA001751A3176 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker anthracite - 63x63 | 2520 KI-81 | 1 | sztuka |
| 2CKA001751A3178 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker aluminium silver - 63x63 | 2520 KI-83 | 1 | sztuka |
| 2CKA001751A3181 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel | 2520 KI-866 | 1 | sztuka |
| 2CKA001751A3182 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker studio white matt - 63x63 | 2520 KI-884 | 1 | sztuka |
| 2CKA001751A3183 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker black matt - 63x63 | 2520 KI-885 | 1 | sztuka |
| 2CKA001751A3185 | Rocker for Switch/push button, Single rocker grey metallic - 63x63 | 2520 LI-803 | 1 | sztuka |
| 2CKA001751A3186 | Rocker with legend Symbol "light" for Switch/push button, Single rocker anthracite - 63x63 | 2520 LI-81 | 1 | sztuka |
| 2CKA001751A3188 | Rocker with legend Symbol "light" for Switch/push button, Single rocker aluminium silver - 63x63 | 2520 LI-83 | 1 | sztuka |
| 2CKA001751A3191 | Rocker with legend Symbol "light" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel | 2520 LI-866 | 1 | sztuka |
| 2CKA001751A3192 | Rocker with legend Symbol "light" for Switch/push button, Single rocker studio white matt - 63x63 | 2520 LI-884 | 1 | sztuka |
| 2CKA001751A3193 | Rocker with legend Symbol "light" for Switch/push button, Single rocker black matt - 63x63 | 2520 LI-885 | 1 | sztuka |
| 2CKA001751A3195 | Rocker for Switch/push button, Single rocker grey metallic - 63x63 | 2520 TR-803 | 1 | sztuka |
| 2CKA001751A3196 | Rocker with legend Symbol "key" for Switch/push button, Single rocker anthracite - 63x63 | 2520 TR-81 | 1 | sztuka |
| 2CKA001751A3197 | Rocker with legend Symbol "key" for Switch/push button, Single rocker ivory white - 63x63 | 2520 TR-82 | 1 | sztuka |
| 2CKA001751A3198 | Rocker with legend Symbol "key" for Switch/push button, Single rocker aluminium silver - 63x63 | 2520 TR-83 | 1 | sztuka |

| | | | | |
|-----------------|---|----------------|---|--------|
| 2CKA001751A3200 | Rocker with legend Symbol "key" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel | 2520 TR-866 | 1 | sztuka |
| 2CKA001751A3201 | Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white matt - 63x63 | 2520 TR-884 | 1 | sztuka |
| 2CKA001751A3202 | Rocker with legend Symbol "key" for Switch/push button, Single rocker black matt - 63x63 | 2520 TR-885 | 1 | sztuka |
| 2CKA001724A4407 | Cover plate Bore hole grey metallic - 63x63 | 2533-803 | 1 | sztuka |
| 2CKA001724A4254 | Cover plate Bore hole 1 gang anthracite - 63x63 | 2533-81 | 1 | sztuka |
| 2CKA001724A4382 | Cover plate Bore hole 1 gang yellow - 63x63 | 2533-82-15 | 1 | sztuka |
| 2CKA001724A4261 | Cover plate Bore hole 1 gang aluminium silver - 63x63 | 2533-83 | 1 | sztuka |
| 2CKA001724A4270 | Cover plate Bore hole 1 gang stainless steel - Pure Stainless Steel | 2533-866 | 1 | sztuka |
| 2CKA001724A4296 | Cover plate Bore hole 1 gang studio white matt - 63x63 | 2533-884 | 1 | sztuka |
| 2CKA001724A4301 | Cover plate Bore hole 1 gang black matt - 63x63 | 2533-885 | 1 | sztuka |
| 2CKA001710A4125 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button grey metallic - 63x63 | 2542 DR/01-803 | 1 | sztuka |
| 2CKA001710A3644 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button anthracite - 63x63 | 2542 DR/01-81 | 1 | sztuka |
| 2CKA001710A3671 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button aluminium silver - 63x63 | 2542 DR/01-83 | 1 | sztuka |
| 2CKA001710A3758 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button stainless steel - Pure Stainless Steel | 2542 DR/01-866 | 1 | sztuka |
| 2CKA001710A3890 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button studio white matt - 63x63 | 2542 DR/01-884 | 1 | sztuka |
| 2CKA001710A3913 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button black matt - 63x63 | 2542 DR/01-885 | 1 | sztuka |
| 2CKA001710A4126 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button grey metallic - 63x63 | 2542 DR/02-803 | 1 | sztuka |
| 2CKA001710A3649 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button anthracite - 63x63 | 2542 DR/02-81 | 1 | sztuka |
| 2CKA001710A3672 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button aluminium silver - 63x63 | 2542 DR/02-83 | 1 | sztuka |
| 2CKA001710A3759 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button stainless steel - Pure Stainless Steel | 2542 DR/02-866 | 1 | sztuka |
| 2CKA001710A3891 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button studio white matt - 63x63 | 2542 DR/02-884 | 1 | sztuka |
| 2CKA001710A3914 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button black matt - 63x63 | 2542 DR/02-885 | 1 | sztuka |
| 2CKA001724A4398 | Cover plate XLR grey metallic - 63x63 | 2553-803 | 1 | sztuka |
| 2CKA001724A4399 | Cover plate XLR 1 gang anthracite - 63x63 | 2553-81 | 1 | sztuka |
| 2CKA001724A4401 | Cover plate XLR 1 gang aluminium silver - 63x63 | 2553-83 | 1 | sztuka |
| 2CKA001724A4403 | Cover plate XLR 1 gang stainless steel - Pure Stainless Steel | 2553-866 | 1 | sztuka |
| 2CKA001724A4404 | Cover plate XLR 1 gang studio white matt - 63x63 | 2553-884 | 1 | sztuka |
| 2CKA001724A4405 | Cover plate XLR 1 gang black matt - 63x63 | 2553-885 | 1 | sztuka |
| 2CKA001753A0316 | Cover plate Modular Jack 2 gang grey metallic - 63x63 | 2561-02-803 | 1 | sztuka |
| 2CKA001753A0317 | Cover plate Modular Jack 2 gang anthracite - 63x63 | 2561-02-81 | 1 | sztuka |
| 2CKA001753A0393 | Cover plate Modular Jack 2 gang aluminium silver - 63x63 | 2561-02-83 | 1 | sztuka |
| 2CKA001753A0395 | Cover plate Modular Jack 2 gang stainless steel - Pure Stainless Steel | 2561-02-866 | 1 | sztuka |

| | | | | |
|-----------------|---|-----------------|---|--------|
| 2CKA001753A0396 | Cover plate Modular Jack 2 gang studio white matt - 63x63 | 2561-02-884 | 1 | sztuka |
| 2CKA001753A0397 | Cover plate Modular Jack 2 gang black matt - 63x63 | 2561-02-885 | 1 | sztuka |
| 2CKA001753A0399 | Cover plate Modular Jack 1 gang grey metallic - 63x63 | 2561-803 | 1 | sztuka |
| 2CKA001753A0400 | Cover plate Modular Jack 1 gang anthracite - 63x63 | 2561-81 | 1 | sztuka |
| 2CKA001753A0402 | Cover plate Modular Jack 1 gang aluminium silver - 63x63 | 2561-83 | 1 | sztuka |
| 2CKA001753A0404 | Cover plate Modular Jack 1 gang stainless steel - Pure Stainless Steel | 2561-866 | 1 | sztuka |
| 2CKA001753A0405 | Cover plate Modular Jack 1 gang studio white matt - 63x63 | 2561-884 | 1 | sztuka |
| 2CKA001753A0406 | Cover plate Modular Jack 1 gang black matt - 63x63 | 2561-885 | 1 | sztuka |
| 2CKA003116A0666 | FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA grey metallic - 63x63 | 3120 EUCB-803 | 1 | sztuka |
| 2CKA003116A0667 | FI-Schukomat SCHUKO® socket insert Without imprint Safety Shutter anthracite - 63x63 | 3120 EUCB-81 | 1 | sztuka |
| 2CKA003116A0668 | FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA aluminium silver - 63x63 | 3120 EUCB-83 | 1 | sztuka |
| 2CKA003116A0669 | FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA stainless steel - Pure Stainless Steel | 3120 EUCB-866 | 1 | sztuka |
| 2CKA003116A0670 | FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA studio white matt - 63x63 | 3120 EUCB-884 | 1 | sztuka |
| 2CKA003116A0671 | FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA black matt - 63x63 | 3120 EUCB-885 | 1 | sztuka |
| 2CKA003117A0008 | Buschmat RCD - Insert RCD 30 mA grey metallic - 63x63 | 3151 UC-803 | 1 | sztuka |
| 2CKA003117A0009 | Buschmat RCD - Insert RCD 30 mA anthracite - 63x63 | 3151 UC-81 | 1 | sztuka |
| 2CKA003117A0010 | Buschmat RCD - Insert RCD 30 mA aluminium silver - 63x63 | 3151 UC-83 | 1 | sztuka |
| 2CKA003117A0011 | Buschmat RCD - Insert RCD 30 mA stainless steel - Pure Stainless Steel | 3151 UC-866 | 1 | sztuka |
| 2CKA003117A0012 | Buschmat RCD - Insert RCD 30 mA studio white matt - 63x63 | 3151 UC-884 | 1 | sztuka |
| 2CKA003117A0013 | Buschmat RCD - Insert RCD 30 mA black matt - 63x63 | 3151 UC-885 | 1 | sztuka |
| 2CKA006115A0489 | 6108/61-803-500 Coverplate f. CE | 6108/61-803-500 | 1 | sztuka |
| 2CKA006115A0483 | 6108/61-81-500 Coverplate f. CE | 6108/61-81-500 | 1 | sztuka |
| 2CKA006115A0485 | 6108/61-83-500 Coverplate f. CE | 6108/61-83-500 | 1 | sztuka |
| 2CKA006115A0492 | 6108/61-866-500 Coverplate f. CE | 6108/61-866-500 | 1 | sztuka |
| 2CKA006115A0487 | 6108/61-884-500 Coverplate f. CE | 6108/61-884-500 | 1 | sztuka |
| 2CKA006115A0488 | 6108/61-885-500 Coverplate f. CE | 6108/61-885-500 | 1 | sztuka |
| 2CKA006155A0066 | 6109/03-803-500 Coverplate f. RTC | 6109/03-803-500 | 1 | sztuka |
| 2CKA006155A0060 | 6109/03-81-500 Coverplate f. RTC | 6109/03-81-500 | 1 | sztuka |
| 2CKA006155A0062 | 6109/03-83-500 Coverplate f. RTC | 6109/03-83-500 | 1 | sztuka |

| | | | | |
|-----------------|---|-----------------|---|--------|
| 2CKA006155A0069 | 6109/03-866-500 Coverplate f. RTC | 6109/03-866-500 | 1 | sztuka |
| 2CKA006155A0064 | 6109/03-884-500 Coverplate f. RTC | 6109/03-884-500 | 1 | sztuka |
| 2CKA006155A0065 | 6109/03-885-500 Coverplate f. RTC | 6109/03-885-500 | 1 | sztuka |
| 2CKA006132A0382 | Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° grey metallic | 6122/10-803-500 | 1 | sztuka |
| 2CKA006132A0376 | Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° anthracite | 6122/10-81-500 | 1 | sztuka |
| 2CKA006132A0378 | Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° aluminium silver | 6122/10-83-500 | 1 | sztuka |
| 2CKA006132A0385 | Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° stainless steel | 6122/10-866-500 | 1 | sztuka |
| 2CKA006132A0380 | Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° studio white matt | 6122/10-884-500 | 1 | sztuka |
| 2CKA006132A0381 | Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° black matt | 6122/10-885-500 | 1 | sztuka |
| 2CKA006115A0212 | 6125/01-803-500 Control element 1g w. BAU | 6125/01-803-500 | 1 | sztuka |
| 2CKA006115A0205 | 6125/01-81-500 Control element 1g w. BAU | 6125/01-81-500 | 1 | sztuka |
| 2CKA006115A0207 | 6125/01-83-500 Control element 1g w. BAU | 6125/01-83-500 | 1 | sztuka |
| 2CKA006115A0211 | 6125/01-866-500 Control element 1g w. BAU | 6125/01-866-500 | 1 | sztuka |
| 2CKA006115A0214 | 6125/01-884-500 Control element 1g w. BAU | 6125/01-884-500 | 1 | sztuka |
| 2CKA006115A0215 | 6125/01-885-500 Control element 1g w. BAU | 6125/01-885-500 | 1 | sztuka |
| 2CKA006115A0224 | 6125/02-803-500 Control element 1/2gang | 6125/02-803-500 | 1 | sztuka |
| 2CKA006115A0216 | 6125/02-81-500 Control element 1/2gang | 6125/02-81-500 | 1 | sztuka |
| 2CKA006115A0218 | 6125/02-83-500 Control element 1/2gang | 6125/02-83-500 | 1 | sztuka |
| 2CKA006115A0223 | 6125/02-866-500 Control element 1/2gang | 6125/02-866-500 | 1 | sztuka |
| 2CKA006115A0226 | 6125/02-884-500 Control element 1/2gang | 6125/02-884-500 | 1 | sztuka |
| 2CKA006115A0227 | 6125/02-885-500 Control element 1/2gang | 6125/02-885-500 | 1 | sztuka |
| 2CKA006116A0202 | 6126/01-803-500 Control element 2g w. BAU | 6126/01-803-500 | 1 | sztuka |
| 2CKA006116A0195 | 6126/01-81-500 Control element 2g w. BAU | 6126/01-81-500 | 1 | sztuka |
| 2CKA006116A0197 | 6126/01-83-500 Control element 2g w. BAU | 6126/01-83-500 | 1 | sztuka |
| 2CKA006116A0201 | 6126/01-866-500 Control element 2g w. BAU | 6126/01-866-500 | 1 | sztuka |
| 2CKA006116A0204 | 6126/01-884-500 Control element 2g w. BAU | 6126/01-884-500 | 1 | sztuka |
| 2CKA006116A0205 | 6126/01-885-500 Control element 2g w. BAU | 6126/01-885-500 | 1 | sztuka |
| 2CKA006116A0214 | 6126/02-803-500 Control element 2/4gang | 6126/02-803-500 | 1 | sztuka |
| 2CKA006116A0206 | 6126/02-81-500 Control element 2/4gang | 6126/02-81-500 | 1 | sztuka |

| | | | | |
|-----------------|---|-----------------|---|--------|
| 2CKA006116A0208 | 6126/02-83-500 Control element 2/4gang | 6126/02-83-500 | 1 | sztuka |
| 2CKA006116A0213 | 6126/02-866-500 Control element 2/4gang | 6126/02-866-500 | 1 | sztuka |
| 2CKA006116A0216 | 6126/02-884-500 Control element 2/4gang | 6126/02-884-500 | 1 | sztuka |
| 2CKA006116A0217 | 6126/02-885-500 Control element 2/4gang | 6126/02-885-500 | 1 | sztuka |
| 2CKA006117A0228 | 6127/01-803-500 Control element 4g w. BAU | 6127/01-803-500 | 1 | sztuka |
| 2CKA006117A0221 | 6127/01-81-500 Control element 4g w. BAU | 6127/01-81-500 | 1 | sztuka |
| 2CKA006117A0223 | 6127/01-83-500 Control element 4g w. BAU | 6127/01-83-500 | 1 | sztuka |
| 2CKA006117A0227 | 6127/01-866-500 Control element 4g w. BAU | 6127/01-866-500 | 1 | sztuka |
| 2CKA006117A0230 | 6127/01-884-500 Control element 4g w. BAU | 6127/01-884-500 | 1 | sztuka |
| 2CKA006117A0231 | 6127/01-885-500 Control element 4g w. BAU | 6127/01-885-500 | 1 | sztuka |
| 2CKA006117A0240 | 6127/02-803-500 Control element 4/8gang | 6127/02-803-500 | 1 | sztuka |
| 2CKA006117A0232 | 6127/02-81-500 Control element 4/8gang | 6127/02-81-500 | 1 | sztuka |
| 2CKA006117A0234 | 6127/02-83-500 Control element 4/8gang | 6127/02-83-500 | 1 | sztuka |
| 2CKA006117A0239 | 6127/02-866-500 Control element 4/8gang | 6127/02-866-500 | 1 | sztuka |
| 2CKA006117A0242 | 6127/02-884-500 Control element 4/8gang | 6127/02-884-500 | 1 | sztuka |
| 2CKA006117A0243 | 6127/02-885-500 Control element 4/8gang | 6127/02-885-500 | 1 | sztuka |
| 2CKA006134A0336 | 6128/28-803-500 RTC Control element 2/4g | 6128/28-803-500 | 1 | sztuka |
| 2CKA006134A0331 | 6128/28-81-500 RTC Control element 2/4g | 6128/28-81-500 | 1 | sztuka |
| 2CKA006134A0333 | 6128/28-83-500 RTC Control element 2/4g | 6128/28-83-500 | 1 | sztuka |
| 2CKA006134A0335 | 6128/28-866-500 RTC Control element 2/4g | 6128/28-866-500 | 1 | sztuka |
| 2CKA006134A0338 | 6128/28-884-500 RTC Control element 2/4g | 6128/28-884-500 | 1 | sztuka |
| 2CKA006134A0339 | 6128/28-885-500 RTC Control element 2/4g | 6128/28-885-500 | 1 | sztuka |
| 2CKA006135A0163 | 6129/01-803-500 Control element 3/6g w. IR | 6129/01-803-500 | 1 | sztuka |
| 2CKA006135A0156 | 6129/01-81-500 Control element 3/6g w. IR | 6129/01-81-500 | 1 | sztuka |
| 2CKA006135A0158 | 6129/01-83-500 Control element 3/6g w. IR | 6129/01-83-500 | 1 | sztuka |
| 2CKA006135A0162 | 6129/01-866-500 Control element 3/6g w. IR | 6129/01-866-500 | 1 | sztuka |
| 2CKA006135A0165 | 6129/01-884-500 Control element 3/6g w. IR | 6129/01-884-500 | 1 | sztuka |
| 2CKA006135A0166 | 6129/01-885-500 Control element 3/6g w. IR | 6129/01-885-500 | 1 | sztuka |
| 2CKA006430A0350 | Control Element Symbol "arrows" for Venetian blind grey metallic - 63x63 | 6430-803-102 | 1 | sztuka |
| 2CKA006430A0326 | Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind One-part rocker anthracite - 63x63 | 6430-81-102 | 1 | sztuka |

| | | | | |
|-----------------|---|--------------|---|--------|
| 2CKA006430A0328 | Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind One-part rocker aluminium silver - 63x63 | 6430-83-102 | 1 | sztuka |
| 2CKA006430A0343 | Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind One-part rocker stainless steel - Pure Stainless Steel | 6430-866-102 | 1 | sztuka |
| 2CKA006430A0385 | Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind One-part rocker studio white matt - 63x63 | 6430-884-102 | 1 | sztuka |
| 2CKA006430A0386 | Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind One-part rocker black matt - 63x63 | 6430-885-102 | 1 | sztuka |
| 2CKA006430A0351 | Cover plate with legend Various symbols for Time switch Central cover plate grey metallic - 63x63 | 6435-803 | 1 | sztuka |
| 2CKA006430A0303 | Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate anthracite - 63x63 | 6435-81 | 1 | sztuka |
| 2CKA006430A0305 | Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate aluminium silver - 63x63 | 6435-83 | 1 | sztuka |
| 2CKA006430A0344 | Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate stainless steel - Pure Stainless Steel | 6435-866 | 1 | sztuka |
| 2CKA006430A0388 | Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate studio white matt - 63x63 | 6435-884 | 1 | sztuka |
| 2CKA006430A0389 | Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate black matt - 63x63 | 6435-885 | 1 | sztuka |
| 2CKA006470A0006 | Cover plate Symbol "key/door" for Proximity switch One-part button grey metallic - 63x63 | 6476-803 | 1 | sztuka |
| 2CKA006470A0008 | Cover plate None for Proximity switch One-part button aluminium silver - 63x63 | 6476-83 | 1 | sztuka |
| 2CKA006470A0009 | Cover plate None for Proximity switch One-part button stainless steel - Pure Stainless Steel | 6476-866 | 1 | sztuka |
| 2CKA006470A0010 | Cover plate None for Proximity switch One-part button studio white matt - 63x63 | 6476-884 | 1 | sztuka |
| 2CKA006470A0011 | Cover plate None for Proximity switch One-part button black matt - 63x63 | 6476-885 | 1 | sztuka |
| 2CKA006400A0060 | Cover plate PowerDock 1 gang grey metallic - 63x63 | 6477-803 | 1 | sztuka |
| 2CKA006400A0056 | Cover plate PowerDock 1 gang anthracite - 63x63 | 6477-81 | 1 | sztuka |
| 2CKA006400A0058 | Cover plate PowerDock 1 gang aluminium silver - 63x63 | 6477-83 | 1 | sztuka |
| 2CKA006400A0064 | Cover plate PowerDock 1 gang stainless steel - Pure Stainless Steel | 6477-866 | 1 | sztuka |
| 2CKA006400A0062 | Cover plate PowerDock 1 gang studio white matt - 63x63 | 6477-884 | 1 | sztuka |
| 2CKA006400A0063 | Cover plate PowerDock 1 gang black matt - 63x63 | 6477-885 | 1 | sztuka |
| 2CKA006599A2980 | Cover plate None for Dimmer Turn button with Neon lamp grey metallic - 63x63 | 6540-803-102 | 1 | sztuka |
| 2CKA006599A2950 | Cover plate None for Dimmer Turn button with Neon lamp anthracite - 63x63 | 6540-81-102 | 1 | sztuka |
| 2CKA006599A2952 | Cover plate None for Dimmer Turn button with Neon lamp aluminium silver - 63x63 | 6540-83-102 | 1 | sztuka |
| 2CKA006599A2959 | Cover plate None for Dimmer Turn button with Neon lamp stainless steel - Pure Stainless Steel | 6540-866-102 | 1 | sztuka |
| 2CKA006599A2961 | Cover plate None for Dimmer Turn button with Neon lamp studio white matt - 63x63 | 6540-884-102 | 1 | sztuka |
| 2CKA006599A2966 | Cover plate None for Dimmer Turn button with Neon lamp black matt - 63x63 | 6540-885-102 | 1 | sztuka |
| 2CKA006599A2882 | Cover plate None for Cooling Central cover plate anthracite - 63x63 | 6541-81 | 1 | sztuka |

| | | | | |
|-----------------|---|------------------|---|--------|
| 2CKA006599A2885 | Cover plate None for Cooling Central cover plate aluminium silver - 63x63 | 6541-83 | 1 | sztuka |
| 2CKA006599A2924 | Cover plate None for Cooling Central cover plate stainless steel - Pure Stainless Steel | 6541-866 | 1 | sztuka |
| 2CKA006599A2962 | Cover plate None for Cooling Central cover plate studio white matt - 63x63 | 6541-884 | 1 | sztuka |
| 2CKA006599A2967 | Cover plate None for Cooling Central cover plate black matt - 63x63 | 6541-885 | 1 | sztuka |
| 2CKA006599A2881 | Control Element None for Switch/dimmer Single push button anthracite - 63x63 | 6543-81-101 | 1 | sztuka |
| 2CKA006599A2887 | Control Element None for Switch/dimmer Single push button aluminium silver - 63x63 | 6543-83-101 | 1 | sztuka |
| 2CKA006599A2926 | Control Element None for Switch/dimmer Single push button stainless steel - Pure Stainless Steel | 6543-866-101 | 1 | sztuka |
| 2CKA006599A2963 | Control Element None for Switch/dimmer Single push button studio white matt - 63x63 | 6543-884-101 | 1 | sztuka |
| 2CKA006599A2968 | Control Element None for Switch/dimmer Single push button black matt - 63x63 | 6543-885-101 | 1 | sztuka |
| 2CKA006599A2943 | Control Element None for Dimmer Two-part button with Neon lamp grey metallic - 63x63 | 6545-803 | 1 | sztuka |
| 2CKA006599A2906 | Control Element None for Dimmer Two-part button with Neon lamp anthracite - 63x63 | 6545-81 | 1 | sztuka |
| 2CKA006599A2914 | Control Element None for Dimmer Two-part button with Neon lamp aluminium silver - 63x63 | 6545-83 | 1 | sztuka |
| 2CKA006599A2927 | Control Element None for Dimmer Two-part button with Neon lamp stainless steel - Pure Stainless Steel | 6545-866 | 1 | sztuka |
| 2CKA006599A2964 | Control Element None for Dimmer Two-part button with Neon lamp studio white matt - 63x63 | 6545-884 | 1 | sztuka |
| 2CKA006599A2969 | Control Element None for Dimmer Two-part button with Neon lamp black matt - 63x63 | 6545-885 | 1 | sztuka |
| 2CKA006730A0035 | Electronic Controls 1 channel Radio Control aluminium silver - 63x63 | 6731-83-500 | 1 | sztuka |
| 2CKA006730A0041 | WaveLine Electronic Controls 1 channel Radio Control stainless steel - Pure Stainless Steel | 6731-866-500 | 1 | sztuka |
| 2CKA006730A0036 | Electronic Controls 2 channel Radio Control aluminium silver - 63x63 | 6732-83-500 | 1 | sztuka |
| 2CKA006730A0042 | Wall sensor 2 channel Radio Control stainless steel - Pure Stainless Steel | 6732-866-500 | 1 | sztuka |
| 2CKA006730A0037 | Electronic Controls 4 channel Radio Control aluminium silver - 63x63 | 6733-83-500 | 1 | sztuka |
| 2CKA006730A0043 | Electronic Controls 4 channel Radio Control stainless steel - Pure Stainless Steel | 6733-866-500 | 1 | sztuka |
| 2CKA006730A0141 | Control Element None for Dimmer Two-part button black matt - 63x63 | 6736 FoH-885 | 1 | sztuka |
| 2CKA006800A2832 | Electronic Controls aluminium silver - 63x63 | 6815-83-101-500 | 1 | sztuka |
| 2CKA006800A2843 | Electronic Controls stainless steel - Pure Stainless Steel | 6815-866-101-500 | 1 | sztuka |
| 2CKA008200A0253 | Cover plate with legend Radio 0 gang aluminium silver - 63x63 | 8252-83-101-500 | 1 | sztuka |
| 2CKA008200A0264 | Cover plate with legend Radio 0 gang stainless steel - Pure Stainless Steel | 8252-866-101-500 | 1 | sztuka |
| 2CKA008200A0261 | Cover plate with legend Radio 0 gang black matt - 63x63 | 8252-885-101-500 | 1 | sztuka |
| 2CKA008200A0115 | Cover plate Loudspeaker grey metallic - 63x63 | 8253-803 | 1 | sztuka |
| 2CKA008200A0078 | Cover plate Loudspeaker anthracite - 63x63 | 8253-81 | 1 | sztuka |
| 2CKA008200A0080 | Cover plate Loudspeaker aluminium silver - 63x63 | 8253-83 | 1 | sztuka |
| 2CKA008200A0087 | Cover plate Loudspeaker stainless steel - Pure Stainless Steel | 8253-866 | 1 | sztuka |

| | | | | |
|-----------------|---|--------------------|---|--------|
| 2CKA008200A0123 | Cover plate Loudspeaker studio white matt - 63x63 | 8253-884 | 1 | sztuka |
| 2CKA008200A0126 | Cover plate Loudspeaker black matt - 63x63 | 8253-885 | 1 | sztuka |
| 2CKA008300A0226 | 83260-81-515 Cover plates, Indoor St. | 83260-81-515 | 1 | sztuka |
| 2CKA006220A0566 | CP-FCC-803 C-plate Fan Coil | CP-FCC-803 | 1 | sztuka |
| 2CKA006220A0242 | CP-FCC-81 C-plate Fan Coil | CP-FCC-81 | 1 | sztuka |
| 2CKA006220A0243 | CP-FCC-83 C-plate Fan Coil | CP-FCC-83 | 1 | sztuka |
| 2CKA006220A0549 | CP-FCC-866 C-plate Fan Coil | CP-FCC-866 | 1 | sztuka |
| 2CKA006220A0617 | CP-FCC-884 C-plate Fan Coil | CP-FCC-884 | 1 | sztuka |
| 2CKA006220A0634 | CP-FCC-885 C-plate Fan Coil | CP-FCC-885 | 1 | sztuka |
| 2CKA006220A0563 | CP-RTC-803 C-plate RT sensor unit | CP-RTC-803 | 1 | sztuka |
| 2CKA006220A0179 | CP-RTC-81 C-plate RT sensor unit | CP-RTC-81 | 1 | sztuka |
| 2CKA006220A0180 | CP-RTC-83 C-plate RT sensor unit | CP-RTC-83 | 1 | sztuka |
| 2CKA006220A0546 | CP-RTC-866 C-plate RT sensor unit | CP-RTC-866 | 1 | sztuka |
| 2CKA006220A0614 | CP-RTC-884 C-plate RT sensor unit | CP-RTC-884 | 1 | sztuka |
| 2CKA006220A0631 | CP-RTC-885 C-plate RT sensor unit | CP-RTC-885 | 1 | sztuka |
| 2CKA006220A0564 | MD-F-1.0.1-803 Movement detector | MD-F-1.0.1-803 | 1 | sztuka |
| 2CKA006220A0212 | MD-F-1.0.1-81 Movement detector | MD-F-1.0.1-81 | 1 | sztuka |
| 2CKA006220A0213 | MD-F-1.0.1-83 Movement detector | MD-F-1.0.1-83 | 1 | sztuka |
| 2CKA006220A0547 | MD-F-1.0.1-866 Movement detector | MD-F-1.0.1-866 | 1 | sztuka |
| 2CKA006220A0615 | MD-F-1.0.1-884 Movement detector | MD-F-1.0.1-884 | 1 | sztuka |
| 2CKA006220A0632 | MD-F-1.0.1-885 Movement detector | MD-F-1.0.1-885 | 1 | sztuka |
| 2CKA006220A0565 | MSA-F-1.1.1-803 Mov. detector/actuator 1g | MSA-F-1.1.1-803 | 1 | sztuka |
| 2CKA006220A0215 | MSA-F-1.1.1-81 Mov. detector/actuator 1g | MSA-F-1.1.1-81 | 1 | sztuka |
| 2CKA006200A0083 | MSA-F-1.1.1-81-WL WL-Mov. detector/act. 1g | MSA-F-1.1.1-81-WL | 1 | sztuka |
| 2CKA006220A0216 | MSA-F-1.1.1-83 Mov. detector/actuator 1g | MSA-F-1.1.1-83 | 1 | sztuka |
| 2CKA006200A0085 | MSA-F-1.1.1-83-WL WL-Mov. detector/act. 1g | MSA-F-1.1.1-83-WL | 1 | sztuka |
| 2CKA006220A0548 | MSA-F-1.1.1-866 Mov. detector/actuator 1g | MSA-F-1.1.1-866 | 1 | sztuka |
| 2CKA006220A0616 | MSA-F-1.1.1-884 Mov. detector/actuator 1g | MSA-F-1.1.1-884 | 1 | sztuka |
| 2CKA006200A0097 | MSA-F-1.1.1-884-WL WL-Mov. detector/act. 1g | MSA-F-1.1.1-884-WL | 1 | sztuka |
| 2CKA006220A0633 | MSA-F-1.1.1-885 Mov. detector/actuator 1g | MSA-F-1.1.1-885 | 1 | sztuka |
| 2CKA006200A0098 | MSA-F-1.1.1-885-WL WL-Mov. detector/act. 1g | MSA-F-1.1.1-885-WL | 1 | sztuka |
| 2CKA006220A0550 | Electronic Controls grey metallic - 63x63 | SR-1-803 | 1 | sztuka |
| 2CKA006220A0137 | Electronic Controls anthracite - 63x63 | SR-1-81 | 1 | sztuka |
| 2CKA006220A0138 | Electronic Controls aluminium silver - 63x63 | SR-1-83 | 1 | sztuka |
| 2CKA006220A0533 | Electronic Controls stainless steel - solo | SR-1-866 | 1 | sztuka |
| 2CKA006220A0601 | Electronic Controls studio white matt - 63x63 | SR-1-884 | 1 | sztuka |
| 2CKA006220A0618 | Electronic Controls black matt - 63x63 | SR-1-885 | 1 | sztuka |
| 2CKA006220A0555 | Electronic Controls grey metallic - 63x63 | SR-2-803 | 1 | sztuka |
| 2CKA006220A0152 | Electronic Controls anthracite - 63x63 | SR-2-81 | 1 | sztuka |
| 2CKA006220A0153 | Electronic Controls aluminium silver - 63x63 | SR-2-83 | 1 | sztuka |

| | | | | |
|-----------------|---|-------------|---|--------|
| 2CKA006220A0538 | Electronic Controls stainless steel - solo | SR-2-866 | 1 | sztuka |
| 2CKA006220A0606 | Electronic Controls studio white matt - 63x63 | SR-2-884 | 1 | sztuka |
| 2CKA006220A0623 | Electronic Controls black matt - 63x63 | SR-2-885 | 1 | sztuka |
| 2CKA006220A0552 | Electronic Controls grey metallic - 63x63 | SRB-1-803 | 1 | sztuka |
| 2CKA006220A0143 | Electronic Controls anthracite - 63x63 | SRB-1-81 | 1 | sztuka |
| 2CKA006220A0144 | Electronic Controls aluminium silver - 63x63 | SRB-1-83 | 1 | sztuka |
| 2CKA006220A0535 | Electronic Controls stainless steel - solo | SRB-1-866 | 1 | sztuka |
| 2CKA006220A0603 | Electronic Controls studio white matt - 63x63 | SRB-1-884 | 1 | sztuka |
| 2CKA006220A0620 | Electronic Controls black matt - 63x63 | SRB-1-885 | 1 | sztuka |
| 2CKA006220A0557 | Electronic Controls grey metallic - 63x63 | SRB-2-803 | 1 | sztuka |
| 2CKA006220A0158 | Electronic Controls anthracite - 63x63 | SRB-2-81 | 1 | sztuka |
| 2CKA006220A0159 | Electronic Controls aluminium silver - 63x63 | SRB-2-83 | 1 | sztuka |
| 2CKA006220A0540 | Electronic Controls stainless steel - solo | SRB-2-866 | 1 | sztuka |
| 2CKA006220A0608 | Electronic Controls studio white matt - 63x63 | SRB-2-884 | 1 | sztuka |
| 2CKA006220A0625 | Electronic Controls black matt - 63x63 | SRB-2-885 | 1 | sztuka |
| 2CKA006220A0554 | Electronic Controls grey metallic - 63x63 | SRD-1-803 | 1 | sztuka |
| 2CKA006220A0149 | Electronic Controls anthracite - 63x63 | SRD-1-81 | 1 | sztuka |
| 2CKA006220A0150 | Electronic Controls aluminium silver - 63x63 | SRD-1-83 | 1 | sztuka |
| 2CKA006220A0537 | Electronic Controls stainless steel - solo | SRD-1-866 | 1 | sztuka |
| 2CKA006220A0605 | Electronic Controls studio white matt - 63x63 | SRD-1-884 | 1 | sztuka |
| 2CKA006220A0622 | Electronic Controls black matt - 63x63 | SRD-1-885 | 1 | sztuka |
| 2CKA006220A0559 | Electronic Controls grey metallic - 63x63 | SRD-2-L-803 | 1 | sztuka |
| 2CKA006220A0164 | Electronic Controls anthracite - 63x63 | SRD-2-L-81 | 1 | sztuka |
| 2CKA006220A0165 | Electronic Controls aluminium silver - 63x63 | SRD-2-L-83 | 1 | sztuka |
| 2CKA006220A0542 | Electronic Controls stainless steel - solo | SRD-2-L-866 | 1 | sztuka |
| 2CKA006220A0610 | Electronic Controls studio white matt - 63x63 | SRD-2-L-884 | 1 | sztuka |
| 2CKA006220A0627 | Electronic Controls black matt - 63x63 | SRD-2-L-885 | 1 | sztuka |
| 2CKA006220A0560 | Electronic Controls grey metallic - 63x63 | SRD-2-R-803 | 1 | sztuka |
| 2CKA006220A0258 | Electronic Controls anthracite - 63x63 | SRD-2-R-81 | 1 | sztuka |
| 2CKA006220A0259 | Electronic Controls aluminium silver - 63x63 | SRD-2-R-83 | 1 | sztuka |
| 2CKA006220A0543 | Electronic Controls stainless steel - solo | SRD-2-R-866 | 1 | sztuka |
| 2CKA006220A0611 | Electronic Controls studio white matt - 63x63 | SRD-2-R-884 | 1 | sztuka |
| 2CKA006220A0628 | Electronic Controls black matt - 63x63 | SRD-2-R-885 | 1 | sztuka |
| 2CKA006220A0551 | Electronic Controls grey metallic - 63x63 | SRL-1-803 | 1 | sztuka |
| 2CKA006220A0140 | Electronic Controls anthracite - 63x63 | SRL-1-81 | 1 | sztuka |
| 2CKA006220A0141 | Electronic Controls aluminium silver - 63x63 | SRL-1-83 | 1 | sztuka |
| 2CKA006220A0534 | Electronic Controls stainless steel - solo | SRL-1-866 | 1 | sztuka |
| 2CKA006220A0602 | Electronic Controls studio white matt - 63x63 | SRL-1-884 | 1 | sztuka |
| 2CKA006220A0619 | Electronic Controls black matt - 63x63 | SRL-1-885 | 1 | sztuka |
| 2CKA006220A0556 | Electronic Controls grey metallic - 63x63 | SRL-2-L-803 | 1 | sztuka |
| 2CKA006220A0155 | Electronic Controls anthracite - 63x63 | SRL-2-L-81 | 1 | sztuka |
| 2CKA006220A0156 | Electronic Controls aluminium silver - 63x63 | SRL-2-L-83 | 1 | sztuka |
| 2CKA006220A0539 | Electronic Controls stainless steel - solo | SRL-2-L-866 | 1 | sztuka |
| 2CKA006220A0607 | Electronic Controls studio white matt - 63x63 | SRL-2-L-884 | 1 | sztuka |
| 2CKA006220A0624 | Electronic Controls black matt - 63x63 | SRL-2-L-885 | 1 | sztuka |
| 2CKA006220A0561 | Electronic Controls grey metallic - 63x63 | SRL-2-R-803 | 1 | sztuka |
| 2CKA006220A0167 | Electronic Controls anthracite - 63x63 | SRL-2-R-81 | 1 | sztuka |
| 2CKA006220A0168 | Electronic Controls aluminium silver - 63x63 | SRL-2-R-83 | 1 | sztuka |
| 2CKA006220A0544 | Electronic Controls stainless steel - solo | SRL-2-R-866 | 1 | sztuka |

| | | | | |
|-----------------|--|----------------|---|--------|
| 2CKA006220A0612 | Electronic Controls studio white matt - 63x63 | SRL-2-R-884 | 1 | sztuka |
| 2CKA006220A0629 | Electronic Controls black matt - 63x63 | SRL-2-R-885 | 1 | sztuka |
| 2CKA006220A0553 | Electronic Controls grey metallic - 63x63 | SRS-1-803 | 1 | sztuka |
| 2CKA006220A0146 | Electronic Controls anthracite - 63x63 | SRS-1-81 | 1 | sztuka |
| 2CKA006220A0147 | Electronic Controls aluminium silver - 63x63 | SRS-1-83 | 1 | sztuka |
| 2CKA006220A0536 | Electronic Controls stainless steel - solo | SRS-1-866 | 1 | sztuka |
| 2CKA006220A0604 | Electronic Controls studio white matt - 63x63 | SRS-1-884 | 1 | sztuka |
| 2CKA006220A0621 | Electronic Controls black matt - 63x63 | SRS-1-885 | 1 | sztuka |
| 2CKA006220A0558 | Electronic Controls grey metallic - 63x63 | SRS-2-L-803 | 1 | sztuka |
| 2CKA006220A0161 | Electronic Controls anthracite - 63x63 | SRS-2-L-81 | 1 | sztuka |
| 2CKA006220A0162 | Electronic Controls aluminium silver - 63x63 | SRS-2-L-83 | 1 | sztuka |
| 2CKA006220A0541 | Electronic Controls stainless steel - solo | SRS-2-L-866 | 1 | sztuka |
| 2CKA006220A0609 | Electronic Controls studio white matt - 63x63 | SRS-2-L-884 | 1 | sztuka |
| 2CKA006220A0626 | Electronic Controls black matt - 63x63 | SRS-2-L-885 | 1 | sztuka |
| 2CKA006220A0562 | Electronic Controls grey metallic - 63x63 | SRS-2-R-803 | 1 | sztuka |
| 2CKA006220A0173 | Electronic Controls anthracite - 63x63 | SRS-2-R-81 | 1 | sztuka |
| 2CKA006220A0174 | Electronic Controls aluminium silver - 63x63 | SRS-2-R-83 | 1 | sztuka |
| 2CKA006220A0545 | Electronic Controls stainless steel - solo | SRS-2-R-866 | 1 | sztuka |
| 2CKA006220A0613 | Electronic Controls studio white matt - 63x63 | SRS-2-R-884 | 1 | sztuka |
| 2CKA006220A0630 | Electronic Controls black matt - 63x63 | SRS-2-R-885 | 1 | sztuka |
| 2CKA001731A1922 | Cover Busch-Infolicht® ivory white - 63x63 | 1716-82 | 1 | sztuka |
| 2CKA001753A0308 | Cover plate for Pull-cord switch, Pull cord anthracite - 63x63 | 1796-81 | 1 | sztuka |
| 2CKA001799A0895 | Mounting Box 1 gang anthracite - future linear | 1701-81 | 1 | sztuka |
| 2CKA001799A0896 | Mounting Box 1 gang ivory white - future linear | 1701-82 | 1 | sztuka |
| 2CKA001799A0905 | Mounting Box 1 gang aluminium silver - future linear | 1701-83 | 1 | sztuka |
| 2CKA001799A0921 | Mounting Box 1 gang studio white matt - future linear | 1701-884 | 1 | sztuka |
| 2CKA001799A0923 | Mounting Box 1 gang black matt - future linear | 1701-885 | 1 | sztuka |
| 2CKA001799A0900 | Mounting Box 2 gang anthracite - future linear | 1702-81 | 1 | sztuka |
| 2CKA001799A0901 | Mounting Box 2 gang ivory white - future linear | 1702-82 | 1 | sztuka |
| 2CKA001799A0906 | Mounting Box 2 gang aluminium silver - future linear | 1702-83 | 1 | sztuka |
| 2CKA001799A0922 | Mounting Box 2 gang studio white matt - future linear | 1702-884 | 1 | sztuka |
| 2CKA001799A0924 | Mounting Box 2 gang black matt - future linear | 1702-885 | 1 | sztuka |
| 2CKA001799A0915 | Mounting Box 3 gang anthracite - future linear | 1703-81 | 1 | sztuka |
| 2CKA001799A0916 | Mounting Box 3 gang ivory white - future linear | 1703-82 | 1 | sztuka |
| 2CKA001799A0917 | Mounting Box 3 gang aluminium silver - future linear | 1703-83 | 1 | sztuka |
| 2CKA001799A0955 | Mounting Box 3 gang studio white matt - future linear | 1703-884 | 1 | sztuka |
| 2CKA001799A0956 | Mounting Box 3 gang black matt - future linear | 1703-885 | 1 | sztuka |
| 2CKA001751A3122 | Mechanical Controls None for Switch/push button, Two-part rocker anthracite - 63x63 | 1785 K-81-500 | 1 | sztuka |
| 2CKA001751A3124 | Mechanical Controls None for Switch/push button, Two-part rocker ivory white - carat | 1785 K-82-500 | 1 | sztuka |
| 2CKA001751A3135 | Mechanical Controls None for Switch/push button, Two-part rocker studio white matt - 63x63 | 1785 K-884-500 | 1 | sztuka |
| 2CKA001751A3137 | Mechanical Controls None for Switch/push button, Two-part rocker black matt - 63x63 | 1785 K-885-500 | 1 | sztuka |

| | | | | |
|-----------------|--|---------------|---|--------|
| 2CKA001751A3215 | Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang grey metallic - 63x63 | 1785/11 K-803 | 1 | sztuka |
| 2CKA001751A3212 | Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang anthracite - 63x63 | 1785/11 K-81 | 1 | sztuka |
| 2CKA001751A3214 | Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang ivory white - 63x63 | 1785/11 K-82 | 1 | sztuka |
| 2CKA001751A3210 | Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang aluminium silver - 63x63 | 1785/11 K-83 | 1 | sztuka |
| 2CKA001751A3216 | Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang stainless steel - Pure Stainless Steel | 1785/11 K-866 | 1 | sztuka |
| 2CKA001751A3211 | Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang studio white matt - 63x63 | 1785/11 K-884 | 1 | sztuka |
| 2CKA001751A3213 | Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang black matt - 63x63 | 1785/11 K-885 | 1 | sztuka |
| 2CKA001751A3206 | Rocker DND for Switch/push button, Single rocker grey metallic - 63x63 | 1786/11-803 | 1 | sztuka |
| 2CKA001710A4133 | Cover plate with legend Symbol "card" for Card switch RFID Hotel card grey metallic - 63x63 | 1792 RFID-803 | 1 | sztuka |
| 2CKA001710A4130 | Cover plate with legend Card, Symbol "arrows" Hotel card anthracite - 63x63 | 1792 RFID-81 | 1 | sztuka |
| 2CKA001710A4132 | Cover plate with legend Card, Symbol "arrows" Hotel card ivory white - 63x63 | 1792 RFID-82 | 1 | sztuka |
| 2CKA001710A4128 | Cover plate with legend Card, Symbol "arrows" Hotel card aluminium silver - 63x63 | 1792 RFID-83 | 1 | sztuka |
| 2CKA001710A4134 | Cover plate with legend Card, Symbol "arrows" Hotel card stainless steel - Pure Stainless Steel | 1792 RFID-866 | 1 | sztuka |
| 2CKA001710A4129 | Cover plate with legend Card, Symbol "arrows" Hotel card studio white matt - 63x63 | 1792 RFID-884 | 1 | sztuka |
| 2CKA001710A4131 | Cover plate with legend Card, Symbol "arrows" Hotel card black matt - 63x63 | 1792 RFID-885 | 1 | sztuka |
| 2CKA001710A4198 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - 63x63 | 1794 R-81 | 1 | sztuka |
| 2CKA001710A4199 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button white - 63x63 | 1794 R-82 | 1 | sztuka |
| 2CKA001710A4200 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium - future linear | 1794 R-83 | 1 | sztuka |
| 2CKA001710A4203 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button stainless steel - Pure Stainless Steel | 1794 R-866 | 1 | sztuka |
| 2CKA001710A4204 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white matt - 63x63 | 1794 R-884 | 1 | sztuka |
| 2CKA001710A4205 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button black matt - 63x63 | 1794 R-885 | 1 | sztuka |
| 2CKA002011A6268 | Socket insert None Protective contact (SCHUKO) 20 EUCB2USB with USB AA anthracite - 63x63 | -81-500 | 1 | sztuka |
| 2CKA002011A6270 | Socket insert None Protective contact (SCHUKO) 20 EUCB2USB with USB AA ivory white - 63x63 | -82-500 | 1 | sztuka |
| 2CKA002011A6272 | Socket insert None Protective contact (SCHUKO) 20 EUCB2USB with USB AA aluminium silver - 63x63 | -83-500 | 1 | sztuka |
| 2CKA002011A6284 | Socket insert None Protective contact (SCHUKO) 20 EUCB2USB with USB AA stainless steel - Pure Stainless Steel | -866-500 | 1 | sztuka |
| 2CKA002011A6278 | Socket insert None Protective contact (SCHUKO) 20 EUCB2USB with USB AA studio white matt - 63x63 | -884-500 | 1 | sztuka |
| 2CKA002011A6280 | Socket insert None Protective contact (SCHUKO) 20 EUCB2USB with USB AA black matt - 63x63 | -885-500 | 1 | sztuka |
| 2CKA002018A1549 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid 20 EUKNBL-82 ivory white - 63x63 | | 1 | sztuka |

| | | | | |
|-----------------|--|------------------------|---|--------|
| 2CKA002018A1550 | SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid 20 aluminium silver - 63x63 | 20 EUKNBL-83 | 1 | sztuka |
| 2CKA002018A1555 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking grey metallic - 63x63 | 20 EUKNBSL-803 | 1 | sztuka |
| 2CKA002018A1556 | SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking grey metallic - 63x63 | 20 EUKNBSL-803-101 | 1 | sztuka |
| 2CKA002017A1892 | Socket with USB AA grey metallic - Busch-axcent | 20 MUCB2USB-803-500 | 1 | sztuka |
| 2CKA002017A1903 | Socket with USB AA anthracite - Busch-axcent | 20 MUCB2USB-81-500 | 1 | sztuka |
| 2CKA002017A1889 | Socket None Earthing pin with USB AA ivory white - 63x63 | 20 MUCB2USB-82-500 | 1 | sztuka |
| 2CKA002017A1890 | Socket None Earthing pin with USB AA aluminium silver - 63x63 | 20 MUCB2USB-83-500 | 1 | sztuka |
| 2CKA002017A1897 | Socket with USB AA stainless steel - Pure Stainless Steel | 20 MUCB2USB-866-500 | 1 | sztuka |
| 2CKA002017A1893 | Socket None Earthing pin with USB AA studio white matt - 63x63 | 20 MUCB2USB-884-500 | 1 | sztuka |
| 2CKA002017A1894 | Socket None Earthing pin with USB AA black matt - 63x63 | 20 MUCB2USB-885-500 | 1 | sztuka |
| 2CKA002017A0884 | Flush Mounted Inserts CSN-Norm 250 V | 2017-0-0884 | 1 | sztuka |
| 2CKA001751A3166 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO grey metallic - 63x63 | 2029 UC-803 | 1 | sztuka |
| 2CKA001751A3167 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO anthracite - 63x63 | 2029 UC-81 | 1 | sztuka |
| 2CKA001751A3168 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO ivory white - 63x63 | 2029 UC-82 | 1 | sztuka |
| 2CKA001751A3169 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO aluminium silver - 63x63 | 2029 UC-83 | 1 | sztuka |
| 2CKA001751A3171 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO stainless steel - Pure Stainless Steel | 2029 UC-866 | 1 | sztuka |
| 2CKA001751A3172 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO studio white matt - 63x63 | 2029 UC-884 | 1 | sztuka |
| 2CKA001751A3173 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO black matt - 63x63 | 2029 UC-885 | 1 | sztuka |
| 2CKA001751A3237 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, grey metallic - 63x63 | 2029/12 UC-803 | 1 | sztuka |
| 2CKA001751A3234 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 2029/12 UC-81 anthracite - 63x63 | 2029/12 UC-81 | 1 | sztuka |
| 2CKA001751A3236 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, ivory white - 63x63 | 2029/12 UC-82 | 1 | sztuka |
| 2CKA001751A3232 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 2029/12 UC-83 aluminium silver - 63x63 | 2029/12 UC-83 | 1 | sztuka |

| | | | | |
|-----------------|--|----------------|---|--------|
| 2CKA001751A3238 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, stainless steel - Pure Stainless Steel | 2029/12 UC-866 | 1 | sztuka |
| 2CKA001751A3233 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, studio white matt - 63x63 | 2029/12 UC-884 | 1 | sztuka |
| 2CKA001751A3235 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, black matt - 63x63 | 2029/12 UC-885 | 1 | sztuka |
| 2CKA001751A3226 | Rocker with legend DND, MUR for Switch/push button Two-part rocker grey metallic - solo | 2058-24-803 | 1 | sztuka |
| 2CKA001751A3223 | Rocker with legend DND, MUR for Switch/push button Two-part rocker anthracite - 63x63 | 2058-24-81 | 1 | sztuka |
| 2CKA001751A3225 | Rocker with legend DND, MUR for Switch/push button Two-part rocker ivory white - 63x63 | 2058-24-82 | 1 | sztuka |
| 2CKA001751A3221 | Rocker with legend DND, MUR for Switch/push button Two-part rocker aluminium silver - 63x63 | 2058-24-83 | 1 | sztuka |
| 2CKA001751A3227 | Rocker with legend DND, MUR for Switch/push button Two-part rocker stainless steel - Pure Stainless Steel | 2058-24-866 | 1 | sztuka |
| 2CKA001751A3222 | Rocker with legend DND, MUR for Switch/push button Two-part rocker studio white matt - 63x63 | 2058-24-884 | 1 | sztuka |
| 2CKA001751A3224 | Rocker with legend DND, MUR for Switch/push button Two-part rocker black matt - 63x63 | 2058-24-885 | 1 | sztuka |
| 2CKA001751A3246 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang grey metallic - solo | 2059 UC-803 | 1 | sztuka |
| 2CKA001751A3243 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang anthracite - 63x63 | 2059 UC-81 | 1 | sztuka |
| 2CKA001751A3245 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang ivory white - 63x63 | 2059 UC-82 | 1 | sztuka |
| 2CKA001751A3241 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang aluminium silver - 63x63 | 2059 UC-83 | 1 | sztuka |
| 2CKA001751A3247 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang stainless steel - Pure Stainless Steel | 2059 UC-866 | 1 | sztuka |
| 2CKA001751A3242 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang studio white matt - 63x63 | 2059 UC-884 | 1 | sztuka |
| 2CKA001751A3244 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang black matt - 63x63 | 2059 UC-885 | 1 | sztuka |
| 2CKA001761A1493 | Cable Entry anthracite - future linear | 2087-81 | 1 | sztuka |
| 2CKA001761A1494 | Cable Entry ivory white - future linear | 2087-82 | 1 | sztuka |
| 2CKA001761A1504 | Cable Entry aluminium silver - future linear | 2087-83 | 1 | sztuka |
| 2CKA001761A1498 | Cable Entry anthracite - future linear | 2088-81 | 1 | sztuka |
| 2CKA001761A1499 | Cable Entry ivory white - future linear | 2088-82 | 1 | sztuka |
| 2CKA001761A1505 | Cable Entry aluminium silver - future linear | 2088-83 | 1 | sztuka |
| 2CKA002495A0097 | Socket insert Equipotential compensation Socket outlet 2-position grey metallic - 63x63 | 2095 UC-803 | 1 | sztuka |
| 2CKA002013A5473 | SCHUKO® socket insert Without imprint Safety Shutter grey metallic - 63x63 | 23 EUCB-803 | 1 | sztuka |
| 2CKA001719A0216 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring grey metallic - 63x63 | 2518-WD-803 | 1 | sztuka |
| 2CKA001719A0217 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring anthracite - 63x63 | 2518-WD-81 | 1 | sztuka |

| | | | | |
|-----------------|--|-----------------|---|--------|
| 2CKA001719A0219 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring aluminium silver - 63x63 | 2518-WD-83 | 1 | sztuka |
| 2CKA001719A0221 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring stainless steel - Pure Stainless Steel | 2518-WD-866 | 1 | sztuka |
| 2CKA001719A0222 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring studio white matt - 63x63 | 2518-WD-884 | 1 | sztuka |
| 2CKA001719A0223 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring black matt - 63x63 | 2518-WD-885 | 1 | sztuka |
| 2CKA001751A3264 | Rocker for Switch/push button Single rocker grey metallic - solo | 2570-10-803 | 1 | sztuka |
| 2CKA001751A3261 | Rocker for Switch/push button Single rocker anthracite - 63x63 | 2570-10-81 | 1 | sztuka |
| 2CKA001751A3263 | Rocker for Switch/push button Single rocker ivory white - 63x63 | 2570-10-82 | 1 | sztuka |
| 2CKA001751A3259 | Rocker for Switch/push button Single rocker aluminium silver - 63x63 | 2570-10-83 | 1 | sztuka |
| 2CKA001751A3265 | Rocker for Switch/push button Single rocker stainless steel - Pure Stainless Steel | 2570-10-866 | 1 | sztuka |
| 2CKA001751A3260 | Rocker for Switch/push button Single rocker studio white matt - 63x63 | 2570-10-884 | 1 | sztuka |
| 2CKA001751A3262 | Rocker for Switch/push button Single rocker black matt - 63x63 | 2570-10-885 | 1 | sztuka |
| 2CKA001751A3275 | Rocker for Switch/push button Two-part rocker grey metallic | 2570-20-803 | 1 | sztuka |
| 2CKA001751A3272 | Rocker for Switch/push button Two-part rocker anthracite - 63x63 | 2570-20-81 | 1 | sztuka |
| 2CKA001751A3274 | Rocker for Switch/push button Two-part rocker ivory white - 63x63 | 2570-20-82 | 1 | sztuka |
| 2CKA001751A3270 | Rocker for Switch/push button Two-part rocker aluminium silver - 63x63 | 2570-20-83 | 1 | sztuka |
| 2CKA001751A3276 | Rocker for Switch/push button Two-part rocker stainless steel - Pure Stainless Steel | 2570-20-866 | 1 | sztuka |
| 2CKA001751A3271 | Rocker for Switch/push button Two-part rocker studio white matt - 63x63 | 2570-20-884 | 1 | sztuka |
| 2CKA001751A3273 | Rocker for Switch/push button Two-part rocker black matt - 63x63 | 2570-20-885 | 1 | sztuka |
| 2CKA001751A3286 | Rocker for Switch/push button Three-part rocker grey metallic - solo | 2570-30-803 | 1 | sztuka |
| 2CKA001751A3283 | Rocker for Switch/push button Three-part rocker anthracite - 63x63 | 2570-30-81 | 1 | sztuka |
| 2CKA001751A3285 | Rocker for Switch/push button Three-part rocker ivory white - 63x63 | 2570-30-82 | 1 | sztuka |
| 2CKA001751A3281 | Rocker for Switch/push button Three-part rocker aluminium silver - 63x63 | 2570-30-83 | 1 | sztuka |
| 2CKA001751A3287 | Rocker for Switch/push button Three-part rocker stainless steel - Pure Stainless Steel | 2570-30-866 | 1 | sztuka |
| 2CKA001751A3282 | Rocker for Switch/push button Three-part rocker studio white matt - 63x63 | 2570-30-884 | 1 | sztuka |
| 2CKA001751A3284 | Rocker for Switch/push button Three-part rocker black matt - 63x63 | 2570-30-885 | 1 | sztuka |
| 2CKA006132A0256 | 6122/01-815 Watchdog 180 Standard FM | 6122/01-815 | 1 | sztuka |
| 2CKA006132A0280 | 6122/01-815-500 Watchdog 180 Standard FM | 6122/01-815-500 | 1 | sztuka |
| 2CKA006132A0290 | Solo Horizontal 0 ... 180 ° grey metallic | 6122/02-803-500 | 1 | sztuka |
| 2CKA006132A0269 | 6122/02-815 Watchdog 180 comfort FM | 6122/02-815 | 1 | sztuka |
| 2CKA006132A0283 | Solo Horizontal 0 ... 180 ° anthracite | 6122/02-81-500 | 1 | sztuka |

| | | | | |
|-----------------|---|-----------------|---|--------|
| 2CKA006132A0291 | 6122/02-815-500 Watchdog 180 comfort FM | 6122/02-815-500 | 1 | sztuka |
| 2CKA006132A0284 | Solo Horizontal 0 ... 180 ° ivory white | 6122/02-82-500 | 1 | sztuka |
| 2CKA006132A0285 | Solo Horizontal 0 ... 180 ° aluminium silver | 6122/02-83-500 | 1 | sztuka |
| 2CKA006132A0289 | Solo Horizontal 0 ... 180 ° stainless steel | 6122/02-866-500 | 1 | sztuka |
| 2CKA006132A0292 | Solo Horizontal 0 ... 180 ° studio white matt | 6122/02-884-500 | 1 | sztuka |
| 2CKA006132A0293 | Solo Horizontal 0 ... 180 ° black matt | 6122/02-885-500 | 1 | sztuka |
| 2CKA006132A0371 | 6122/10-896 BW standard | 6122/10-896 | 1 | sztuka |
| 2CKA006134A0253 | 6124/01-803 Room Thermostat | 6124/01-803 | 1 | sztuka |
| 2CKA006134A0280 | 6124/01-803-500 Room Thermostat | 6124/01-803-500 | 1 | sztuka |
| 2CKA006134A0244 | 6124/01-81 Room Thermostat | 6124/01-81 | 1 | sztuka |
| 2CKA006134A0254 | 6124/01-815 Room Thermostat | 6124/01-815 | 1 | sztuka |
| 2CKA006134A0295 | 6124/01-81-500 Room Thermostat | 6124/01-81-500 | 1 | sztuka |
| 2CKA006134A0281 | 6124/01-815-500 Room Thermostat | 6124/01-815-500 | 1 | sztuka |
| 2CKA006134A0245 | 6124/01-82 Room Thermostat | 6124/01-82 | 1 | sztuka |
| 2CKA006134A0274 | 6124/01-82-500 Room Thermostat | 6124/01-82-500 | 1 | sztuka |
| 2CKA006134A0275 | 6124/01-83-500 Room Thermostat | 6124/01-83-500 | 1 | sztuka |
| 2CKA006134A0279 | 6124/01-866-500 Room Thermostat | 6124/01-866-500 | 1 | sztuka |
| 2CKA006134A0255 | 6124/01-884 Room Thermostat | 6124/01-884 | 1 | sztuka |
| 2CKA006134A0256 | 6124/01-885 Room Thermostat | 6124/01-885 | 1 | sztuka |
| 2CKA006134A0283 | 6124/01-885-500 Room Thermostat | 6124/01-885-500 | 1 | sztuka |
| 2CKA006134A0303 | 6124/01-896 Room Thermostat | 6124/01-896 | 1 | sztuka |
| 2CKA006134A0304 | 6124/01-896-500 Room Thermostat | 6124/01-896-500 | 1 | sztuka |
| 2CKA006134A0221 | 6124-83-101 Room Thermostat with Display | 6124-83-101 | 1 | sztuka |
| 2CKA006134A0229 | 6124-866-101 Room Thermostat with Display | 6124-866-101 | 1 | sztuka |
| 2CKA006134A0226 | 6124-87-101 Room Thermostat with Display | 6124-87-101 | 1 | sztuka |
| 2CKA006134A0291 | 6128/01-803-500 RTC Control element 2/4g | 6128/01-803-500 | 1 | sztuka |
| 2CKA006134A0257 | 6128/01-81 RTC Control element 2/4g | 6128/01-81 | 1 | sztuka |
| 2CKA006134A0267 | 6128/01-815 RTC Control element 2/4g | 6128/01-815 | 1 | sztuka |
| 2CKA006134A0284 | 6128/01-81-500 RTC Control element 2/4g | 6128/01-81-500 | 1 | sztuka |
| 2CKA006134A0292 | 6128/01-815-500 RTC Control element 2/4g | 6128/01-815-500 | 1 | sztuka |
| 2CKA006134A0258 | 6128/01-82 RTC Control element 2/4g | 6128/01-82 | 1 | sztuka |
| 2CKA006134A0286 | 6128/01-83-500 RTC Control element 2/4g | 6128/01-83-500 | 1 | sztuka |
| 2CKA006134A0293 | 6128/01-884-500 RTC Control element 2/4g | 6128/01-884-500 | 1 | sztuka |
| 2CKA006134A0269 | 6128/01-885 RTC Control element 2/4g | 6128/01-885 | 1 | sztuka |
| 2CKA006134A0294 | 6128/01-885-500 RTC Control element 2/4g | 6128/01-885-500 | 1 | sztuka |
| 2CKA006134A0305 | 6128/01-896 RTC Control element 2/4g | 6128/01-896 | 1 | sztuka |

| | | | | |
|-----------------|---|------------------|---|--------|
| 2CKA006134A0306 | 6128/01-896-500 RTC Control element 2/4g | 6128/01-896-500 | 1 | sztuka |
| 2CKA006134A0208 | 6128-81-101 RoomThermostat/Switch Sensor | 6128-81-101 | 1 | sztuka |
| 2CKA006134A0209 | 6128-82-101 RoomThermostat/Switch Sensor | 6128-82-101 | 1 | sztuka |
| 2CKA006134A0218 | 6128-866-101 RoomThermostat/Switch Sensor | 6128-866-101 | 1 | sztuka |
| 2CKA006135A0152 | 6129/01-815 Control element 3/6g w. IR | 6129/01-815 | 1 | sztuka |
| 2CKA006135A0164 | 6129/01-815-500 Control element 3/6g w. IR | 6129/01-815-500 | 1 | sztuka |
| 2CKA006135A0169 | 6129/01-896 Control element 3/6g w. IR | 6129/01-896 | 1 | sztuka |
| 2CKA006220A0479 | 6215/1.1-896 Mov. detector/actuator 1g | 6215/1.1-896 | 1 | sztuka |
| 2CKA006220A0478 | 6225/1.0-896 Movement detector | 6225/1.0-896 | 1 | sztuka |
| 2CKA006200A0166 | 62762-81-WL-500 WD 180 flex comf. sens. WL | 62762-81-WL-500 | 1 | sztuka |
| 2CKA006200A0178 | 62762-885-WL-500 WD 180 flex comf. sens. WL | 62762-885-WL-500 | 1 | sztuka |
| 2CKA006800A2929 | Busch-Watchdog Electronic Controls Movement sensor grey metallic - 63x63 | 64761-803-500 | 1 | sztuka |
| 2CKA006800A2921 | Busch-Watchdog Electronic Controls Movement sensor anthracite - 63x63 | 64761-81-500 | 1 | sztuka |
| 2CKA006800A2923 | Busch-Watchdog Electronic Controls Movement sensor ivory white - 63x63 | 64761-82-500 | 1 | sztuka |
| 2CKA006800A2925 | Busch-Watchdog Electronic Controls Movement sensor aluminium silver - 63x63 | 64761-83-500 | 1 | sztuka |
| 2CKA006800A2936 | Busch-Watchdog Electronic Controls Movement sensor stainless steel - Pure Stainless Steel | 64761-866-500 | 1 | sztuka |
| 2CKA006800A2931 | Busch-Watchdog Electronic Controls Movement sensor studio white matt - 63x63 | 64761-884-500 | 1 | sztuka |
| 2CKA006800A2933 | Electronic Controls Movement sensor black matt - 63x63 | 64761-885-500 | 1 | sztuka |
| 2CKA006800A2966 | Busch-Watchdog Cover plate Movement sensor grey metallic - 63x63 | 64762-803-500 | 1 | sztuka |
| 2CKA006800A2958 | Busch-Watchdog Cover plate Movement sensor anthracite - 63x63 | 64762-81-500 | 1 | sztuka |
| 2CKA006800A2960 | 64762-82-500 WD 180 flex comfort sensor | 64762-82-500 | 1 | sztuka |
| 2CKA006800A2962 | Busch-Watchdog Cover plate Movement sensor aluminium silver - 63x63 | 64762-83-500 | 1 | sztuka |
| 2CKA006800A2973 | Busch-Watchdog Cover plate Movement sensor stainless steel - Pure Stainless Steel | 64762-866-500 | 1 | sztuka |
| 2CKA006800A2968 | Busch-Watchdog Cover plate Movement sensor studio white matt - 63x63 | 64762-884-500 | 1 | sztuka |
| 2CKA006800A2970 | Busch-Watchdog Cover plate Movement sensor black matt - 63x63 | 64762-885-500 | 1 | sztuka |
| 2CKA006800A3003 | Electronic Controls Movement sensor grey metallic - 63x63 | 64764-803-500 | 1 | sztuka |
| 2CKA006800A2995 | Electronic Controls Movement sensor anthracite - 63x63 | 64764-81-500 | 1 | sztuka |
| 2CKA006800A2999 | Electronic Controls Movement sensor aluminium silver - 63x63 | 64764-83-500 | 1 | sztuka |
| 2CKA006800A3005 | Electronic Controls Movement sensor studio white matt - 63x63 | 64764-884-500 | 1 | sztuka |
| 2CKA006800A3007 | Electronic Controls Movement sensor black matt - 63x63 | 64764-885-500 | 1 | sztuka |
| 2CKA006800A2883 | Electronic Controls Movement sensor anthracite - 63x63 | 64765-81-500 | 1 | sztuka |
| 2CKA006800A2885 | 64765-82-500 Comfort switch flex sensor | 64765-82-500 | 1 | sztuka |
| 2CKA006800A2887 | Electronic Controls Movement sensor aluminium silver - 63x63 | 64765-83-500 | 1 | sztuka |
| 2CKA006800A2893 | Electronic Controls Movement sensor studio white matt - 63x63 | 64765-884-500 | 1 | sztuka |

| | | | | |
|-----------------|---|--------------------|---|--------|
| 2CKA006800A2895 | Electronic Controls Movement sensor black matt - 63x63 | 64765-885-500 | 1 | sztuka |
| 2CKA006710A0015 | Control element insert Smart switch 4 chan. Bluetooth white - 63x63 | 6716 UBT | 1 | sztuka |
| 2CKA006730A0155 | Smart switch set 4 channel Bluetooth black matt - future linear | 6716/01 UJ-885 | 1 | sztuka |
| 2CKA006730A0157 | Kits 4 channel Bluetooth black matt - future linear | 6716/01 UJ-885-500 | 1 | sztuka |
| 2CKA006730A0159 | Kits 4 channel Bluetooth black matt - future linear | 6716/01 UJ-885-510 | 1 | sztuka |
| 2CKA006730A0142 | Rocker None for Dimmer Single rocker anthracite - 63x63 | 6735 BT-81 | 1 | sztuka |
| 2CKA006730A0143 | Rocker None for Dimmer Single rocker beige - 63x63 | 6735 BT-82 | 1 | sztuka |
| 2CKA006730A0144 | Rocker None for Dimmer Single rocker aluminium - 63x63 | 6735 BT-83 | 1 | sztuka |
| 2CKA006730A0148 | Rocker None for Dimmer Single rocker stainless steel - Pure Stainless Steel | 6735 BT-866 | 1 | sztuka |
| 2CKA006730A0149 | Rocker None for Dimmer Single rocker studio white matt - 63x63 | 6735 BT-884 | 1 | sztuka |
| 2CKA006730A0150 | Rocker None for Dimmer Single rocker black matt - 63x63 | 6735 BT-885 | 1 | sztuka |
| 2CKA006730A0117 | Wall sensor for ZigBee Light Link 1 channel 1gang Radio Control grey metallic - 63x63 | 6735/01-803 | 1 | sztuka |
| 2CKA006730A0079 | Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control anthracite - 63x63 | 6735/01-81 | 1 | sztuka |
| 2CKA006730A0080 | Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control ivory white - 63x63 | 6735/01-82 | 1 | sztuka |
| 2CKA006730A0081 | Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control aluminium silver - 63x63 | 6735/01-83 | 1 | sztuka |
| 2CKA006730A0116 | Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control stainless steel - Pure Stainless Steel | 6735/01-866 | 1 | sztuka |
| 2CKA006730A0118 | Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control studio white matt - 63x63 | 6735/01-884 | 1 | sztuka |
| 2CKA006730A0119 | Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control black matt - 63x63 | 6735/01-885 | 1 | sztuka |
| 2CKA006730A0099 | Control Element for Switch/dimmer 1gang Radio Control grey metallic - 63x63 | 6735-803 | 1 | sztuka |
| 2CKA006730A0067 | Control Element for Switch/dimmer 1gang Radio Control anthracite - 63x63 | 6735-81 | 1 | sztuka |
| 2CKA006730A0068 | Control Element for Switch/dimmer 1gang Radio Control ivory white - 63x63 | 6735-82 | 1 | sztuka |
| 2CKA006730A0069 | Control Element for Switch/dimmer 1gang Radio Control aluminium silver - 63x63 | 6735-83 | 1 | sztuka |
| 2CKA006730A0098 | Control Element for Switch/dimmer 1gang Radio Control stainless steel - Pure Stainless Steel | 6735-866 | 1 | sztuka |
| 2CKA006730A0100 | Control Element for Switch/dimmer 1gang Radio Control studio white matt - 63x63 | 6735-884 | 1 | sztuka |
| 2CKA006730A0101 | Control Element for Switch/dimmer 1gang Radio Control black matt - 63x63 | 6735-885 | 1 | sztuka |
| 2CKA006730A0137 | Control Element None for Dimmer Two-part button grey metallic - 63x63 | 6736 FoH-803 | 1 | sztuka |
| 2CKA006730A0133 | Control Element None for Dimmer Two-part button anthracite - 63x63 | 6736 FoH-81 | 1 | sztuka |
| 2CKA006730A0135 | Control Element None for Dimmer Two-part button aluminium - 63x63 | 6736 FoH-83 | 1 | sztuka |

| | | | | |
|-----------------|---|--------------|---|--------|
| 2CKA006730A0139 | Control Element None for Dimmer Two-part button stainless steel - Pure Stainless Steel | 6736 FoH-866 | 1 | sztuka |
| 2CKA006730A0140 | Control Element None for Dimmer Two-part button studio white matt - 63x63 | 6736 FoH-884 | 1 | sztuka |
| 2CKA006730A0121 | Wall sensor 2 channel 2gang Radio Control grey metallic - 63x63 | 6736/01-803 | 1 | sztuka |
| 2CKA006730A0083 | Wall sensor 2 channel 2gang Radio Control anthracite - 63x63 | 6736/01-81 | 1 | sztuka |
| 2CKA006730A0084 | Wall sensor 2 channel 2gang Radio Control ivory white - 63x63 | 6736/01-82 | 1 | sztuka |
| 2CKA006730A0085 | Wall sensor 2 channel 2gang Radio Control aluminium silver - 63x63 | 6736/01-83 | 1 | sztuka |
| 2CKA006730A0122 | Wall sensor 2 channel 2gang Radio Control stainless steel - Pure Stainless Steel | 6736/01-866 | 1 | sztuka |
| 2CKA006730A0124 | Wall sensor 2 channel 2gang Radio Control studio white matt - 63x63 | 6736/01-884 | 1 | sztuka |
| 2CKA006730A0125 | Wall sensor 2 channel 2gang Radio Control black matt - 63x63 | 6736/01-885 | 1 | sztuka |
| 2CKA006730A0105 | Control Element for Switch/dimmer 2gang Radio Control grey metallic - 63x63 | 6736-803 | 1 | sztuka |
| 2CKA006730A0071 | Control Element for Switch/dimmer 2gang Radio Control anthracite - 63x63 | 6736-81 | 1 | sztuka |
| 2CKA006730A0072 | Control Element for Switch/dimmer 2gang Radio Control ivory white - 63x63 | 6736-82 | 1 | sztuka |
| 2CKA006730A0073 | Control Element for Switch/dimmer 2gang Radio Control aluminium silver - 63x63 | 6736-83 | 1 | sztuka |
| 2CKA006730A0104 | Control Element for Switch/dimmer 2gang Radio Control stainless steel - Pure Stainless Steel | 6736-866 | 1 | sztuka |
| 2CKA006730A0106 | Control Element for Switch/dimmer 2gang Radio Control studio white matt - 63x63 | 6736-884 | 1 | sztuka |
| 2CKA006730A0107 | Control Element for Switch/dimmer 2gang Radio Control black matt - 63x63 | 6736-885 | 1 | sztuka |
| 2CKA006730A0127 | Wall sensor for ZigBee Light Link 4 channel 4gang Radio Control grey metallic - 63x63 | 6737/01-803 | 1 | sztuka |
| 2CKA006730A0087 | Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control anthracite - 63x63 | 6737/01-81 | 1 | sztuka |
| 2CKA006730A0088 | Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control ivory white - 63x63 | 6737/01-82 | 1 | sztuka |
| 2CKA006730A0089 | Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control aluminium silver - 63x63 | 6737/01-83 | 1 | sztuka |
| 2CKA006730A0128 | Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control stainless steel - Pure Stainless Steel | 6737/01-866 | 1 | sztuka |
| 2CKA006730A0130 | Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control studio white matt - 63x63 | 6737/01-884 | 1 | sztuka |
| 2CKA006730A0131 | Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control black matt - 63x63 | 6737/01-885 | 1 | sztuka |
| 2CKA006730A0111 | Control Element for Switch/dimmer 4gang Radio Control grey metallic - 63x63 | 6737-803 | 1 | sztuka |
| 2CKA006730A0075 | Control Element for Switch/dimmer 4gang Radio Control anthracite - 63x63 | 6737-81 | 1 | sztuka |
| 2CKA006730A0076 | Control Element for Switch/dimmer 4gang Radio Control ivory white - 63x63 | 6737-82 | 1 | sztuka |
| 2CKA006730A0077 | Control Element for Switch/dimmer 4gang Radio Control aluminium silver - 63x63 | 6737-83 | 1 | sztuka |
| 2CKA006730A0110 | Control Element for Switch/dimmer 4gang Radio Control stainless steel - Pure Stainless Steel | 6737-866 | 1 | sztuka |

| | | | | |
|-----------------|--|----------------------|---|--------|
| 2CKA006730A0112 | Control Element for Switch/dimmer 4gang Radio Control studio white matt - 63x63 | 6737-884 | 1 | sztuka |
| 2CKA006730A0113 | Control Element for Switch/dimmer 4gang Radio Control black matt - 63x63 | 6737-885 | 1 | sztuka |
| 2CKA006800A2325 | Electronic Controls aluminium silver - 63x63 | 6800-83-104 | 1 | sztuka |
| 2CKA006800A2327 | 6800-83-104M Watchdog Comfort Sensor 180 | 6800-83-104M | 1 | sztuka |
| 2CKA006800A2343 | Electronic Controls stainless steel - Pure Stainless Steel | 6800-866-104 | 1 | sztuka |
| 2CKA006800A2506 | 6800-885-104 Watchdog Comfort Sensor 180 | 6800-885-104 | 1 | sztuka |
| 2CKA008200A0257 | Cover plate with legend Radio 0 gang grey metallic - 63x63 | 8252-803-101- 500 | 1 | sztuka |
| 2CKA008200A0249 | Cover plate with legend Radio 0 gang anthracite - 63x63 | 8252-81-101- 500 | 1 | sztuka |
| 2CKA008200A0251 | Cover plate with legend Radio 0 gang ivory white - 63x63 | 8252-82-101- 500 | 1 | sztuka |
| 2CKA008200A0259 | Cover plate with legend Radio 0 gang studio white matt - 63x63 | 8252-884-101- 500 | 1 | sztuka |
| 2CKA008200A0230 | Cover plate Multimedia 3 gang grey metallic - solo | 8256-803 | 1 | sztuka |
| 2CKA008200A0227 | Cover plate Multimedia 3 gang anthracite - 63x63 | 8256-81 | 1 | sztuka |
| 2CKA008200A0229 | Cover plate Multimedia 3 gang ivory white - 63x63 | 8256-82 | 1 | sztuka |
| 2CKA008200A0225 | Cover plate Multimedia 3 gang aluminium silver - 63x63 | 8256-83 | 1 | sztuka |
| 2CKA008200A0231 | Cover plate Multimedia 3 gang stainless steel - Pure Stainless Steel | 8256-866 | 1 | sztuka |
| 2CKA008200A0226 | Cover plate Multimedia 3 gang studio white matt - 63x63 | 8256-884 | 1 | sztuka |
| 2CKA008200A0228 | Cover plate Multimedia 3 gang black matt - 63x63 | 8256-885 | 1 | sztuka |

Kategorie

Produkty niskiego napięcia i systemy → Wiring Accessories - Light Switch Ranges → Frames

