

Opis produktu

1722-832-500

Cover frame 2gang ivory white - Busch-Dynasty



Ogólne informacje

Typ produktu	1722-832-500
Kod zamówieniowy	2CKA001754A4601
Oznaczenie typu ABB	Cover Frame 2gang xxx - Busch-Dynasty
Numer EAN	4011395195284
Opis katalogowy	Cover frame 2gang ivory white - Busch-Dynasty
Opis	For vertical or horizontal installation.

Installation

Instrukcje i podręczniki	No document needed
Typ montażu	Flush Mounted
Rodzaj mocowania	Clamp
Orientacja montażu	Horizontal Vertical

Dane techniczne

Arkusze danych, informacje techniczne	No document needed
Liczba	2

Design

Design Range	Busch-Dynasty 63x63
Wykończenie pokrywy	Untreated Glossy
Materiał	Thermoplastic
Zapewnione miejsce na etykiety	No
Kolor RAL	RAL 1013 - Oyster White
Kolor	ivory white

Material Compliance

Dane RoHS	2CKA200000E2922
Status RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Deklaracja REACH	2CKA309999E9999
REACH Information	False - does not contains substances > 0.1 mass percentage
Szablon raportowania CMRT	9AKK108468A3363

Normy środowiskowe

Stopień ochrony	IP20
-----------------	------

Wymiary

Szerokość netto	106 mm
Wysokość netto	177 mm
Głębokość / długość netto	12 mm
Masa netto	56 g

Certyfikaty i deklaracje (Numer dokumentu)

Deklaracja zgodności UE	No declaration needed
-------------------------	-----------------------

Klasyfikacje

ETIM 9	EC000007 - Cover frame for domestic switching devices
eClass	V11.0 : 27144001
Kategoria WEEE	Product Not in WEEE Scope

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA001582A0346	Cover plate with labelling field Busch-Infoline® Single push button studio white - 63x63	1571 CN-84	1	sztuka
2CKA001582A0348	Cover plate with labelling field Busch-Infoline® Single push button Przeźroczysty studio white - 63x63	1572 CN-84	1	sztuka
2CKA001582A0350	Cover plate with labelling field Busch-Infoline® Central cover plate studio white - 63x63	1573 CN-84	1	sztuka
2CKA001582A0353	Cover plate with labelling field Busch-Infoline® Central cover plate studio white - 63x63	1575 CN-84	1	sztuka
2CKA001582A0355	Cover plate with labelling field Busch-Infoline® Central cover plate studio white - 63x63	1576 CN-84	1	sztuka
2CKA001731A1923	Cover Busch-Infolicht® studio white - 63x63	1716-84	1	sztuka
2CKA001731A1916	Rocker None for Pull-cord switch, Pull cord studio white - 63x63	1720-84	1	sztuka
2CKA001710A3808	Cover plate with legend Level switch Turn button studio white - 63x63	1740 DR/03-84	1	sztuka
2CKA001710A3512	Cover plate Symbol "2-1-3" for Level switch, Turn button studio white - 63x63	1740 DRL-84- 503	1	sztuka
2CKA001710A3172	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button studio white - 63x63	1740-84	1	sztuka
2CKA001710A3161	Cover plate Blind cap 1 gang with Mounting plate studio white - 63x63	1742-84	1	sztuka
2CKA001710A3991	Cable Outlet / Blank Plate / Adapter Ring Blind cap 0 gang studio white - 63x63	1742-84-500	1	sztuka
2CKA001724A4368	Cover plate SAT 4 gang studio white - 63x63	1743/10-04-84	1	sztuka
2CKA001724A4377	Cover plate TV / Radio / 2x SAT 4 gang studio white - 63x63	1743-04-84	1	sztuka
2CKA001724A4332	Data / Telecommunication / Antenna SAT 3 gang studio white - 63x63	1743-84-500	1	sztuka
2CKA001710A3173	Cover plate Busch-Infoline® telephone connector boxes (VDo) Central cover plate studio white - 63x63	1745-84	1	sztuka
2CKA001710A3993	Data / Telecommunication / Antenna Telecommunication inserts 0 gang studio white - 63x63	1746/10-84- 500	1	sztuka
2CKA001710A3167	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang studio white - 63x63	1746-84	1	sztuka
2CKA001710A4096	Intermediate Ring for cover plates Busch- Balance® SI studio white - 63x63	1747 BSI-84	1	sztuka
2CKA001710A3863	Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI studio white - 63x63	1747 SI-84	1	sztuka
2CKA001710A3861	Intermediate Ring studio white - 63x63	1747-84	1	sztuka
2CKA001710A3163	Cover plate Cable outlet studio white - 63x63	1749-84	1	sztuka
2CKA001723A0240	Cover plate Loudspeaker 2 gang studio white - 63x63	1751-84	1	sztuka
2CKA001710A3175	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key studio white - 63x63	1755 SL/PZ-84 -101	1	sztuka

2CKA001724A2761	Cover plate with labelling field For data connection housing 2 gang studio white - 63x63	1758-84	1	sztuka
2CKA001731A1877	Rocker with labelling field for Switch/push button, Single push button with Pilot lamp studio white - 63x63	1764 NLI-84	1	sztuka
2CKA001710A3992	Data / Telecommunication / Antenna TAE 0 gang studio white - 63x63	1766-84-500	1	sztuka
2CKA001753A0258	Cover plate with legend 1 ... 15 Min for Time switch, Toggle studio white - 63x63	1770-84-103	1	sztuka
2CKA001753A0301	Cover plate with legend 10 ... 120 Min for Time switch, Toggle studio white - 63x63	1771-84-103	1	sztuka
2CKA001751A2980	Multimedia Devices studio white	1785 ENO-84	1	sztuka
2CKA001751A3099	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white - 63x63	1785 JA/02-84	1	sztuka
2CKA001751A3088	Mechanical Controls Symbol "arrows" for Venetian blind, Two-part rocker studio white - 63x63	1785 JA-84-500	1	sztuka
2CKA001751A3128	Mechanical Controls None for Switch/push button, Two-part rocker studio white - 63x63	1785 K-84-500	1	sztuka
2CKA001751A2992	Rocker with legend DND, MUR for Switch/push button, Two-part rocker studio white - 63x63	1785/11-84	1	sztuka
2CKA001751A3076	Mechanical Controls Without imprint for Switch/push button, Two-part rocker studio white - 63x63	1785-84-500	1	sztuka
2CKA001751A2968	Multimedia Devices studio white	1786 ENO-84	1	sztuka
2CKA001751A3098	Rocker with legend Symbol "arrows" for Venetian blind, Single rocker studio white - 63x63	1786 JA/02-84	1	sztuka
2CKA001751A2998	Rocker with legend DND for Switch/push button, Single rocker studio white - 63x63	1786/11-84	1	sztuka
2CKA001751A3074	Mechanical Controls Without imprint for Switch/push button, Single rocker studio white - 63x63	1786-84-500	1	sztuka
2CKA001751A2750	Rocker None for Switch/push button, Single rocker studio white - 63x63	1788-84	1	sztuka
2CKA001751A2751	Rocker with legend Heizung for Switch/push button, Single rocker studio white - 63x63	1789 H-84	1	sztuka
2CKA001751A2754	Rocker with legend Symbol "bell" for Switch/push button, Single rocker studio white - 63x63	1789 KI-84	1	sztuka
2CKA001751A3084	Mechanical Controls Symbol "light" for Switch/push button, Single rocker studio white - 63x63	1789 LI-84-500	1	sztuka
2CKA001751A3151	Mechanical Controls for Switch/push button, Single rocker studio white - 63x63	1789 N-84-500	1	sztuka
2CKA001751A3161	Mechanical Controls Various symbols for Switch/push button, Single rocker studio white - 63x63	1789 ST-84-500	1	sztuka
2CKA001751A2755	Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white - 63x63	1789 TR-84	1	sztuka
2CKA001751A3091	Mechanical Controls Without imprint for Switch/push button, Single rocker studio white - 63x63	1789-84-500	1	sztuka
2CKA001710A4111	Cover plate studio white - 63x63	1790-590-84	1	sztuka
2CKA001710A4112	Cover plate studio white - 63x63	1790-591-84	1	sztuka
2CKA001710A4113	Cover plate studio white - 63x63	1790-592-84	1	sztuka

2CKA001710A4114	Cover plate studio white - 63x63	1790-593-84	1	sztuka
2CKA001710A4115	Cover plate studio white - 63x63	1790-594-84	1	sztuka
2CKA001710A4116	Cover plate studio white - 63x63	1790-595-84	1	sztuka
2CKA001710A3698	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white - 63x63	1794 TA-84	1	sztuka
2CKA001710A4017	Cover plate Various symbols for Thermostat Turn button studio white - 63x63	1795 HK-84	1	sztuka
2CKA001710A4049	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white - 63x63	1795 HKEA-84	1	sztuka
2CKA001710A3725	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white - 63x63	1795 TA-84	1	sztuka
2CKA001710A3569	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white - 63x63	1795-84	1	sztuka
2CKA001753A0311	Cover plate for Pull-cord switch, Pull cord studio white - 63x63	1796-84	1	sztuka
2CKA001710A3990	Data / Telecommunication / Antenna Modular Jack 2 gang studio white - 63x63	1800-84-500	1	sztuka
2CKA001710A1551	Data / Telecommunication / Antenna UAE/IAE (ISDN) 2 gang studio white - 63x63	1803-02-84- 500	1	sztuka
2CKA001710A1550	Data / Telecommunication / Antenna UAE/IAE (ISDN) 1 gang studio white - 63x63	1803-84-500	1	sztuka
2CKA002013A5407	Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter studio white - 63x63	20 EUAB-84	1	sztuka
2CKA002011A6207	Socket Outlets Without imprint studio white - 63x63	20 EUC-84- 500	1	sztuka
2CKA002013A5418	Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter studio white - 63x63	20 EUCBDR- 84	1	sztuka
2CKA002013A5467	SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green green - 63x63	20 EUCBL-13- 84-101	1	sztuka
2CKA002013A5288	SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green orange - 63x63	20 EUCBL-14- 84	1	sztuka
2CKA002013A5286	SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green studio white - 63x63	20 EUCBL-84	1	sztuka
2CKA002013A5294	Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White studio white - 63x63	20 EUCBLI-84	1	sztuka
2CKA002013A5268	SCHUKO® Socket insert with legend EDV Safety Shutter studio white - 63x63	20 EUCKS/DV- 84	1	sztuka
2CKA002013A5372	Socket insert Without imprint Safety Shutter Protective contact (SCHUKO) studio white - 63x63	20 EUCKS-84- 500	1	sztuka
2CKA002013A5441	20 EUCRB-84-500 Socket Outlet	20 EUCRB-84- 500	1	sztuka
2CKA002018A1509	Socket Outlets Without imprint with Hinged Lid, studio white - 63x63	20 EUK-84-500	1	sztuka

2CKA002018A1520	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid studio white - 63x63	20 EUKB-84	1	sztuka
2CKA002018A1529	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid studio white - 63x63	20 EUKBR-84	1	sztuka
2CKA002018A1540	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid studio white - 63x63	20 EUKNB-84	1	sztuka
2CKA002018A1551	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid studio white - 63x63	20 EUKNBL-84	1	sztuka
2CKA002018A1563	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking studio white - 63x63	20 EUKNBSL-84	1	sztuka
2CKA002018A1564	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking studio white - 63x63	20 EUKNBSL-84-101	1	sztuka
2CKA002011A6209	Socket Outlets Without imprint studio white - 63x63	20 EUN-84-500	1	sztuka
2CKA001510A0005	Cover Busch-iceLight Reflector Ambient / orientation lightning / White studio white - 63x63	2068/11-84	1	sztuka
2CKA001510A0008	Cover Busch-iceLight Reflector Ambient / orientation lightning, Infolight studio white - 63x63	2068/14-84	1	sztuka
2CKA001510A0017	Cover Busch-iceLight Ambient lightning studio white - 63x63	2068/22-84	1	sztuka
2CKA001510A0015	Busch-iceLight set with Night light; LED studio white - future linear	2069/11-84	1	sztuka
2CKA002495A0086	Equipotential socket insert Socket outlet 2-position studio white - 63x63	2095 UC-84	1	sztuka
2CKA002190A0215	2190 EUC-84 Socket Outl. S/F 1g	2190 EUC-84	1	sztuka
2CKA002013A5477	SCHUKO® socket insert Without imprint Safety Shutter studio white - 63x63	23 EUCB-84	1	sztuka
2CKA002013A5451	SCHUKO® socket insert Without imprint Safety Shutter studio white - 63x63	2300 EUCB-84	1	sztuka
2CKA002113A0511	2300 UCRKS-84-503 Socket Outl. S	2300 UCRKS-84-503	1	sztuka
2CKA002011A3833	Busch-Protector® SCHUKO® socket insert Without imprint studio white - 63x63	2310 EUGL/VA-84-11	1	sztuka
2CKA002099A0198	2397 UCKS-84-505 Center PI, SF for 2300	2397 UCKS-84-505	1	sztuka
2CKA002013A5361	2398 CKS-84 Cover plate shuttered	2398 CKS-84	1	sztuka
2CKA002099A0214	Socket insert Without imprint Safety Shutter Earthing pin studio white - 63x63	2399 UCKS-84	1	sztuka
2CKA002099A0192	2399 UCKS-84-505 Center PI, SF for 23M	2399 UCKS-84-505	1	sztuka
2CKA001751A3180	Electronic Controls Symbol "bell" for Switch/push button Single rocker studio white - 63x63	2520 KI-84-500	1	sztuka
2CKA001751A3199	Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white - 63x63	2520 TR-84	1	sztuka
2CKA001724A4256	Cover plate Bore hole 1 gang studio white - 63x63	2533-84	1	sztuka
2CKA001710A3646	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button studio white - 63x63	2542 DR/01-84	1	sztuka

2CKA001710A3651	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button studio white - 63x63	2542 DR/02-84	1	sztuka
2CKA001724A4385	Cover plate Call unit studio white - 63x63	2548-020 F-84	1	sztuka
2CKA001724A4387	Cover plate Czerwony studio white - 63x63	2548-022 A-84	1	sztuka
2CKA001724A4388	Cover plate Doctor Niebieski studio white - 63x63	2548-022 AR-84	1	sztuka
2CKA001724A4389	Cover plate Call module Czerwony studio white - 63x63	2548-022 B-84	1	sztuka
2CKA001724A4390	Cover plate Pull-cord switch studio white - 63x63	2548-046 A-84	1	sztuka
2CKA001724A4391	Cover plate Call module Czerwony studio white - 63x63	2548-071 D-84	1	sztuka
2CKA001724A4392	Cover plate Call module Czerwony studio white - 63x63	2548-071 E-84	1	sztuka
2CKA001724A4393	Cover plate Call / reset Red / Green studio white - 63x63	2548-642 B-84	1	sztuka
2CKA001724A4395	Cover plate Reset Zielony studio white - 63x63	2548-642 C-84	1	sztuka
2CKA001724A4402	Cover plate XLR 1 gang studio white - 63x63	2553-84	1	sztuka
2CKA001753A0394	Cover plate Modular Jack 2 gang studio white - 63x63	2561-02-84	1	sztuka
2CKA001753A0403	Cover plate Modular Jack 1 gang studio white - 63x63	2561-84	1	sztuka
2CKA003116A0662	FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA studio white - 63x63	3120 EUCEB-84	1	sztuka
2CKA003117A0006	Buschmat RCD - Insert RCD 30 mA studio white - 63x63	3151 UC-84	1	sztuka
2CKA006155A0121	6108/61-840-500 Coverplate f. CE	6108/61-840-500	1	sztuka
2CKA006115A0486	6108/61-84-500 Coverplate f. CE	6108/61-84-500	1	sztuka
2CKA006155A0114	6109/03-840-500 Coverplate f. RTC	6109/03-840-500	1	sztuka
2CKA006155A0063	6109/03-84-500 Coverplate f. RTC	6109/03-84-500	1	sztuka
2CKA006132A0407	6122/10-840-500 BW standard	6122/10-840-500	1	sztuka
2CKA006132A0379	Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° studio white	6122/10-84-500	1	sztuka
2CKA006115A0183	6125/01-84-500 Control element 1g w. BAU	6125/01-84-500	1	sztuka
2CKA006115A0452	6125/02-840-500 cont.-element KNX 1g	6125/02-840-500	1	sztuka
2CKA006115A0219	6125/02-84-500 Control element 1/2gang	6125/02-84-500	1	sztuka
2CKA006116A0174	6126/01-84-500 Control element 2g w. BAU	6126/01-84-500	1	sztuka
2CKA006116A0227	6126/02-840-500 cont.-element KNX 2g	6126/02-840-500	1	sztuka
2CKA006116A0209	6126/02-84-500 Control element 2/4gang	6126/02-84-500	1	sztuka
2CKA006117A0200	6127/01-84-500 Control element 4g w. BAU	6127/01-84-500	1	sztuka
2CKA006117A0252	6127/02-840-500 cont.-element KNX 4g	6127/02-840-500	1	sztuka

2CKA006117A0235	6127/02-84-500 Control element 4/8gang	6127/02-84-500	1	sztuka
2CKA006134A0342	6128/28-840-500 RTC Control element 2/4g	6128/28-840-500	1	sztuka
2CKA006134A0334	6128/28-84-500 RTC Control element 2/4g	6128/28-84-500	1	sztuka
2CKA006135A0146	6129/01-84-500 Control element 3/6g w. IR	6129/01-84-500	1	sztuka
2CKA006430A0400	6430-84-102-500 Control Cover	6430-84-102-500	1	sztuka
2CKA006430A0306	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate studio white - 63x63	6435-84	1	sztuka
2CKA006400A0059	Cover plate PowerDock 1 gang studio white - 63x63	6477-84	1	sztuka
2CKA006400A0047	Multimedia Devices studio white - solo	6480/11-84-500	1	sztuka
2CKA006400A0045	Multimedia Devices studio white - future linear	6480-84-500	1	sztuka
2CKA006599A3009	6540-84-102-500 Center Pl. SF Dimmer	6540-84-102-500	1	sztuka
2CKA006599A2835	Cover plate None for Cooling Central cover plate studio white - 63x63	6541-84	1	sztuka
2CKA006599A3010	6543-84-101-500 Dimmer Control Cover	6543-84-101-500	1	sztuka
2CKA006599A2908	Control Element None for Dimmer Two-part button with Neon lamp studio white - 63x63	6545-84	1	sztuka
2CKA006730A0038	Electronic Controls 1 channel Radio Control studio white - 63x63	6731-84-500	1	sztuka
2CKA006730A0039	Electronic Controls 2 channel Radio Control studio white - 63x63	6732-84-500	1	sztuka
2CKA006730A0040	6733-84-500 RF-Switch Sensor 4-fold	6733-84-500	1	sztuka
2CKA006800A2834	Electronic Controls studio white - 63x63	6815-84-101-500	1	sztuka
2CKA008200A0255	Cover plate with legend Radio 0 gang studio white - 63x63	8252-84-101-500	1	sztuka
2CKA008200A0081	Cover plate Loudspeaker studio white - 63x63	8253-84	1	sztuka
2CKA008300A0225	83260-84-515 Cover plates, Indoor St.	83260-84-515	1	sztuka
2CKA006220A0244	CP-FCC-84 C-plate Fan Coil	CP-FCC-84	1	sztuka
2CKA006220A0181	CP-RTC-84 C-plate RT sensor unit	CP-RTC-84	1	sztuka
2CKA006220A0384	CP-RTC-840 c-plate temp.	CP-RTC-840	1	sztuka
2CKA006220A0214	MD-F-1.0.1-84 Movement detector	MD-F-1.0.1-84	1	sztuka
2CKA006220A0385	MD-F-1.0.1-840 WD 180 sens	MD-F-1.0.1-840	1	sztuka
2CKA006220A0217	MSA-F-1.1.1-84 Mov. detector/actuator 1g	MSA-F-1.1.1-84	1	sztuka
2CKA006220A0386	MSA-F-1.1.1-840 WD 180 sens actuator	MSA-F-1.1.1-840	1	sztuka
2CKA006200A0086	MSA-F-1.1.1-84-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-84-WL	1	sztuka
2CKA006220A0139	SR-1-84 rocker 1gang	SR-1-84	1	sztuka
2CKA006220A0371	Electronic Controls antique brass - 63x63	SR-1-840	1	sztuka
2CKA006220A0154	SR-2-84 rocker 2gang	SR-2-84	1	sztuka

2CKA006220A0376	Electronic Controls antique brass - 63x63	SR-2-840	1	sztuka
2CKA006220A0145	SRB-1-84 rocker 1gang, blinds	SRB-1-84	1	sztuka
2CKA006220A0373	Electronic Controls antique brass - 63x63	SRB-1-840	1	sztuka
2CKA006220A0160	SRB-2-84 rocker 2g, blinds	SRB-2-84	1	sztuka
2CKA006220A0378	Electronic Controls antique brass - 63x63	SRB-2-840	1	sztuka
2CKA006220A0151	SRD-1-84 rocker 1gang, dimming	SRD-1-84	1	sztuka
2CKA006220A0375	Electronic Controls antique brass - 63x63	SRD-1-840	1	sztuka
2CKA006220A0166	SRD-2-L-84 rocker 2g, left, dimming	SRD-2-L-84	1	sztuka
2CKA006220A0380	Electronic Controls antique brass - 63x63	SRD-2-L-840	1	sztuka
2CKA006220A0260	SRD-2-R-84 rocker 2g, right, dimming	SRD-2-R-84	1	sztuka
2CKA006220A0383	Electronic Controls antique brass - 63x63	SRD-2-R-840	1	sztuka
2CKA006220A0142	SRL-1-84 rocker 1gang, lighting	SRL-1-84	1	sztuka
2CKA006220A0372	Electronic Controls antique brass - 63x63	SRL-1-840	1	sztuka
2CKA006220A0157	SRL-2-L-84 rocker 2g, left, lighting	SRL-2-L-84	1	sztuka
2CKA006220A0377	Electronic Controls antique brass - 63x63	SRL-2-L-840	1	sztuka
2CKA006220A0169	SRL-2-R-84 rocker 2g, right, lighting	SRL-2-R-84	1	sztuka
2CKA006220A0381	Electronic Controls antique brass - 63x63	SRL-2-R-840	1	sztuka
2CKA006220A0148	SRS-1-84 rocker 1gang, scene	SRS-1-84	1	sztuka
2CKA006220A0374	Electronic Controls antique brass - 63x63	SRS-1-840	1	sztuka
2CKA006220A0163	SRS-2-L-84 rocker 2gang, left, scene	SRS-2-L-84	1	sztuka
2CKA006220A0379	Electronic Controls antique brass - 63x63	SRS-2-L-840	1	sztuka
2CKA006220A0175	SRS-2-R-84 rocker 2g, right, scene	SRS-2-R-84	1	sztuka
2CKA006220A0382	Electronic Controls antique brass - 63x63	SRS-2-R-840	1	sztuka
2CKA001751A3170	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, with LED 1NO studio white - 63x63	2029 UC-84	1	sztuka
2CKA001719A0220	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring studio white - 63x63	2518-WD-84	1	sztuka
2CKA006710A0011	Kits 4 chan. Zigbee studio white - future linear	6716 UJ-84-500	1	sztuka
2CKA006730A0136	Control Element None for Dimmer Two-part button studio white - 63x63	6736 FoH-84	1	sztuka
2CKA001032A0523	Room Temperature Controller set studio white - future linear	1098 UJ-84	1	sztuka
2CKA001799A0984	1701 P-84 SM box, 1-gang, Philips	1701 P-84	1	sztuka
2CKA001799A0982	Mounting Box 1 gang studio white - future linear	1701-84-500	1	sztuka
2CKA001799A0902	Mounting Box 2 gang studio white - future linear	1702-84	1	sztuka
2CKA001799A0918	Mounting Box 3 gang studio white - future linear	1703-84	1	sztuka
2CKA001751A3209	Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang studio white - 63x63	1785/11 K-84	1	sztuka
2CKA001710A4127	Cover plate with legend Card, Symbol "arrows" Hotel card studio white - 63x63	1792 RFID-84	1	sztuka
2CKA001710A4201	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white - 63x63	1794 R-84	1	sztuka
2CKA001710A4202	Cover plate Characters 1 ... 6 for Thermostat Turn button studio white - solo	1794 R-84-500	1	sztuka

2CKA002011A6274	Socket insert None Protective contact (SCHUKO) 20 EUCB2USB with USB AA studio white - 63x63	-84-500	1	sztuka
2CKA002011A6281	Socket insert None Protective contact (SCHUKO) 20 EUCB2USB with USB AA antique brass anthracite - 63x63	-845-500	1	sztuka
2CKA002017A1891	Socket None Earthing pin with USB AA studio white - 63x63	20 MUCB2USB-84-500	1	sztuka
2CKA002017A0885	Flush Mounted Inserts CSN-Norm 250 V	2017-0-0885	1	sztuka
2CKA001751A3231	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 2029/12 UC-84 studio white - 63x63		1	sztuka
2CKA001751A3220	Rocker with legend DND, MUR for Switch/push button Two-part rocker studio white - 63x63	2058-24-84	1	sztuka
2CKA001751A3240	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang studio white - 63x63	2059 UC-84	1	sztuka
2CKA001761A1495	Cable Entry studio white - future linear	2087-84	1	sztuka
2CKA001761A1500	Cable Entry studio white - future linear	2088-84	1	sztuka
2CKA001751A3190	Mechanical Controls Symbol "light" for Switch/push button, Single rocker studio white - 2520 LI-84-500 63x63		1	sztuka
2CKA001724A4383	Cover plate Call unit studio white - 63x63	2548-020 D-84	1	sztuka
2CKA001724A4384	Cover plate Call unit studio white - 63x63	2548-020 E-84	1	sztuka
2CKA001724A4386	Cover plate Call unit studio white - 63x63	2548-021 G-84	1	sztuka
2CKA001724A4394	Cover plate Duty room unit White / Green studio white - 63x63	2548-642 BD-84	1	sztuka
2CKA001724A4396	Cover plate Reset Żółty studio white - 63x63	2548-642 D-84	1	sztuka
2CKA001751A3258	Rocker for Switch/push button Single rocker studio white - 63x63	2570-10-84	1	sztuka
2CKA001751A3269	Rocker for Switch/push button Two-part rocker studio white - 63x63	2570-20-84	1	sztuka
2CKA001751A3280	Rocker for Switch/push button Three-part rocker studio white - 63x63	2570-30-84	1	sztuka
2CKA006132A0263	Solo Horizontal 0 ... 180 ° studio white	6122/02-84-500	1	sztuka
2CKA006134A0222	6124-84-101 Room Thermostat with Display	6124-84-101	1	sztuka
2CKA006134A0223	6124-84-500-101 Room Thermostat with Display	6124-84-500-101	1	sztuka
2CKA006134A0212	6128-84-500-101 RoomThermostat/Switch Sensor	6128-84-500-101	1	sztuka
2CKA006200A0196	62762 UJ-84-WL-500 WD 180 flex set comfort WL	62762 UJ-84-WL-500	1	sztuka
2CKA006200A0172	62762-84-WL-500 WD 180 flex conf. sens. WL	62762-84-WL-500	1	sztuka
2CKA006200A0240	62764-84-WL-500 WD 180 flex multi sens. WL	62764-84-WL-500	1	sztuka
2CKA006200A0295	Kits 1gang studio white - future linear	62851 UJ-84-WL-500	1	sztuka
2CKA006800A2951	Kits Movement sensor 1gang studio white - future linear	64761 UJ-84-500	1	sztuka
2CKA006800A2934	Busch-Watchdog Cover plate Movement sensor antique brass - 63x63	64761-840-500	1	sztuka

2CKA006800A2927	Electronic Controls Movement sensor studio white - 63x63	64761-84-500	1	sztuka
2CKA006800A2988	Kits Movement sensor 1gang studio white - future linear	64762 UJ-84-500	1	sztuka
2CKA006800A2964	64762-84-500 WD 180 flex comfort sensor	64762-84-500	1	sztuka
2CKA006800A3025	Kits Movement sensor 1gang studio white - future linear	64764 UJ-84-500	1	sztuka
2CKA006800A3008	Busch-Watchdog Cover plate Movement sensor antique brass - 63x63	64764-840-500	1	sztuka
2CKA006800A3001	64764-84-500 WD 180 flex, multi sensor	64764-84-500	1	sztuka
2CKA006800A2889	Electronic Controls Movement sensor studio white - 63x63	64765-84-500	1	sztuka
2CKA006730A0154	Smart switch set 4 chan. Bluetooth studio white - future linear	6716/01 UJ-84	1	sztuka
2CKA006730A0156	Kits 4 chan. Bluetooth studio white - future linear	6716/01 UJ-84-500	1	sztuka
2CKA006730A0158	Kits 4 channel Bluetooth studio white - future linear	6716/01 UJ-84-510	1	sztuka
2CKA006730A0145	Rocker None for Dimmer Single rocker studio white - 63x63	6735 BT-84	1	sztuka
2CKA006730A0082	Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control studio white - 63x63	6735/01-84	1	sztuka
2CKA006730A0164	Electronic Controls None for Dimmer Single rocker studio white - 63x63	6735/10-84	1	sztuka
2CKA006730A0070	Control Element for Switch/dimmer 1gang Radio Control studio white - 63x63	6735-84	1	sztuka
2CKA006730A0086	Wall sensor 2 channel 2gang Radio Control studio white - 63x63	6736/01-84	1	sztuka
2CKA006730A0165	Electronic Controls None for Dimmer Two-part button studio white - 63x63	6736/10-84	1	sztuka
2CKA006730A0074	Control Element for Switch/dimmer 2gang Radio Control studio white - 63x63	6736-84	1	sztuka
2CKA006730A0090	Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control studio white - 63x63	6737/01-84	1	sztuka
2CKA006730A0078	Control Element for Switch/dimmer 4gang Radio Control studio white - 63x63	6737-84	1	sztuka
2CKA006800A2101	6800-84-104 Watchdog Comfort Sensor 180	6800-84-104	1	sztuka
2CKA008200A0234	Busch-Radio set DAB+ studio white - future linear	8220 UJ-84-101-500	1	sztuka
2CKA008200A0156	Multimedia Devices Radio receiver studio white - future linear	8240-84-500	1	sztuka
2CKA008200A0224	Cover plate Multimedia 3 gang studio white - 63x63	8256-84	1	sztuka
2CKA008200A0237	Busch-Radio set DAB+ studio white - future linear	8270 UJ-84-101-500	1	sztuka
2CKA001731A1976	Cover Busch-Infolicht® grey metallic - 63x63	1716-803	1	sztuka
2CKA001731A1921	Cover Busch-Infolicht® anthracite - 63x63	1716-81	1	sztuka
2CKA001731A1950	Cover Busch-Infolicht® aluminium silver - 63x63	1716-83	1	sztuka
2CKA001731A1955	Cover Busch-Infolicht® stainless steel - Pure Stainless Steel	1716-866	1	sztuka
2CKA001731A1978	Cover Busch-Infolicht® studio white matt - 63x63	1716-884	1	sztuka

2CKA001731A1980	Cover Busch-Infolicht® black matt - 63x63	1716-885	1	sztuka
2CKA001731A1914	Rocker None for Pull-cord switch, Pull cord anthracite - 63x63	1720-81	1	sztuka
2CKA001731A1915	Rocker None for Pull-cord switch, Pull cord ivory white - 63x63	1720-82	1	sztuka
2CKA001731A1949	Rocker for Pull-cord switch, Pull cord aluminium silver - 63x63	1720-83	1	sztuka
2CKA001731A1954	Rocker None for Pull-cord switch, Pull cord stainless steel - Pure Stainless Steel	1720-866	1	sztuka
2CKA001731A1979	Rocker None for Pull-cord switch, Pull cord studio white matt - 63x63	1720-884	1	sztuka
2CKA001731A1981	Rocker None for Pull-cord switch, Pull cord black matt - 63x63	1720-885	1	sztuka
2CKA001710A4119	Cover plate with legend Level switch Turn button grey metallic - 63x63	1740 DR/03-803	1	sztuka
2CKA001710A4120	Cover plate with legend Level switch Turn button anthracite - 63x63	1740 DR/03-81	1	sztuka
2CKA001710A3807	Cover plate with legend Level switch Turn button ivory white - 63x63	1740 DR/03-82	1	sztuka
2CKA001710A3811	Cover plate with legend Level switch Turn button aluminium silver - 63x63	1740 DR/03-83	1	sztuka
2CKA001710A3812	Cover plate with legend Level switch Turn button stainless steel - Pure Stainless Steel	1740 DR/03-866	1	sztuka
2CKA001710A3870	Cover plate with legend Level switch Turn button studio white matt - 63x63	1740 DR/03-884	1	sztuka
2CKA001710A3892	Cover plate with legend Level switch Turn button black matt - 63x63	1740 DR/03-885	1	sztuka
2CKA001710A4121	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button grey metallic - 63x63	1740 DRL-803-503	1	sztuka
2CKA001710A4122	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button anthracite - 63x63	1740 DRL-81-503	1	sztuka
2CKA001710A3511	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button ivory white - 63x63	1740 DRL-82-503	1	sztuka
2CKA001710A4123	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button aluminium silver - 63x63	1740 DRL-83-503	1	sztuka
2CKA001710A3771	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button stainless steel - Pure Stainless Steel	1740 DRL-866-503	1	sztuka
2CKA001710A3871	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button studio white matt - 63x63	1740 DRL-884-503	1	sztuka
2CKA001710A3893	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button black matt - 63x63	1740 DRL-885-503	1	sztuka
2CKA001710A3840	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button grey metallic - 63x63	1740-803	1	sztuka
2CKA001710A3623	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button anthracite - 63x63	1740-81	1	sztuka
2CKA001710A3154	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button ivory white - 63x63	1740-82	1	sztuka
2CKA001710A3661	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button aluminium silver - 63x63	1740-83	1	sztuka
2CKA001710A3748	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button stainless steel - Pure Stainless Steel	1740-866	1	sztuka

2CKA001710A3872	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button studio white matt - 63x63	1740-884	1	sztuka
2CKA001710A3894	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button black matt - 63x63	1740-885	1	sztuka
2CKA001710A3843	Cover plate Blind cap 1 gang with Mounting plate grey metallic - 63x63	1742-803	1	sztuka
2CKA001710A3612	Cover plate Blind cap 1 gang with Mounting plate anthracite - 63x63	1742-81	1	sztuka
2CKA001710A3143	Cover plate Blind cap 1 gang with Mounting plate ivory white - 63x63	1742-82	1	sztuka
2CKA001710A3664	Cover plate Blind cap 1 gang with Mounting plate aluminium silver - 63x63	1742-83	1	sztuka
2CKA001710A3751	Cover plate Blind cap 1 gang with Mounting plate stainless steel - Pure Stainless Steel	1742-866	1	sztuka
2CKA001710A3873	Cover plate Blind cap 1 gang with Mounting plate studio white matt - 63x63	1742-884	1	sztuka
2CKA001710A3895	Cover plate Blind cap 1 gang with Mounting plate black matt - 63x63	1742-885	1	sztuka
2CKA001724A4364	Cover plate SAT 4 gang grey metallic - 63x63	1743/10-04-803	1	sztuka
2CKA001724A4365	Cover plate SAT 4 gang anthracite - 63x63	1743/10-04-81	1	sztuka
2CKA001724A4366	Cover plate SAT 4 gang ivory white - 63x63	1743/10-04-82	1	sztuka
2CKA001724A4367	Cover plate SAT 4 gang aluminium silver - 63x63	1743/10-04-83	1	sztuka
2CKA001724A4369	Cover plate SAT 4 gang stainless steel - Pure Stainless Steel	1743/10-04-866	1	sztuka
2CKA001724A4370	Cover plate TV / Radio / 2x SAT 4 gang studio white matt - 63x63	1743/10-04-884	1	sztuka
2CKA001724A4371	Cover plate SAT 4 gang black matt - 63x63	1743/10-04-885	1	sztuka
2CKA001724A4373	Cover plate TV / Radio / 2x SAT 4 gang grey metallic - 63x63	1743-04-803	1	sztuka
2CKA001724A4374	Cover plate SAT 4 gang anthracite - 63x63	1743-04-81	1	sztuka
2CKA001724A4375	Cover plate TV / Radio / 2x SAT 4 gang ivory white - 63x63	1743-04-82	1	sztuka
2CKA001724A4376	Cover plate SAT 4 gang aluminium silver - 63x63	1743-04-83	1	sztuka
2CKA001724A4378	Cover plate SAT 4 gang stainless steel - Pure Stainless Steel	1743-04-866	1	sztuka
2CKA001724A4379	Cover plate TV / Radio / 2x SAT 4 gang studio white matt - 63x63	1743-04-884	1	sztuka
2CKA001724A4380	Cover plate SAT 4 gang black matt - 63x63	1743-04-885	1	sztuka
2CKA001724A4291	Cover plate SAT 3 gang grey metallic - 63x63	1743-803	1	sztuka
2CKA001724A4252	Cover plate SAT 3 gang anthracite - 63x63	1743-81	1	sztuka
2CKA001724A2758	Cover plate SAT 3 gang ivory white - 63x63	1743-82	1	sztuka
2CKA001724A4262	Cover plate SAT 3 gang aluminium silver - 63x63	1743-83	1	sztuka
2CKA001724A4271	Cover plate SAT 3 gang stainless steel - Pure Stainless Steel	1743-866	1	sztuka
2CKA001724A4293	Cover plate SAT 3 gang studio white matt - 63x63	1743-884	1	sztuka
2CKA001724A4298	Cover plate SAT 3 gang black matt - 63x63	1743-885	1	sztuka
2CKA001710A3855	Cover plate telephone connector boxes (VDo) grey metallic - 63x63	1745-803	1	sztuka

2CKA001710A3624	Cover plate telephone connector boxes (VDo) anthracite - 63x63	1745-81	1	sztuka
2CKA001710A3155	Cover plate telephone connector boxes (VDo) ivory white - 63x63	1745-82	1	sztuka
2CKA001710A3675	Cover plate telephone connector boxes (VDo) aluminium silver - 63x63	1745-83	1	sztuka
2CKA001710A3766	Cover plate telephone connector boxes (VDo) stainless steel - Pure Stainless Steel	1745-866	1	sztuka
2CKA001710A3874	Cover plate telephone connector boxes (VDo) studio white matt - 63x63	1745-884	1	sztuka
2CKA001710A3896	Cover plate telephone connector boxes (VDo) black matt - 63x63	1745-885	1	sztuka
2CKA001710A3857	Cover plate Telecommunication inserts 50 x 50 mm grey metallic - 63x63	1746/10-803	1	sztuka
2CKA001710A3628	Cover plate Telecommunication inserts 50 x 50 mm anthracite - 63x63	1746/10-81	1	sztuka
2CKA001710A3521	Cover plate Telecommunication inserts 50 x 50 mm ivory white - 63x63	1746/10-82	1	sztuka
2CKA001710A3677	Cover plate Telecommunication inserts 50 x 50 mm aluminium silver - 63x63	1746/10-83	1	sztuka
2CKA001710A3768	Cover plate Telecommunication inserts 50 x 50 mm stainless steel - Pure Stainless Steel	1746/10-866	1	sztuka
2CKA001710A3875	Cover plate Telecommunication inserts 50 x 50 mm studio white matt - 63x63	1746/10-884	1	sztuka
2CKA001710A3897	Cover plate Telecommunication inserts 50 x 50 mm black matt - 63x63	1746/10-885	1	sztuka
2CKA001710A3858	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang grey metallic - 63x63	1746-803	1	sztuka
2CKA001710A3618	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang anthracite - 63x63	1746-81	1	sztuka
2CKA001710A3149	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang ivory white - 63x63	1746-82	1	sztuka
2CKA001710A3678	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang aluminium silver - 63x63	1746-83	1	sztuka
2CKA001710A3769	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang stainless steel - Pure Stainless Steel	1746-866	1	sztuka
2CKA001710A3876	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang studio white matt - 63x63	1746-884	1	sztuka
2CKA001710A3898	Cover plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang black matt - 63x63	1746-885	1	sztuka
2CKA001710A4092	Intermediate Ring for cover plates Busch- Balance® SI grey metallic - 63x63	1747 BSI-803	1	sztuka
2CKA001710A4093	Intermediate Ring for cover plates Busch- Balance® SI anthracite - 63x63	1747 BSI-81	1	sztuka
2CKA001710A4094	Intermediate Ring for cover plates Busch- Balance® SI ivory white - 63x63	1747 BSI-82	1	sztuka
2CKA001710A4095	Intermediate Ring for cover plates Busch- Balance® SI aluminium silver - 63x63	1747 BSI-83	1	sztuka
2CKA001710A4097	Intermediate Ring for cover plates Busch- Balance® SI stainless steel - Pure Stainless Steel	1747 BSI-866	1	sztuka

2CKA001710A4098	Intermediate Ring for cover plates Busch-Balance® SI studio white matt - 63x63	1747 BSI-884	1	sztuka
2CKA001710A4099	Intermediate Ring for cover plates Busch-Balance® SI black matt - 63x63	1747 BSI-885	1	sztuka
2CKA001710A3862	Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI ivory white - 63x63	1747 SI-82	1	sztuka
2CKA001710A3860	Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI ivory white - 63x63	1747-82	1	sztuka
2CKA001710A3844	Cover plate Cable outlet with Mounting plate grey metallic - 63x63	1749-803	1	sztuka
2CKA001710A3614	Cover plate Cable outlet with Mounting plate anthracite - 63x63	1749-81	1	sztuka
2CKA001710A3145	Cover plate Cable outlet with Mounting plate ivory white - 63x63	1749-82	1	sztuka
2CKA001710A3665	Cover plate Cable outlet with Mounting plate aluminium silver - 63x63	1749-83	1	sztuka
2CKA001710A3752	Cover plate Cable outlet with Mounting plate stainless steel - Pure Stainless Steel	1749-866	1	sztuka
2CKA001710A3878	Cover plate Cable outlet with Mounting plate studio white matt - 63x63	1749-884	1	sztuka
2CKA001710A3900	Cover plate Cable outlet with Mounting plate black matt - 63x63	1749-885	1	sztuka
2CKA001710A3679	Cover plate BNC/TNC 2 gang aluminium silver - 63x63	1750-83	1	sztuka
2CKA001723A0257	Cover plate Loudspeaker 2 gang grey metallic - 63x63	1751-803	1	sztuka
2CKA001723A0253	Cover plate Loudspeaker 2 gang anthracite - 63x63	1751-81	1	sztuka
2CKA001723A0239	Cover plate Loudspeaker 2 gang ivory white - 63x63	1751-82	1	sztuka
2CKA001723A0254	Cover plate Loudspeaker 2 gang aluminium silver - 63x63	1751-83	1	sztuka
2CKA001723A0255	Cover plate Loudspeaker 2 gang stainless steel - Pure Stainless Steel	1751-866	1	sztuka
2CKA001723A0260	Cover plate Loudspeaker 2 gang studio white matt - 63x63	1751-884	1	sztuka
2CKA001723A0259	Cover plate Loudspeaker 2 gang black matt - 63x63	1751-885	1	sztuka
2CKA001710A3841	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key grey metallic - 63x63	1755 SL/PZ-803-101	1	sztuka
2CKA001710A3626	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key anthracite - 63x63	1755 SL/PZ-81-101	1	sztuka
2CKA001710A3157	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key ivory white - 63x63	1755 SL/PZ-82-101	1	sztuka
2CKA001710A3662	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key aluminium silver - 63x63	1755 SL/PZ-83-101	1	sztuka
2CKA001710A3749	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key stainless steel - Pure Stainless Steel	1755 SL/PZ-866-101	1	sztuka
2CKA001710A3925	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key studio white matt - 63x63	1755 SL/PZ-884-101	1	sztuka
2CKA001710A3902	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key black matt - 63x63	1755 SL/PZ-885-101	1	sztuka

2CKA001724A4292	Cover plate with labelling field For data connection housing 2 gang grey metallic - 63x63	1758-803	1	sztuka
2CKA001724A4253	Cover plate with labelling field For data connection housing 2 gang anthracite - 63x63	1758-81	1	sztuka
2CKA001724A2759	Cover plate with labelling field For data connection housing 2 gang ivory white - 63x63	1758-82	1	sztuka
2CKA001724A4263	Cover plate with labelling field For data connection housing 2 gang aluminium silver - 63x63	1758-83	1	sztuka
2CKA001724A4272	Cover plate with labelling field For data connection housing 2 gang stainless steel - Pure Stainless Steel	1758-866	1	sztuka
2CKA001724A4307	Cover plate with labelling field For data connection housing 2 gang studio white matt - 63x63	1758-884	1	sztuka
2CKA001724A4299	Cover plate with labelling field For data connection housing 2 gang black matt - 63x63	1758-885	1	sztuka
2CKA001731A3997	Rocker with labelling field Symbol "bell" for Switch/push button, Single push button grey metallic - 63x63	1764 NLI/KI-803	1	sztuka
2CKA001731A3998	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single push button with Pilot lamp anthracite - 63x63	1764 NLI/KI-81	1	sztuka
2CKA001731A3999	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single push button with Pilot lamp ivory white - 63x63	1764 NLI/KI-82	1	sztuka
2CKA001731A4000	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single push button with Pilot lamp aluminium silver - 63x63	1764 NLI/KI-83	1	sztuka
2CKA001731A4003	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single push button with Pilot lamp stainless steel - Pure Stainless Steel	1764 NLI/KI-866	1	sztuka
2CKA001731A4004	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single push button with Pilot lamp studio white matt - 63x63	1764 NLI/KI-884	1	sztuka
2CKA001731A4005	Rocker with labelling field and legend Symbol "bell" for Switch/push button, Single push button with Pilot lamp black matt - 63x63	1764 NLI/KI-885	1	sztuka
2CKA001731A4011	Rocker with labelling field for Switch/push button, Single push button with Pilot lamp red - 63x63	1764 NLI-12-82-101	1	sztuka
2CKA001731A4007	Rocker with labelling field for Switch/push button, Single push button with Pilot lamp green - 63x63	1764 NLI-13-82	1	sztuka
2CKA001731A1975	Rocker with labelling field for Switch/push button, Single rocker grey metallic - 63x63	1764 NLI-803	1	sztuka
2CKA001731A1552	Rocker with labelling field for Switch/push button, Single push button with Pilot lamp anthracite - 63x63	1764 NLI-81	1	sztuka
2CKA001731A1876	Rocker with labelling field for Switch/push button, Single push button with Pilot lamp ivory white - 63x63	1764 NLI-82	1	sztuka
2CKA001731A1948	Rocker with labelling field for Switch/push button, Single push button with Pilot lamp aluminium silver - 63x63	1764 NLI-83	1	sztuka
2CKA001731A1953	Rocker with labelling field for Switch/push button, Single push button with Pilot lamp stainless steel - Pure Stainless Steel	1764 NLI-866	1	sztuka

2CKA001731A1985	Rocker with labelling field for Switch/push button, Single push button with Pilot lamp studio white matt - 63x63	1764 NLI-884	1	sztuka
2CKA001731A1982	Rocker with labelling field for Switch/push button, Single push button with Pilot lamp black matt - 63x63	1764 NLI-885	1	sztuka
2CKA001710A3854	Cover plate TAE 1 gang grey metallic - 63x63	1766-803	1	sztuka
2CKA001710A3613	Cover plate TAE 1 gang anthracite - 63x63	1766-81	1	sztuka
2CKA001710A3144	Cover plate TAE 1 gang ivory white - 63x63	1766-82	1	sztuka
2CKA001710A3659	Cover plate TAE 1 gang aluminium silver - 63x63	1766-83	1	sztuka
2CKA001710A3765	Cover plate TAE 1 gang stainless steel - Pure Stainless Steel	1766-866	1	sztuka
2CKA001710A3926	Cover plate TAE 1 gang studio white matt - 63x63	1766-884	1	sztuka
2CKA001710A3903	Cover plate TAE 1 gang black matt - 63x63	1766-885	1	sztuka
2CKA001753A0254	Cover plate 1 ... 15 Min for Time switch, Toggle grey metallic - 63x63	1770-803-103	1	sztuka
2CKA001753A0255	Cover plate with legend 1 ... 15 Min for Time switch, Toggle anthracite - 63x63	1770-81-103	1	sztuka
2CKA001753A0256	Cover plate with legend 1 ... 15 Min for Time switch, Toggle white - 63x63	1770-82-103	1	sztuka
2CKA001753A0257	Cover plate with legend 1 ... 15 Min for Time switch, Toggle aluminium - 63x63	1770-83-103	1	sztuka
2CKA001753A0259	Cover plate with legend 1 ... 15 Min for Time switch, Toggle stainless steel - Pure Stainless Steel	1770-866-103	1	sztuka
2CKA001753A0260	Cover plate with legend 1 ... 15 Min for Time switch, Toggle studio white matt - 63x63	1770-884-103	1	sztuka
2CKA001753A0261	Cover plate with legend 1 ... 15 Min for Time switch, Toggle black matt - 63x63	1770-885-103	1	sztuka
2CKA001753A0264	Cover plate Time indication for Time switch, Turn button grey metallic - 63x63	1771-803-103	1	sztuka
2CKA001753A0265	Cover plate with legend 10 ... 120 Min for Time switch, Toggle anthracite - 63x63	1771-81-103	1	sztuka
2CKA001753A0266	Cover plate with legend 10 ... 120 Min for Time switch, Toggle white - 63x63	1771-82-103	1	sztuka
2CKA001753A0267	Cover plate with legend 10 ... 120 Min for Time switch, Toggle aluminium - 63x63	1771-83-103	1	sztuka
2CKA001753A0302	Cover plate with legend 10 ... 120 Min for Time switch, Toggle stainless steel - Pure Stainless Steel	1771-866-103	1	sztuka
2CKA001753A0303	Cover plate with legend 10 ... 120 Min for Time switch, Toggle studio white matt - 63x63	1771-884-103	1	sztuka
2CKA001753A0304	Cover plate with legend 10 ... 120 Min for Time switch, Toggle black matt - 63x63	1771-885-103	1	sztuka
2CKA001751A2977	Multimedia Devices anthracite	1785 ENO-81	1	sztuka
2CKA001751A2978	Multimedia Devices ivory white	1785 ENO-82	1	sztuka
2CKA001751A2979	Multimedia Devices aluminium silver	1785 ENO-83	1	sztuka
2CKA001751A3101	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker ivory white - carat	1785 JA/02-82	1	sztuka
2CKA001751A3097	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker aluminium silver - 63x63	1785 JA/02-83	1	sztuka
2CKA001751A3103	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white matt - 63x63	1785 JA/02- 884	1	sztuka

2CKA001751A3105	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker black matt - 63x63	1785 JA/02-885	1	sztuka
2CKA001751A3020	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker grey metallic - 63x63	1785 JA-803	1	sztuka
2CKA001751A2934	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker anthracite - 63x63	1785 JA-81	1	sztuka
2CKA001751A2748	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker ivory white - 63x63	1785 JA-82	1	sztuka
2CKA001751A2944	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker aluminium silver - 63x63	1785 JA-83	1	sztuka
2CKA001751A2964	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker stainless steel - Pure Stainless Steel	1785 JA-866	1	sztuka
2CKA001751A3022	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white matt - 63x63	1785 JA-884	1	sztuka
2CKA001751A3036	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker black matt - 63x63	1785 JA-885	1	sztuka
2CKA001751A3126	Mechanical Controls None for Switch/push button, Two-part rocker aluminium silver - 63x63	1785 K-83-500	1	sztuka
2CKA001751A3204	Rocker with legend DND, MUR for Switch/push button, Single rocker grey metallic - 63x63	1785/11-803	1	sztuka
2CKA001751A3205	Rocker with legend DND, MUR for Switch/push button, Two-part rocker anthracite - 63x63	1785/11-81	1	sztuka
2CKA001751A2991	Rocker with legend DND, MUR for Switch/push button, Two-part rocker ivory white - 63x63	1785/11-82	1	sztuka
2CKA001751A2995	Rocker with legend DND, MUR for Switch/push button, Two-part rocker aluminium silver - 63x63	1785/11-83	1	sztuka
2CKA001751A2996	Rocker with legend DND, MUR for Switch/push button, Two-part rocker stainless steel - Pure Stainless Steel	1785/11-866	1	sztuka
2CKA001751A3023	Rocker with legend DND, MUR for Switch/push button, Two-part rocker studio white matt - 63x63	1785/11-884	1	sztuka
2CKA001751A3037	Rocker with legend DND, MUR for Switch/push button, Two-part rocker black matt - 63x63	1785/11-885	1	sztuka
2CKA001751A3018	Rocker for Switch/push button, Two-part rocker grey metallic - 63x63	1785-803	1	sztuka
2CKA001751A2930	Rocker None for Switch/push button, Two-part rocker anthracite - 63x63	1785-81	1	sztuka
2CKA001751A2744	Rocker for Switch/push button, Two-part rocker ivory white - 63x63	1785-82	1	sztuka
2CKA001751A2942	Rocker None for Switch/push button, Two-part rocker aluminium silver - 63x63	1785-83	1	sztuka
2CKA001751A3092	Mechanical Controls Without imprint for Switch/push button, Two-part rocker aluminium silver - 63x63	1785-83-500	1	sztuka
2CKA001751A3087	Mechanical Controls Without imprint for Switch/push button, Two-part rocker stainless steel - Pure Stainless Steel	1785-866-500	1	sztuka
2CKA001751A3024	Rocker for Switch/push button, Two-part rocker studio white matt - 63x63	1785-884	1	sztuka
2CKA001751A3038	Rocker None for Switch/push button, Two-part rocker black matt - 63x63	1785-885	1	sztuka
2CKA001751A2965	Multimedia Devices anthracite	1786 ENO-81	1	sztuka
2CKA001751A2966	Multimedia Devices ivory white	1786 ENO-82	1	sztuka

2CKA001751A2967	Multimedia Devices aluminium silver	1786 ENO-83	1	sztuka
2CKA001751A3100	Rocker with legend Symbol "arrows" for Venetian blind, Single rocker ivory white - carat	1786 JA/02-82	1	sztuka
2CKA001751A3096	Rocker with legend Symbol "arrows" for Switch/push button, aluminium silver - 63x63	1786 JA/02-83	1	sztuka
2CKA001751A3102	Rocker with legend Symbol "arrows" for Venetian blind, Single rocker studio white matt - 63x63	1786 JA/02-884	1	sztuka
2CKA001751A3104	Rocker with legend Symbol "arrows" black matt - 63x63	1786 JA/02-885	1	sztuka
2CKA001751A3207	Rocker with legend DND for Switch/push button, Single rocker anthracite - 63x63	1786/11-81	1	sztuka
2CKA001751A2997	Rocker with legend DND for Switch/push button, Single rocker ivory white - 63x63	1786/11-82	1	sztuka
2CKA001751A3001	Rocker with legend DND for Switch/push button, Single rocker aluminium silver - 63x63	1786/11-83	1	sztuka
2CKA001751A3002	Rocker with legend DND for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1786/11-866	1	sztuka
2CKA001751A3026	Rocker with legend DND for Switch/push button, Single rocker studio white matt - 63x63	1786/11-884	1	sztuka
2CKA001751A3040	Rocker with legend DND for Switch/push button, Single rocker black matt - 63x63	1786/11-885	1	sztuka
2CKA001751A3145	Rocker None for Switch/push button, Single rocker red - 63x63	1786-12-82	1	sztuka
2CKA001751A3093	Mechanical Controls Without imprint for Switch/push button, Single rocker grey metallic - 63x63	1786-803-500	1	sztuka
2CKA001751A3079	Mechanical Controls Without imprint for Switch/push button, Single rocker anthracite - 63x63	1786-81-500	1	sztuka
2CKA001751A3083	Mechanical Controls Without imprint for Switch/push button, Single rocker ivory white - 63x63	1786-82-500	1	sztuka
2CKA001751A3075	Mechanical Controls Without imprint for Switch/push button, Single rocker aluminium silver - 63x63	1786-83-500	1	sztuka
2CKA001751A3077	Mechanical Controls Without imprint for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1786-866-500	1	sztuka
2CKA001751A3089	Mechanical Controls Without imprint for Switch/push button, Single rocker studio white matt - 63x63	1786-884-500	1	sztuka
2CKA001751A3094	Mechanical Controls Without imprint for Switch/push button, Single rocker black matt - 63x63	1786-885-500	1	sztuka
2CKA001751A3017	Rocker for Switch/push button, Single rocker grey metallic - 63x63	1788-803	1	sztuka
2CKA001751A2927	Rocker None for Switch/push button, Single rocker anthracite - 63x63	1788-81	1	sztuka
2CKA001751A2742	Rocker None for Switch/push button, Single rocker ivory white - 63x63	1788-82	1	sztuka
2CKA001751A2954	Rocker with legend Characters 0 and 1 for Switch/push button, Single rocker aluminium silver - 63x63	1788-83	1	sztuka

2CKA001751A2961	Rocker None for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1788-866	1	sztuka
2CKA001751A3028	Rocker None for Switch/push button, Single rocker studio white matt - 63x63	1788-884	1	sztuka
2CKA001751A3042	Rocker None for Switch/push button, Single rocker black matt - 63x63	1788-885	1	sztuka
2CKA001751A3019	Rocker with legend Heizung for Switch/push button, Single rocker grey metallic - 63x63	1789 H-803	1	sztuka
2CKA001751A2929	Rocker with legend Heizung for Switch/push button, Single rocker anthracite - 63x63	1789 H-81	1	sztuka
2CKA001751A2743	Rocker with legend Heizung for Switch/push button, Single rocker ivory white - 63x63	1789 H-82	1	sztuka
2CKA001751A2955	Rocker with legend Heizung for Switch/push button, Single rocker aluminium silver - 63x63	1789 H-83	1	sztuka
2CKA001751A2963	Rocker with legend Heizung for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 H-866	1	sztuka
2CKA001751A3029	Rocker with legend Heizung for Switch/push button, Single rocker studio white matt - 63x63	1789 H-884	1	sztuka
2CKA001751A3043	Rocker with legend Heizung for Switch/push button, Single rocker black matt - 63x63	1789 H-885	1	sztuka
2CKA001751A3015	Rocker for Switch/push button, Single rocker grey metallic - 63x63	1789 KI-803	1	sztuka
2CKA001751A2932	Rocker with legend Symbol "bell" for Switch/push button, Single rocker anthracite - 63x63	1789 KI-81	1	sztuka
2CKA001751A2746	Rocker with legend Symbol "bell" for Switch/push button, Single rocker ivory white - 63x63	1789 KI-82	1	sztuka
2CKA001751A2952	Rocker with legend Symbol "key/door" for Switch/push button, Single rocker aluminium silver - 63x63	1789 KI-83	1	sztuka
2CKA001751A2959	Rocker with legend Symbol "bell" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 KI-866	1	sztuka
2CKA001751A3030	Rocker with legend Symbol "bell" for Switch/push button, Single rocker studio white matt - 63x63	1789 KI-884	1	sztuka
2CKA001751A3044	Rocker with legend Symbol "bell" for Switch/push button, Single rocker black matt - 63x63	1789 KI-885	1	sztuka
2CKA001751A3014	Rocker with legend Symbol "light" for Switch/push button, Single rocker grey metallic - 63x63	1789 LI-803	1	sztuka
2CKA001751A2931	Rocker with legend Symbol "light" for Switch/push button, Single rocker anthracite - 63x63	1789 LI-81	1	sztuka
2CKA001751A2745	Rocker with legend Symbol "light" for Switch/push button, Single rocker ivory white - 63x63	1789 LI-82	1	sztuka
2CKA001751A2951	Rocker with legend Symbol "light" for Switch/push button, Single rocker aluminium silver - 63x63	1789 LI-83	1	sztuka
2CKA001751A2958	Rocker with legend Symbol "light" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 LI-866	1	sztuka
2CKA001751A3031	Rocker with legend Symbol "light" for Switch/push button, Single rocker studio white matt - 63x63	1789 LI-884	1	sztuka
2CKA001751A3045	Rocker with legend Symbol "light" for Switch/push button, Single rocker black matt - 63x63	1789 LI-885	1	sztuka
2CKA001751A3146	Rocker for Switch/push button, Single rocker grey metallic - 63x63	1789 N-803	1	sztuka

2CKA001751A3147	Rocker None for Switch/push button, Single rocker anthracite - 63x63	1789 N-81	1	sztuka
2CKA001751A3148	Rocker None for Switch/push button, Single rocker ivory white - 63x63	1789 N-82	1	sztuka
2CKA001751A3149	Rocker for Switch/push button, Single rocker aluminium silver - 63x63	1789 N-83	1	sztuka
2CKA001751A3152	Rocker None for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 N-866	1	sztuka
2CKA001751A3153	Rocker None for Switch/push button, Single rocker studio white matt - 63x63	1789 N-884	1	sztuka
2CKA001751A3154	Rocker None for Switch/push button, Single rocker black matt - 63x63	1789 N-885	1	sztuka
2CKA001751A3156	Rocker for Switch/push button, Single rocker grey metallic - 63x63	1789 ST-803	1	sztuka
2CKA001751A3157	Rocker with legend Symbol "plug" for Switch/push button, Single rocker anthracite - 63x63	1789 ST-81	1	sztuka
2CKA001751A3158	Rocker with legend Symbol "plug" for Switch/push button, Single rocker ivory white - 63x63	1789 ST-82	1	sztuka
2CKA001751A3159	Rocker with legend Symbol "plug" for Switch/push button, Single rocker aluminium silver - 63x63	1789 ST-83	1	sztuka
2CKA001751A3162	Rocker with legend Symbol "plug" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 ST-866	1	sztuka
2CKA001751A3163	Rocker with legend Symbol "plug" for Switch/push button, Single rocker studio white matt - 63x63	1789 ST-884	1	sztuka
2CKA001751A3164	Rocker with legend Symbol "plug" for Switch/push button, Single rocker black matt - 63x63	1789 ST-885	1	sztuka
2CKA001751A3016	Rocker with legend Symbol "key" for Switch/push button, Single rocker grey metallic - 63x63	1789 TR-803	1	sztuka
2CKA001751A2933	Rocker with legend Symbol "key" for Switch/push button, Single rocker anthracite - 63x63	1789 TR-81	1	sztuka
2CKA001751A2747	Rocker with legend Symbol "key" for Switch/push button, Single rocker ivory white - 63x63	1789 TR-82	1	sztuka
2CKA001751A2953	Rocker with legend Symbol "key" for Switch/push button, Single rocker aluminium silver - 63x63	1789 TR-83	1	sztuka
2CKA001751A2960	Rocker with legend Symbol "key" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 TR-866	1	sztuka
2CKA001751A3032	Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white matt - 63x63	1789 TR-884	1	sztuka
2CKA001751A3046	Rocker with legend Symbol "key" for Switch/push button, Single rocker black matt - 63x63	1789 TR-885	1	sztuka
2CKA001751A3013	Rocker for Switch/push button, Single rocker grey metallic - 63x63	1789-803	1	sztuka
2CKA001751A2928	Rocker for Switch/push button, Single rocker anthracite - 63x63	1789-81	1	sztuka
2CKA001751A2813	Rocker for Switch/push button, Single rocker ivory white - 63x63	1789-82	1	sztuka
2CKA001751A2945	Rocker None for Switch/push button, Single rocker aluminium silver - 63x63	1789-83	1	sztuka
2CKA001751A2957	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789-866	1	sztuka
2CKA001751A3033	Rocker for Switch/push button, Single rocker studio white matt - 63x63	1789-884	1	sztuka

2CKA001751A3047	Rocker for Switch/push button, Single rocker black matt - 63x63	1789-885	1	sztuka
2CKA001710A4124	Cover plate with legend Card, Symbol "arrows" for Switch/push button, Hotel card grey metallic - 63x63	1792-803	1	sztuka
2CKA001710A3639	Cover plate with legend Card, Symbol "arrows" Hotel card anthracite - 63x63	1792-81	1	sztuka
2CKA001710A3640	Cover plate with legend Card, Symbol "arrows" Hotel card ivory white - 63x63	1792-82	1	sztuka
2CKA001710A3670	Cover plate with legend Card, Symbol "arrows" Hotel card aluminium silver - 63x63	1792-83	1	sztuka
2CKA001710A3757	Cover plate with legend Card, Symbol "arrows" Hotel card stainless steel - Pure Stainless Steel	1792-866	1	sztuka
2CKA001710A3928	Cover plate with legend Card, Symbol "arrows" Hotel card studio white matt - 63x63	1792-884	1	sztuka
2CKA001710A3905	Cover plate with legend Card, Symbol "arrows" Hotel card black matt - 63x63	1792-885	1	sztuka
2CKA001710A3849	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button grey metallic - 63x63	1794 TA-803	1	sztuka
2CKA001710A3695	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - 63x63	1794 TA-81	1	sztuka
2CKA001710A3696	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button ivory white - 63x63	1794 TA-82	1	sztuka
2CKA001710A3697	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium silver - 63x63	1794 TA-83	1	sztuka
2CKA001710A3761	Cover plate with legend Symbol "1" for Thermostat Turn button stainless steel - Pure Stainless Steel	1794 TA-866	1	sztuka
2CKA001710A3883	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white matt - 63x63	1794 TA-884	1	sztuka
2CKA001710A3906	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button black matt - 63x63	1794 TA-885	1	sztuka
2CKA001710A3847	Cover plate with legend Symbol "1" for Thermostat Turn button grey metallic - 63x63	1794-803	1	sztuka
2CKA001710A3629	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - 63x63	1794-81	1	sztuka
2CKA001710A3668	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium silver - 63x63	1794-83	1	sztuka
2CKA001710A3884	Cover plate Various symbols for Thermostat Turn button studio white matt - 63x63	1794-884	1	sztuka
2CKA001710A3907	Cover plate Various symbols for Thermostat Turn button black matt - 63x63	1794-885	1	sztuka
2CKA001710A4012	Cover plate with legend Symbol "1" for Thermostat Turn button grey metallic - 63x63	1795 HK-803	1	sztuka
2CKA001710A4015	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button ivory white - 63x63	1795 HK-82	1	sztuka
2CKA001710A4018	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button stainless steel - Pure Stainless Steel	1795 HK-866	1	sztuka
2CKA001710A4044	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch grey metallic - 63x63	1795 HKEA- 803	1	sztuka
2CKA001710A4045	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch anthracite - 63x63	1795 HKEA-81	1	sztuka

2CKA001710A4047	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch ivory white - 63x63	1795 HKEA-82	1	sztuka
2CKA001710A4048	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch aluminium silver - 63x63	1795 HKEA-83	1	sztuka
2CKA001710A4050	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795 HKEA-866	1	sztuka
2CKA001710A4051	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white matt - 63x63	1795 HKEA-884	1	sztuka
2CKA001710A4052	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch black matt - 63x63	1795 HKEA-885	1	sztuka
2CKA001710A3850	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch grey metallic - 63x63	1795 TA-803	1	sztuka
2CKA001710A3722	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch anthracite - 63x63	1795 TA-81	1	sztuka
2CKA001710A3723	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch ivory white - 63x63	1795 TA-82	1	sztuka
2CKA001710A3724	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch aluminium silver - 63x63	1795 TA-83	1	sztuka
2CKA001710A3762	Cover plate with legend Symbol "1" for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795 TA-866	1	sztuka
2CKA001710A3885	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white matt - 63x63	1795 TA-884	1	sztuka
2CKA001710A3908	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch black matt - 63x63	1795 TA-885	1	sztuka
2CKA001710A3848	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch grey metallic - 63x63	1795-803	1	sztuka
2CKA001710A3630	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch anthracite - 63x63	1795-81	1	sztuka
2CKA001710A3568	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch ivory white - 63x63	1795-82	1	sztuka
2CKA001710A3669	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch aluminium silver - 63x63	1795-83	1	sztuka
2CKA001710A3756	Cover plate with legend Symbol "1" for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795-866	1	sztuka
2CKA001710A3886	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch studio white matt - 63x63	1795-884	1	sztuka
2CKA001710A3909	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button 1 sliding switch black matt - 63x63	1795-885	1	sztuka

2CKA001753A0307	Cover plate Pull cord grey metallic - 63x63	1796-803	1	sztuka
2CKA001753A0309	Cover plate for Pull-cord switch, Pull cord ivory white - 63x63	1796-82	1	sztuka
2CKA001753A0310	Cover plate for Pull-cord switch, Pull cord aluminium silver - 63x63	1796-83	1	sztuka
2CKA001753A0312	Cover plate for Pull-cord switch, Pull cord stainless steel - Pure Stainless Steel	1796-866	1	sztuka
2CKA001753A0313	Cover plate for Pull-cord switch, Pull cord studio white matt - 63x63	1796-884	1	sztuka
2CKA001753A0314	Cover plate with legend Symbol "bell" for Switch/push button, Pull cord black matt - 63x63	1796-885	1	sztuka
2CKA001710A3856	Cover plate with labelling field Modular Jack 2 gang grey metallic - 63x63	1800-803	1	sztuka
2CKA001710A3627	Cover plate with labelling field Modular Jack 2 gang anthracite - 63x63	1800-81	1	sztuka
2CKA001710A3158	Cover plate with labelling field Modular Jack 2 gang ivory white - 63x63	1800-82	1	sztuka
2CKA001710A3676	Cover plate with labelling field Modular Jack 2 gang aluminium silver - 63x63	1800-83	1	sztuka
2CKA001710A3767	Cover plate with labelling field Modular Jack 2 gang stainless steel - Pure Stainless Steel	1800-866	1	sztuka
2CKA001710A3887	Cover plate with labelling field Modular Jack 2 gang studio white matt - 63x63	1800-884	1	sztuka
2CKA001710A3910	Cover plate with labelling field Modular Jack 2 gang black matt - 63x63	1800-885	1	sztuka
2CKA001710A3853	Cover plate with labelling field UAE/IAE (ISDN) 2 gang grey metallic - 63x63	1803-02-803	1	sztuka
2CKA001710A3615	Cover plate with labelling field UAE/IAE (ISDN) 2 gang anthracite - 63x63	1803-02-81	1	sztuka
2CKA001710A3146	Cover plate with labelling field UAE/IAE (ISDN) 2 gang ivory white - 63x63	1803-02-82	1	sztuka
2CKA001710A3610	Cover plate with labelling field UAE/IAE (ISDN) 2 gang aluminium silver - 63x63	1803-02-83	1	sztuka
2CKA001710A3764	Cover plate with labelling field UAE/IAE (ISDN) 2 gang stainless steel - Pure Stainless Steel	1803-02-866	1	sztuka
2CKA001710A3888	Cover plate with labelling field UAE/IAE (ISDN) 2 gang studio white matt - 63x63	1803-02-884	1	sztuka
2CKA001710A3911	Cover plate with labelling field UAE/IAE (ISDN) 2 gang black matt - 63x63	1803-02-885	1	sztuka
2CKA001710A3852	Cover plate with labelling field UAE/IAE (ISDN) 1 gang grey metallic - 63x63	1803-803	1	sztuka
2CKA001710A3616	Cover plate with labelling field UAE/IAE (ISDN) 1 gang anthracite - 63x63	1803-81	1	sztuka
2CKA001710A3147	Cover plate with labelling field UAE/IAE (ISDN) 1 gang ivory white - 63x63	1803-82	1	sztuka
2CKA001710A3674	Cover plate with labelling field UAE/IAE (ISDN) 1 gang aluminium silver - 63x63	1803-83	1	sztuka
2CKA001710A3763	Cover plate with labelling field UAE/IAE (ISDN) 1 gang stainless steel - Pure Stainless Steel	1803-866	1	sztuka
2CKA001710A3889	Cover plate with labelling field UAE/IAE (ISDN) 1 gang studio white matt - 63x63	1803-884	1	sztuka
2CKA001710A3912	Cover plate with labelling field UAE/IAE (ISDN) 1 gang black matt - 63x63	1803-885	1	sztuka

2CKA002013A5404	Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter anthracite - 63x63	20 EUAB-81	1	sztuka
2CKA002013A5405	Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter ivory white - 63x63	20 EUAB-82	1	sztuka
2CKA002013A5406	Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter aluminium silver - 63x63	20 EUAB-83	1	sztuka
2CKA002013A5408	Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter stainless steel - Pure Stainless Steel	20 EUAB-866	1	sztuka
2CKA002013A5409	Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter studio white matt - 63x63	20 EUAB-884	1	sztuka
2CKA002013A5410	Busch-Object socket outlet SCHUKO® socket insert Without imprint Safety Shutter black matt - 63x63	20 EUAB-885	1	sztuka
2CKA002011A6260	SCHUKO® Socket insert with legend SV green - 63x63	20 EUC-13-82-101	1	sztuka
2CKA002011A3723	SCHUKO® Socket insert with legend ZSV orange - 63x63	20 EUC-14-82	1	sztuka
2CKA002011A6216	Socket Outlets Without imprint grey metallic - 63x63	20 EUC-803-500	1	sztuka
2CKA002011A6215	Socket Outlets Without imprint anthracite - 63x63	20 EUC-81-500	1	sztuka
2CKA002011A6214	Socket Outlets Without imprint ivory white - 63x63	20 EUC-82-500	1	sztuka
2CKA002011A6213	Socket Outlets Without imprint aluminium silver - 63x63	20 EUC-83-500	1	sztuka
2CKA002011A6212	Socket Outlets Without imprint stainless steel - Pure Stainless Steel	20 EUC-866-500	1	sztuka
2CKA002011A6208	Socket Outlets Without imprint studio white matt - 63x63	20 EUC-884-500	1	sztuka
2CKA002011A6211	Socket Outlets Without imprint black matt - 63x63	20 EUC-885-500	1	sztuka
2CKA002013A5472	SCHUKO® Socket insert with legend SV Safety Shutter green - 63x63	20 EUCB-13-82-102	1	sztuka
2CKA002013A5413	SCHUKO® Socket insert with legend ZSV Safety Shutter orange - 63x63	20 EUCB-14-82-10	1	sztuka
2CKA002013A5414	Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter grey metallic - 63x63	20 EUCBDR-803	1	sztuka
2CKA002013A5415	Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter anthracite - 63x63	20 EUCBDR-81	1	sztuka
2CKA002013A5416	Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter ivory white - 63x63	20 EUCBDR-82	1	sztuka
2CKA002013A5417	Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter aluminium silver - 63x63	20 EUCBDR-83	1	sztuka
2CKA002013A5419	Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter stainless steel - Pure Stainless Steel	20 EUCBDR-866	1	sztuka
2CKA002013A5420	Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter studio white matt - 63x63	20 EUCBDR-884	1	sztuka

2CKA002013A5421	Busch-Service-Socket SCHUKO® socket insert Without imprint Safety Shutter black matt - 63x63	20 EUCBDR-885	1	sztuka
2CKA002013A5456	SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green grey metallic - 63x63	20 EUCBL-803	1	sztuka
2CKA002013A5457	SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green anthracite - 63x63	20 EUCBL-81	1	sztuka
2CKA002013A5284	SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green ivory white - 63x63	20 EUCBL-82	1	sztuka
2CKA002013A5285	SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green aluminium silver - 63x63	20 EUCBL-83	1	sztuka
2CKA002013A5289	SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green stainless steel - Pure Stainless Steel	20 EUCBL-866	1	sztuka
2CKA002013A5336	SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green studio white matt - 63x63	20 EUCBL-884	1	sztuka
2CKA002013A5330	SCHUKO® socket insert Without imprint Safety Shutter withControl light; LED /Green black matt - 63x63	20 EUCBL-885	1	sztuka
2CKA002013A5458	Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White grey metallic - 63x63	20 EUCBLI-803	1	sztuka
2CKA002013A5459	Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White anthracite - 63x63	20 EUCBLI-81	1	sztuka
2CKA002013A5292	Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White ivory white - 63x63	20 EUCBLI-82	1	sztuka
2CKA002013A5293	Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White aluminium silver - 63x63	20 EUCBLI-83	1	sztuka
2CKA002013A5460	Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White stainless steel - Pure Stainless Steel	20 EUCBLI-866	1	sztuka
2CKA002013A5326	Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White studio white matt - 63x63	20 EUCBLI-884	1	sztuka
2CKA002013A5331	Busch-steplight SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) withNight light; LED /White black matt - 63x63	20 EUCBLI-885	1	sztuka
2CKA002013A5463	SCHUKO® socket insert Safety Shutter red - 63x63	20 EUCKS/DV-12-82-101	1	sztuka
2CKA002013A5462	SCHUKO® Socket insert with legend EDV Safety Shutter grey metallic - 63x63	20 EUCKS/DV-803	1	sztuka
2CKA002013A5266	SCHUKO® Socket insert with legend EDV Safety Shutter anthracite - 63x63	20 EUCKS/DV-81	1	sztuka

2CKA002013A5267	SCHUKO® Socket insert with legend EDV Safety 20 EUCKS/DV- Shutter ivory white - 63x63	82	1	sztuka
2CKA002013A5273	SCHUKO® Socket insert with legend EDV Safety 20 EUCKS/DV- Shutter aluminium silver - 63x63	83	1	sztuka
2CKA002013A5277	SCHUKO® Socket insert with legend EDV Safety 20 EUCKS/DV- Shutter stainless steel - Pure Stainless Steel	866	1	sztuka
2CKA002013A5327	SCHUKO® Socket insert with legend EDV Safety 20 EUCKS/DV- Shutter studio white matt - 63x63	884	1	sztuka
2CKA002013A5332	SCHUKO® Socket insert with legend EDV Safety 20 EUCKS/DV- Shutter black matt - 63x63	885	1	sztuka
2CKA002013A5464	SCHUKO® socket insert Without imprint Safety 20 EUCKS-12- Shutter red - 63x63	82-101	1	sztuka
2CKA002013A5470	SCHUKO® socket insert Without imprint Safety 20 EUCKS-13- Shutter green - 63x63	82-101	1	sztuka
2CKA002013A5324	SCHUKO® socket insert Without imprint Safety 20 EUCKS-14- Shutter orange - 63x63	82	1	sztuka
2CKA002013A5297	SCHUKO® socket insert Without imprint Safety 20 EUCKS-803 Shutter grey metallic - 63x63	803	1	sztuka
2CKA002013A5265	SCHUKO® socket insert Without imprint Safety 20 EUCKS-81 Shutter anthracite - 63x63	81	1	sztuka
2CKA002013A5376	Socket Outlets Without imprint Safety Shutter 20 EUCKS-82- ivory white - 63x63	500	1	sztuka
2CKA002013A5375	Socket Outlets Without imprint Safety Shutter 20 EUCKS-83- aluminium silver - 63x63	500	1	sztuka
2CKA002013A5374	Socket Outlets Without imprint Safety Shutter 20 EUCKS-866 stainless steel - Pure Stainless Steel	500	1	sztuka
2CKA002013A5373	Socket insert Without imprint Safety Shutter Protective contact (SCHUKO) studio white matt - 63x63	20 EUCKS-884 -500	1	sztuka
2CKA002013A5333	SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) black matt - 63x63	20 EUCKS-885 - 63x63	1	sztuka
2CKA002013A5423	SCHUKO® Socket insert with labelling field 20 EUCNB-12- Without imprint Safety Shutter red - 63x63	82	1	sztuka
2CKA002013A5424	SCHUKO® Socket insert with labelling field 20 EUCNB-13- Without imprint Safety Shutter green - 63x63	82	1	sztuka
2CKA002013A5425	SCHUKO® Socket insert with labelling field 20 EUCNB-14- Without imprint Safety Shutter orange - 63x63	82	1	sztuka
2CKA002013A5426	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter grey metallic - 63x63	20 EUCNB-803	1	sztuka
2CKA002013A5427	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter anthracite - 63x63	20 EUCNB-81	1	sztuka
2CKA002013A5428	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter ivory white - 63x63	20 EUCNB-82	1	sztuka
2CKA002013A5429	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter aluminium silver - 63x63	20 EUCNB-83	1	sztuka
2CKA002013A5432	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter stainless steel - Pure Stainless Steel	20 EUCNB-866	1	sztuka
2CKA002013A5433	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter studio white matt - 63x63	20 EUCNB-884	1	sztuka

2CKA002013A5434	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter black matt - 63x63	20 EUCNB-885	1	sztuka
2CKA002013A5436	SCHUKO® socket insert Without imprint Safety Shutter Protective contact (SCHUKO) grey metallic - 63x63	20 EUCRB-803	1	sztuka
2CKA002013A5437	SCHUKO® socket insert Without imprint Safety Shutter anthracite - 63x63	20 EUCRB-81	1	sztuka
2CKA002013A5438	SCHUKO® socket insert Without imprint Safety Shutter ivory white - 63x63	20 EUCRB-82	1	sztuka
2CKA002013A5439	SCHUKO® socket insert Without imprint Safety Shutter aluminium silver - 63x63	20 EUCRB-83	1	sztuka
2CKA002013A5442	SCHUKO® socket insert Without imprint Safety Shutter stainless steel - Pure Stainless Steel	20 EUCRB-866	1	sztuka
2CKA002013A5443	SCHUKO® socket insert Without imprint Safety Shutter studio white matt - 63x63	20 EUCRB-884	1	sztuka
2CKA002013A5444	SCHUKO® socket insert Without imprint Safety Shutter black matt - 63x63	20 EUCRB-885	1	sztuka
2CKA002018A1493	SCHUKO® socket insert Without imprint with Hinged Lid grey metallic - 63x63	20 EUK-803	1	sztuka
2CKA002018A1486	SCHUKO® socket insert Without imprint with Hinged Lid anthracite - 63x63	20 EUK-81	1	sztuka
2CKA002018A1465	SCHUKO® socket insert Without imprint with Hinged Lid ivory white - 63x63	20 EUK-82	1	sztuka
2CKA002018A1487	SCHUKO® socket insert Without imprint with Hinged Lid aluminium silver - 63x63	20 EUK-83	1	sztuka
2CKA002018A1490	SCHUKO® socket insert Without imprint with Hinged Lid stainless steel - Pure Stainless Steel	20 EUK-866	1	sztuka
2CKA002018A1494	SCHUKO® socket insert Without imprint with Hinged Lid studio white matt - 63x63	20 EUK-884	1	sztuka
2CKA002018A1495	SCHUKO® socket insert Without imprint with Hinged Lid black matt - 63x63	20 EUK-885	1	sztuka
2CKA002018A1516	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid grey metallic - 63x63	20 EUKB-803	1	sztuka
2CKA002018A1517	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid anthracite - 63x63	20 EUKB-81	1	sztuka
2CKA002018A1518	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid ivory white - 63x63	20 EUKB-82	1	sztuka
2CKA002018A1519	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid aluminium silver - 63x63	20 EUKB-83	1	sztuka
2CKA002018A1521	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid stainless steel - Pure Stainless Steel	20 EUKB-866	1	sztuka
2CKA002018A1522	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid studio white matt - 63x63	20 EUKB-884	1	sztuka
2CKA002018A1523	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid black matt - 63x63	20 EUKB-885	1	sztuka
2CKA002018A1525	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid grey metallic - 63x63	20 EUKBR-803	1	sztuka
2CKA002018A1526	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid anthracite - 63x63	20 EUKBR-81	1	sztuka
2CKA002018A1527	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid ivory white - 63x63	20 EUKBR-82	1	sztuka
2CKA002018A1528	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid aluminium silver - 63x63	20 EUKBR-83	1	sztuka

2CKA002018A1530	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid studio white matt - 63x63	20 EUKBR-884	1	sztuka
2CKA002018A1531	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid black matt - 63x63	20 EUKBR-885	1	sztuka
2CKA002018A1533	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid red - 63x63	20 EUKNB-12-82	1	sztuka
2CKA002018A1534	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid green - 63x63	20 EUKNB-13-82	1	sztuka
2CKA002018A1535	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid orange - 63x63	20 EUKNB-14-82	1	sztuka
2CKA002018A1536	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid grey metallic - 63x63	20 EUKNB-803	1	sztuka
2CKA002018A1537	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid anthracite - 63x63	20 EUKNB-81	1	sztuka
2CKA002018A1538	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid ivory white - 63x63	20 EUKNB-82	1	sztuka
2CKA002018A1539	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid aluminium silver - 63x63	20 EUKNB-83	1	sztuka
2CKA002018A1541	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid studio white matt - 63x63	20 EUKNB-884	1	sztuka
2CKA002018A1542	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid black matt - 63x63	20 EUKNB-885	1	sztuka
2CKA002018A1544	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid red - 63x63	20 EUKNBL-12-82	1	sztuka
2CKA002018A1545	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid green - 63x63	20 EUKNBL-13-82	1	sztuka
2CKA002018A1546	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid orange - 63x63	20 EUKNBL-14-82	1	sztuka
2CKA002018A1547	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid grey metallic - 63x63	20 EUKNBL-803	1	sztuka
2CKA002018A1548	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid anthracite - 63x63	20 EUKNBL-81	1	sztuka
2CKA002018A1552	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid studio white matt - 63x63	20 EUKNBL-884	1	sztuka
2CKA002018A1553	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid black matt - 63x63	20 EUKNBL-885	1	sztuka
2CKA002018A1557	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking anthracite - 63x63	20 EUKNBSL-81	1	sztuka

2CKA002018A1558	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking anthracite - 63x63	20 EUKNBSL- 81-101	1	sztuka
2CKA002018A1559	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking ivory white - 63x63	20 EUKNBSL- 82	1	sztuka
2CKA002018A1560	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking ivory white - 63x63	20 EUKNBSL- 82-101	1	sztuka
2CKA002018A1561	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking aluminium silver - 63x63	20 EUKNBSL- 83	1	sztuka
2CKA002018A1562	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking aluminium silver - 63x63	20 EUKNBSL- 83-101	1	sztuka
2CKA002018A1565	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking studio white matt - 63x63	20 EUKNBSL- 884	1	sztuka
2CKA002018A1566	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking studio white matt - 63x63	20 EUKNBSL- 884-101	1	sztuka
2CKA002018A1567	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking black matt - 63x63	20 EUKNBSL- 885	1	sztuka
2CKA002018A1568	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking black matt - 63x63	20 EUKNBSL- 885-101	1	sztuka
2CKA002011A3876	SCHUKO® Socket insert with labelling field Without imprint grey metallic - 63x63	20 EUN-803	1	sztuka
2CKA002011A3802	SCHUKO® Socket insert with labelling field Without imprint anthracite - 63x63	20 EUN-81	1	sztuka
2CKA002011A3726	SCHUKO® Socket insert with labelling field Without imprint ivory white - 63x63	20 EUN-82	1	sztuka
2CKA002011A3810	SCHUKO® Socket insert with labelling field Without imprint aluminium silver - 63x63	20 EUN-83	1	sztuka
2CKA002011A3851	SCHUKO® Socket insert with labelling field Without imprint stainless steel - Pure Stainless Steel	20 EUN-866	1	sztuka
2CKA002011A3881	SCHUKO® Socket insert with labelling field Without imprint studio white matt - 63x63	20 EUN-884	1	sztuka
2CKA002011A3884	SCHUKO® Socket insert with labelling field Without imprint black matt - 63x63	20 EUN-885	1	sztuka
2CKA002495A0084	Equipotential socket insert Socket outlet 2- position anthracite - 63x63	2095 UC-81	1	sztuka
2CKA002495A0085	Equipotential socket insert Socket outlet 2- position ivory white - 63x63	2095 UC-82	1	sztuka
2CKA002495A0089	Equipotential socket insert Socket outlet 2- position aluminium silver - 63x63	2095 UC-83	1	sztuka

2CKA002495A0090	Equipotential socket insert Socket outlet 2-position stainless steel - Pure Stainless Steel	2095 UC-866	1	sztuka
2CKA002495A0091	Equipotential socket insert Socket outlet 2-position studio white matt - 63x63	2095 UC-884	1	sztuka
2CKA002495A0092	Equipotential socket insert Socket outlet 2-position black matt - 63x63	2095 UC-885	1	sztuka
2CKA002190A0213	Socket Outlets Without imprint British Standard ivory - carat	2190 EUC-82	1	sztuka
2CKA002013A5475	SCHUKO® socket insert Without imprint Safety Shutter ivory white - 63x63	23 EUCB-82	1	sztuka
2CKA002013A5449	SCHUKO® socket insert Without imprint Safety Shutter ivory white - 63x63	2300 EUCB-82	1	sztuka
2CKA002113A0510	Socket Outlets Without imprint Safety Shutter ivory white - 63x63	2300 UCRKS-82-503	1	sztuka
2CKA002011A3831	Busch-Protector® SCHUKO® socket insert Without imprint ivory white - 63x63	2310 EUGL/VA-82-11	1	sztuka
2CKA002099A0197	2397 UCKS-82-505 Center PI, SF for 2300	2397 UCKS-82-505	1	sztuka
2CKA002013A5359	2398 CKS-82 Cover plate shuttered	2398 CKS-82	1	sztuka
2CKA002099A0211	Socket Outlets Without imprint Safety Shutter ivory white - 63x63	2399 UCKS-82	1	sztuka
2CKA002099A0191	Socket Outlets Without imprint Safety Shutter ivory white - 63x63	2399 UCKS-82-505	1	sztuka
2CKA001719A0218	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring ivory white - 63x63	2518-WD-82	1	sztuka
2CKA001751A3177	Rocker with legend Symbol "bell" for Switch/push button, Single rocker ivory white - 63x63	2520 KI-82	1	sztuka
2CKA001751A3187	Rocker with legend Symbol "light" for Switch/push button, Single rocker ivory white - 63x63	2520 LI-82	1	sztuka
2CKA001724A4255	Cover plate Bore hole 1 gang ivory white - 63x63	2533-82	1	sztuka
2CKA001710A3645	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button ivory white - 63x63	2542 DR/01-82	1	sztuka
2CKA001710A3650	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button ivory white - 63x63	2542 DR/02-82	1	sztuka
2CKA001724A4400	Cover plate XLR 1 gang ivory white - 63x63	2553-82	1	sztuka
2CKA001753A0392	Cover plate Modular Jack ivory white - 63x63	2561-02-82	1	sztuka
2CKA001753A0401	Cover plate Modular Jack 1 gang ivory white - 63x63	2561-82	1	sztuka
2CKA003116A0661	FI-Schukomat SCHUKO® socket insert Without imprint Safety Shutter ivory white - 63x63	3120 EUCB-82	1	sztuka
2CKA003117A0005	Buschmat RCD - Insert RCD 30 mA ivory white - 63x63	3151 UC-82	1	sztuka
2CKA006115A0484	6108/61-82-500 Coverplate f. CE	6108/61-82-500	1	sztuka
2CKA006155A0061	6109/03-82-500 Coverplate f. RTC	6109/03-82-500	1	sztuka
2CKA006132A0377	Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° ivory white	6122/10-82-500	1	sztuka
2CKA006115A0206	6125/01-82-500 Control element 1g w. BAU	6125/01-82-500	1	sztuka
2CKA006115A0217	6125/02-82-500 Control element 1/2gang	6125/02-82-500	1	sztuka

2CKA006116A0196	6126/01-82-500 Control element 2g w. BAU	6126/01-82-500	1	sztuka
2CKA006116A0207	6126/02-82-500 Control element 2/4gang	6126/02-82-500	1	sztuka
2CKA006117A0222	6127/01-82-500 Control element 4g w. BAU	6127/01-82-500	1	sztuka
2CKA006117A0233	6127/02-82-500 Control element 4/8gang	6127/02-82-500	1	sztuka
2CKA006134A0332	6128/28-82-500 RTC Control element 2/4g	6128/28-82-500	1	sztuka
2CKA006135A0157	6129/01-82-500 Control element 3/6g w. IR	6129/01-82-500	1	sztuka
2CKA006430A0327	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind One-part rocker ivory white - 63x63	6430-82-102	1	sztuka
2CKA006430A0304	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate ivory white - 63x63	6435-82	1	sztuka
2CKA006470A0003	Cover plate None for Proximity switch One-part button ivory white - 63x63	6476-82	1	sztuka
2CKA006400A0057	Cover plate PowerDock 1 gang white - 63x63	6477-82	1	sztuka
2CKA006599A2951	Cover plate None for Dimmer Turn button with Neon lamp ivory white - 63x63	6540-82-102	1	sztuka
2CKA006599A2832	Cover plate None for Cooling Central cover plate ivory white - 63x63	6541-82	1	sztuka
2CKA006599A2831	Control Element None for Switch/dimmer Single push button ivory white - 63x63	6543-82-101	1	sztuka
2CKA006599A2907	Control Element None for Dimmer Two-part button with Neon lamp ivory white - 63x63	6545-82	1	sztuka
2CKA006730A0032	Electronic Controls 1 channel Radio Control ivory white - 63x63	6731-82-500	1	sztuka
2CKA006730A0033	Electronic Controls 2 channel Radio Control ivory white - 63x63	6732-82-500	1	sztuka
2CKA006730A0034	Electronic Controls 4 channel Radio Control ivory white - 63x63	6733-82-500	1	sztuka
2CKA006730A0134	Control Element None for Dimmer Two-part button beige - 63x63	6736 FoH-82	1	sztuka
2CKA006800A2830	Electronic Controls ivory white - 63x63	6815-82-101-500	1	sztuka
2CKA008200A0079	Cover plate Loudspeaker ivory white - 63x63	8253-82	1	sztuka
2CKA006220A0532	CP-FCC-82 C-plate Fan Coil	CP-FCC-82	1	sztuka
2CKA006220A0529	CP-RTC-82 C-plate RT sensor unit	CP-RTC-82	1	sztuka
2CKA006220A0530	MD-F-1.0.1-82 Movement detector	MD-F-1.0.1-82	1	sztuka
2CKA006200A0084	MSA-F-1.1.1-82-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-82-WL	1	sztuka
2CKA006220A0516	Electronic Controls ivory white - solo	SR-1-82	1	sztuka
2CKA006220A0521	Electronic Controls ivory white - solo	SR-2-82	1	sztuka
2CKA006220A0518	Electronic Controls ivory white - solo	SRB-1-82	1	sztuka
2CKA006220A0523	Electronic Controls ivory white - solo	SRB-2-82	1	sztuka
2CKA006220A0520	Electronic Controls ivory white - solo	SRD-1-82	1	sztuka
2CKA006220A0525	Electronic Controls ivory white - solo	SRD-2-L-82	1	sztuka
2CKA006220A0526	Electronic Controls ivory white - solo	SRD-2-R-82	1	sztuka

2CKA006220A0517	Electronic Controls ivory white - solo	SRL-1-82	1	sztuka
2CKA006220A0522	Electronic Controls ivory white - solo	SRL-2-L-82	1	sztuka
2CKA006220A0527	Electronic Controls ivory white - solo	SRL-2-R-82	1	sztuka
2CKA006220A0519	Electronic Controls ivory white - solo	SRS-1-82	1	sztuka
2CKA006220A0524	Electronic Controls ivory white - solo	SRS-2-L-82	1	sztuka
2CKA006220A0528	Electronic Controls ivory white - solo	SRS-2-R-82	1	sztuka
2CKA002190A0224	Socket Outlets Without imprint British Standard grey metallic - Busch-axcent	2190 EUC-803	1	sztuka
2CKA002190A0216	Socket Outlets Without imprint British Standard anthracite - 63x63	2190 EUC-81	1	sztuka
2CKA002190A0214	Socket Outlets Without imprint British Standard aluminium silver - 63x63	2190 EUC-83	1	sztuka
2CKA002190A0217	Socket Outlets Without imprint British Standard stainless steel - Pure Stainless Steel	2190 EUC-866	1	sztuka
2CKA002190A0218	Socket Outlets Without imprint British Standard studio white matt - 63x63	2190 EUC-884	1	sztuka
2CKA002013A5474	SCHUKO® socket insert Without imprint Safety Shutter anthracite - 63x63	23 EUCB-81	1	sztuka
2CKA002013A5476	SCHUKO® socket insert Without imprint Safety Shutter aluminium silver - 63x63	23 EUCB-83	1	sztuka
2CKA002013A5478	SCHUKO® socket insert Without imprint Safety Shutter stainless steel - Pure Stainless Steel	23 EUCB-866	1	sztuka
2CKA002013A5479	SCHUKO® socket insert Without imprint Safety Shutter studio white matt - 63x63	23 EUCB-884	1	sztuka
2CKA002013A5480	SCHUKO® socket insert Without imprint Safety Shutter black matt - 63x63	23 EUCB-885	1	sztuka
2CKA002013A5447	SCHUKO® socket insert Without imprint Safety Shutter grey metallic - 63x63	2300 EUCB- 803	1	sztuka
2CKA002013A5448	SCHUKO® socket insert Without imprint Safety Shutter anthracite - 63x63	2300 EUCB-81	1	sztuka
2CKA002013A5450	SCHUKO® socket insert Without imprint Safety Shutter aluminium silver - 63x63	2300 EUCB-83	1	sztuka
2CKA002013A5452	SCHUKO® socket insert Without imprint Safety Shutter stainless steel - Pure Stainless Steel	2300 EUCB- 866	1	sztuka
2CKA002013A5453	SCHUKO® socket insert Without imprint Safety Shutter studio white matt - 63x63	2300 EUCB- 884	1	sztuka
2CKA002013A5454	SCHUKO® socket insert Without imprint Safety Shutter black matt - 63x63	2300 EUCB- 885	1	sztuka
2CKA002113A5339	Socket Outlets Without imprint Safety Shutter anthracite - 63x63	2300 UCRKS- 81-503	1	sztuka
2CKA002113A5337	Socket Outlets Without imprint Safety Shutter studio white matt - 63x63	2300 UCRKS- 884-503	1	sztuka
2CKA002113A5340	Socket Outlets Without imprint Safety Shutter black matt - 63x63	2300 UCRKS- 885-503	1	sztuka
2CKA002011A6257	Busch-Protector® SCHUKO® socket insert Without imprint red - 63x63	2310 EUGL/VA -12-82-101	1	sztuka
2CKA002011A3830	Busch-Protector® SCHUKO® socket insert Without imprint anthracite - 63x63	2310 EUGL/VA -81-11	1	sztuka
2CKA002011A3832	Busch-Protector® SCHUKO® socket insert Without imprint aluminium silver - 63x63	2310 EUGL/VA -83-11	1	sztuka
2CKA002011A3877	Busch-Protector® SCHUKO® socket insert Without imprint grey metallic - 63x63	2310 EUGL/VA- 803-11	1	sztuka

2CKA002011A3853	Busch-Protector® SCHUKO® socket insert Without imprint stainless steel - Pure Stainless Steel	2310EUGLVA-866-11	1	sztuka
2CKA002011A3882	Busch-Protector® SCHUKO® socket insert Without imprint studio white matt - 63x63	2310EUGLVA-884-11	1	sztuka
2CKA002011A3885	Busch-Protector® SCHUKO® socket insert Without imprint black matt - 63x63	2310EUGLVA-885-11	1	sztuka
2CKA002013A5356	2398 CKS-803 Cover plate shuttered	2398 CKS-803	1	sztuka
2CKA002013A5357	2398 CKS-81 Cover plate shuttered	2398 CKS-81	1	sztuka
2CKA002013A5360	2398 CKS-83 Cover plate shuttered	2398 CKS-83	1	sztuka
2CKA002013A5363	2398 CKS-884 Cover plate shuttered	2398 CKS-884	1	sztuka
2CKA002013A5364	2398 CKS-885 Cover plate shuttered	2398 CKS-885	1	sztuka
2CKA002099A0253	Socket Outlets Without imprint Safety Shutter grey metallic - 63x63	2399 UCKS-803	1	sztuka
2CKA002099A0216	Socket Outlets Without imprint Safety Shutter anthracite - 63x63	2399 UCKS-81	1	sztuka
2CKA002099A0241	Socket Outlets Without imprint Safety Shutter aluminium silver - 63x63	2399 UCKS-83	1	sztuka
2CKA002099A0243	Socket Without imprint Safety Shutter stainless steel - Pure Stainless Steel	2399 UCKS-866	1	sztuka
2CKA002099A0255	Socket Outlets Without imprint Safety Shutter studio white matt - 63x63	2399 UCKS-884	1	sztuka
2CKA001751A3175	Rocker with legend Symbol "bell" for Switch/push button, Single rocker grey metallic - 63x63	2520 KI-803	1	sztuka
2CKA001751A3176	Rocker with legend Symbol "bell" for Switch/push button, Single rocker anthracite - 63x63	2520 KI-81	1	sztuka
2CKA001751A3178	Rocker with legend Symbol "bell" for Switch/push button, Single rocker aluminium silver - 63x63	2520 KI-83	1	sztuka
2CKA001751A3181	Rocker with legend Symbol "bell" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	2520 KI-866	1	sztuka
2CKA001751A3182	Rocker with legend Symbol "bell" for Switch/push button, Single rocker studio white matt - 63x63	2520 KI-884	1	sztuka
2CKA001751A3183	Rocker with legend Symbol "bell" for Switch/push button, Single rocker black matt - 63x63	2520 KI-885	1	sztuka
2CKA001751A3185	Rocker for Switch/push button, Single rocker grey metallic - 63x63	2520 LI-803	1	sztuka
2CKA001751A3186	Rocker with legend Symbol "light" for Switch/push button, Single rocker anthracite - 63x63	2520 LI-81	1	sztuka
2CKA001751A3188	Rocker with legend Symbol "light" for Switch/push button, Single rocker aluminium silver - 63x63	2520 LI-83	1	sztuka
2CKA001751A3191	Rocker with legend Symbol "light" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	2520 LI-866	1	sztuka
2CKA001751A3192	Rocker with legend Symbol "light" for Switch/push button, Single rocker studio white matt - 63x63	2520 LI-884	1	sztuka
2CKA001751A3193	Rocker with legend Symbol "light" for Switch/push button, Single rocker black matt - 63x63	2520 LI-885	1	sztuka
2CKA001751A3195	Rocker for Switch/push button, Single rocker grey metallic - 63x63	2520 TR-803	1	sztuka
2CKA001751A3196	Rocker with legend Symbol "key" for Switch/push button, Single rocker anthracite - 63x63	2520 TR-81	1	sztuka

2CKA001751A3197	Rocker with legend Symbol "key" for Switch/push button, Single rocker ivory white - 63x63	2520 TR-82	1	sztuka
2CKA001751A3198	Rocker with legend Symbol "key" for Switch/push button, Single rocker aluminium silver - 63x63	2520 TR-83	1	sztuka
2CKA001751A3200	Rocker with legend Symbol "key" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	2520 TR-866	1	sztuka
2CKA001751A3201	Rocker with legend Symbol "key" for Switch/push button, Single rocker studio white matt - 63x63	2520 TR-884	1	sztuka
2CKA001751A3202	Rocker with legend Symbol "key" for Switch/push button, Single rocker black matt - 63x63	2520 TR-885	1	sztuka
2CKA001724A4407	Cover plate Bore hole grey metallic - 63x63	2533-803	1	sztuka
2CKA001724A4254	Cover plate Bore hole 1 gang anthracite - 63x63	2533-81	1	sztuka
2CKA001724A4382	Cover plate Bore hole 1 gang yellow - 63x63	2533-82-15	1	sztuka
2CKA001724A4261	Cover plate Bore hole 1 gang aluminium silver - 63x63	2533-83	1	sztuka
2CKA001724A4270	Cover plate Bore hole 1 gang stainless steel - Pure Stainless Steel	2533-866	1	sztuka
2CKA001724A4296	Cover plate Bore hole 1 gang studio white matt - 63x63	2533-884	1	sztuka
2CKA001724A4301	Cover plate Bore hole 1 gang black matt - 63x63	2533-885	1	sztuka
2CKA001710A4125	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button grey metallic - 63x63	2542 DR/01-803	1	sztuka
2CKA001710A3644	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button anthracite - 63x63	2542 DR/01-81	1	sztuka
2CKA001710A3671	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button aluminium silver - 63x63	2542 DR/01-83	1	sztuka
2CKA001710A3758	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button stainless steel - Pure Stainless Steel	2542 DR/01-866	1	sztuka
2CKA001710A3890	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button studio white matt - 63x63	2542 DR/01-884	1	sztuka
2CKA001710A3913	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button black matt - 63x63	2542 DR/01-885	1	sztuka
2CKA001710A4126	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button grey metallic - 63x63	2542 DR/02-803	1	sztuka
2CKA001710A3649	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button anthracite - 63x63	2542 DR/02-81	1	sztuka
2CKA001710A3672	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button aluminium silver - 63x63	2542 DR/02-83	1	sztuka
2CKA001710A3759	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button stainless steel - Pure Stainless Steel	2542 DR/02-866	1	sztuka
2CKA001710A3891	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button studio white matt - 63x63	2542 DR/02-884	1	sztuka
2CKA001710A3914	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button black matt - 63x63	2542 DR/02-885	1	sztuka
2CKA001724A4398	Cover plate XLR grey metallic - 63x63	2553-803	1	sztuka
2CKA001724A4399	Cover plate XLR 1 gang anthracite - 63x63	2553-81	1	sztuka
2CKA001724A4401	Cover plate XLR 1 gang aluminium silver - 63x63	2553-83	1	sztuka
2CKA001724A4403	Cover plate XLR 1 gang stainless steel - Pure Stainless Steel	2553-866	1	sztuka

2CKA001724A4404	Cover plate XLR 1 gang studio white matt - 63x63	2553-884	1	sztuka
2CKA001724A4405	Cover plate XLR 1 gang black matt - 63x63	2553-885	1	sztuka
2CKA001753A0316	Cover plate Modular Jack 2 gang grey metallic - 63x63	2561-02-803	1	sztuka
2CKA001753A0317	Cover plate Modular Jack 2 gang anthracite - 63x63	2561-02-81	1	sztuka
2CKA001753A0393	Cover plate Modular Jack 2 gang aluminium silver - 63x63	2561-02-83	1	sztuka
2CKA001753A0395	Cover plate Modular Jack 2 gang stainless steel - Pure Stainless Steel	2561-02-866	1	sztuka
2CKA001753A0396	Cover plate Modular Jack 2 gang studio white matt - 63x63	2561-02-884	1	sztuka
2CKA001753A0397	Cover plate Modular Jack 2 gang black matt - 63x63	2561-02-885	1	sztuka
2CKA001753A0399	Cover plate Modular Jack 1 gang grey metallic - 63x63	2561-803	1	sztuka
2CKA001753A0400	Cover plate Modular Jack 1 gang anthracite - 63x63	2561-81	1	sztuka
2CKA001753A0402	Cover plate Modular Jack 1 gang aluminium silver - 63x63	2561-83	1	sztuka
2CKA001753A0404	Cover plate Modular Jack 1 gang stainless steel - Pure Stainless Steel	2561-866	1	sztuka
2CKA001753A0405	Cover plate Modular Jack 1 gang studio white matt - 63x63	2561-884	1	sztuka
2CKA001753A0406	Cover plate Modular Jack 1 gang black matt - 63x63	2561-885	1	sztuka
2CKA003116A0666	FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA grey metallic - 63x63	3120 EUCB-803	1	sztuka
2CKA003116A0667	FI-Schukomat SCHUKO® socket insert Without imprint Safety Shutter anthracite - 63x63	3120 EUCB-81	1	sztuka
2CKA003116A0668	FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA aluminium silver - 63x63	3120 EUCB-83	1	sztuka
2CKA003116A0669	FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA stainless steel - Pure Stainless Steel	3120 EUCB-866	1	sztuka
2CKA003116A0670	FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA studio white matt - 63x63	3120 EUCB-884	1	sztuka
2CKA003116A0671	FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA black matt - 63x63	3120 EUCB-885	1	sztuka
2CKA003117A0008	Buschmat RCD - Insert RCD 30 mA grey metallic - 63x63	3151 UC-803	1	sztuka
2CKA003117A0009	Buschmat RCD - Insert RCD 30 mA anthracite - 63x63	3151 UC-81	1	sztuka
2CKA003117A0010	Buschmat RCD - Insert RCD 30 mA aluminium silver - 63x63	3151 UC-83	1	sztuka
2CKA003117A0011	Buschmat RCD - Insert RCD 30 mA stainless steel - Pure Stainless Steel	3151 UC-866	1	sztuka
2CKA003117A0012	Buschmat RCD - Insert RCD 30 mA studio white matt - 63x63	3151 UC-884	1	sztuka
2CKA003117A0013	Buschmat RCD - Insert RCD 30 mA black matt - 63x63	3151 UC-885	1	sztuka

2CKA006115A0489	6108/61-803-500 Coverplate f. CE	6108/61-803-500	1	sztuka
2CKA006115A0483	6108/61-81-500 Coverplate f. CE	6108/61-81-500	1	sztuka
2CKA006115A0485	6108/61-83-500 Coverplate f. CE	6108/61-83-500	1	sztuka
2CKA006115A0492	6108/61-866-500 Coverplate f. CE	6108/61-866-500	1	sztuka
2CKA006115A0487	6108/61-884-500 Coverplate f. CE	6108/61-884-500	1	sztuka
2CKA006115A0488	6108/61-885-500 Coverplate f. CE	6108/61-885-500	1	sztuka
2CKA006155A0066	6109/03-803-500 Coverplate f. RTC	6109/03-803-500	1	sztuka
2CKA006155A0060	6109/03-81-500 Coverplate f. RTC	6109/03-81-500	1	sztuka
2CKA006155A0062	6109/03-83-500 Coverplate f. RTC	6109/03-83-500	1	sztuka
2CKA006155A0069	6109/03-866-500 Coverplate f. RTC	6109/03-866-500	1	sztuka
2CKA006155A0064	6109/03-884-500 Coverplate f. RTC	6109/03-884-500	1	sztuka
2CKA006155A0065	6109/03-885-500 Coverplate f. RTC	6109/03-885-500	1	sztuka
2CKA006132A0382	Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° grey metallic	6122/10-803-500	1	sztuka
2CKA006132A0376	Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° anthracite	6122/10-81-500	1	sztuka
2CKA006132A0378	Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° aluminium silver	6122/10-83-500	1	sztuka
2CKA006132A0385	Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° stainless steel	6122/10-866-500	1	sztuka
2CKA006132A0380	Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° studio white matt	6122/10-884-500	1	sztuka
2CKA006132A0381	Reflex SI / Busch-Duro 2000SI for Push Button Coupling Units Horizontal 0 ... 180 ° black matt	6122/10-885-500	1	sztuka
2CKA006115A0212	6125/01-803-500 Control element 1g w. BAU	6125/01-803-500	1	sztuka
2CKA006115A0205	6125/01-81-500 Control element 1g w. BAU	6125/01-81-500	1	sztuka
2CKA006115A0207	6125/01-83-500 Control element 1g w. BAU	6125/01-83-500	1	sztuka
2CKA006115A0211	6125/01-866-500 Control element 1g w. BAU	6125/01-866-500	1	sztuka
2CKA006115A0214	6125/01-884-500 Control element 1g w. BAU	6125/01-884-500	1	sztuka
2CKA006115A0215	6125/01-885-500 Control element 1g w. BAU	6125/01-885-500	1	sztuka
2CKA006115A0224	6125/02-803-500 Control element 1/2gang	6125/02-803-500	1	sztuka

2CKA006115A0216	6125/02-81-500 Control element 1/2gang	6125/02-81-500	1	sztuka
2CKA006115A0218	6125/02-83-500 Control element 1/2gang	6125/02-83-500	1	sztuka
2CKA006115A0223	6125/02-866-500 Control element 1/2gang	6125/02-866-500	1	sztuka
2CKA006115A0226	6125/02-884-500 Control element 1/2gang	6125/02-884-500	1	sztuka
2CKA006115A0227	6125/02-885-500 Control element 1/2gang	6125/02-885-500	1	sztuka
2CKA006116A0202	6126/01-803-500 Control element 2g w. BAU	6126/01-803-500	1	sztuka
2CKA006116A0195	6126/01-81-500 Control element 2g w. BAU	6126/01-81-500	1	sztuka
2CKA006116A0197	6126/01-83-500 Control element 2g w. BAU	6126/01-83-500	1	sztuka
2CKA006116A0201	6126/01-866-500 Control element 2g w. BAU	6126/01-866-500	1	sztuka
2CKA006116A0204	6126/01-884-500 Control element 2g w. BAU	6126/01-884-500	1	sztuka
2CKA006116A0205	6126/01-885-500 Control element 2g w. BAU	6126/01-885-500	1	sztuka
2CKA006116A0214	6126/02-803-500 Control element 2/4gang	6126/02-803-500	1	sztuka
2CKA006116A0206	6126/02-81-500 Control element 2/4gang	6126/02-81-500	1	sztuka
2CKA006116A0208	6126/02-83-500 Control element 2/4gang	6126/02-83-500	1	sztuka
2CKA006116A0213	6126/02-866-500 Control element 2/4gang	6126/02-866-500	1	sztuka
2CKA006116A0216	6126/02-884-500 Control element 2/4gang	6126/02-884-500	1	sztuka
2CKA006116A0217	6126/02-885-500 Control element 2/4gang	6126/02-885-500	1	sztuka
2CKA006117A0228	6127/01-803-500 Control element 4g w. BAU	6127/01-803-500	1	sztuka
2CKA006117A0221	6127/01-81-500 Control element 4g w. BAU	6127/01-81-500	1	sztuka
2CKA006117A0223	6127/01-83-500 Control element 4g w. BAU	6127/01-83-500	1	sztuka
2CKA006117A0227	6127/01-866-500 Control element 4g w. BAU	6127/01-866-500	1	sztuka
2CKA006117A0230	6127/01-884-500 Control element 4g w. BAU	6127/01-884-500	1	sztuka
2CKA006117A0231	6127/01-885-500 Control element 4g w. BAU	6127/01-885-500	1	sztuka
2CKA006117A0240	6127/02-803-500 Control element 4/8gang	6127/02-803-500	1	sztuka
2CKA006117A0232	6127/02-81-500 Control element 4/8gang	6127/02-81-500	1	sztuka
2CKA006117A0234	6127/02-83-500 Control element 4/8gang	6127/02-83-500	1	sztuka
2CKA006117A0239	6127/02-866-500 Control element 4/8gang	6127/02-866-500	1	sztuka

2CKA006117A0242	6127/02-884-500 Control element 4/8gang	6127/02-884-500	1	sztuka
2CKA006117A0243	6127/02-885-500 Control element 4/8gang	6127/02-885-500	1	sztuka
2CKA006134A0336	6128/28-803-500 RTC Control element 2/4g	6128/28-803-500	1	sztuka
2CKA006134A0331	6128/28-81-500 RTC Control element 2/4g	6128/28-81-500	1	sztuka
2CKA006134A0333	6128/28-83-500 RTC Control element 2/4g	6128/28-83-500	1	sztuka
2CKA006134A0335	6128/28-866-500 RTC Control element 2/4g	6128/28-866-500	1	sztuka
2CKA006134A0338	6128/28-884-500 RTC Control element 2/4g	6128/28-884-500	1	sztuka
2CKA006134A0339	6128/28-885-500 RTC Control element 2/4g	6128/28-885-500	1	sztuka
2CKA006135A0163	6129/01-803-500 Control element 3/6g w. IR	6129/01-803-500	1	sztuka
2CKA006135A0156	6129/01-81-500 Control element 3/6g w. IR	6129/01-81-500	1	sztuka
2CKA006135A0158	6129/01-83-500 Control element 3/6g w. IR	6129/01-83-500	1	sztuka
2CKA006135A0162	6129/01-866-500 Control element 3/6g w. IR	6129/01-866-500	1	sztuka
2CKA006135A0165	6129/01-884-500 Control element 3/6g w. IR	6129/01-884-500	1	sztuka
2CKA006135A0166	6129/01-885-500 Control element 3/6g w. IR	6129/01-885-500	1	sztuka
2CKA006430A0350	Control Element Symbol "arrows" for Venetian blind grey metallic - 63x63	6430-803-102	1	sztuka
2CKA006430A0326	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind One-part rocker anthracite - 63x63	6430-81-102	1	sztuka
2CKA006430A0328	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind One-part rocker aluminium silver - 63x63	6430-83-102	1	sztuka
2CKA006430A0343	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind One-part rocker stainless steel - Pure Stainless Steel	6430-866-102	1	sztuka
2CKA006430A0385	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind One-part rocker studio white matt - 63x63	6430-884-102	1	sztuka
2CKA006430A0386	Busch-Jalousiecontrol® II Control element with legend Symbol "arrows" for Venetian blind One-part rocker black matt - 63x63	6430-885-102	1	sztuka
2CKA006430A0351	Cover plate with legend Various symbols for Time switch Central cover plate grey metallic - 63x63	6435-803	1	sztuka
2CKA006430A0303	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate anthracite - 63x63	6435-81	1	sztuka
2CKA006430A0305	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate aluminium silver - 63x63	6435-83	1	sztuka

2CKA006430A0344	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate stainless steel - Pure Stainless Steel	6435-866	1	sztuka
2CKA006430A0388	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate studio white matt - 63x63	6435-884	1	sztuka
2CKA006430A0389	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate black matt - 63x63	6435-885	1	sztuka
2CKA006470A0006	Cover plate Symbol "key/door" for Proximity switch One-part button grey metallic - 63x63	6476-803	1	sztuka
2CKA006470A0008	Cover plate None for Proximity switch One-part button aluminium silver - 63x63	6476-83	1	sztuka
2CKA006470A0009	Cover plate None for Proximity switch One-part button stainless steel - Pure Stainless Steel	6476-866	1	sztuka
2CKA006470A0010	Cover plate None for Proximity switch One-part button studio white matt - 63x63	6476-884	1	sztuka
2CKA006470A0011	Cover plate None for Proximity switch One-part button black matt - 63x63	6476-885	1	sztuka
2CKA006400A0060	Cover plate PowerDock 1 gang grey metallic - 63x63	6477-803	1	sztuka
2CKA006400A0056	Cover plate PowerDock 1 gang anthracite - 63x63	6477-81	1	sztuka
2CKA006400A0058	Cover plate PowerDock 1 gang aluminium silver - 63x63	6477-83	1	sztuka
2CKA006400A0064	Cover plate PowerDock 1 gang stainless steel - Pure Stainless Steel	6477-866	1	sztuka
2CKA006400A0062	Cover plate PowerDock 1 gang studio white matt - 63x63	6477-884	1	sztuka
2CKA006400A0063	Cover plate PowerDock 1 gang black matt - 63x63	6477-885	1	sztuka
2CKA006599A2980	Cover plate None for Dimmer Turn button with Neon lamp grey metallic - 63x63	6540-803-102	1	sztuka
2CKA006599A2950	Cover plate None for Dimmer Turn button with Neon lamp anthracite - 63x63	6540-81-102	1	sztuka
2CKA006599A2952	Cover plate None for Dimmer Turn button with Neon lamp aluminium silver - 63x63	6540-83-102	1	sztuka
2CKA006599A2959	Cover plate None for Dimmer Turn button with Neon lamp stainless steel - Pure Stainless Steel	6540-866-102	1	sztuka
2CKA006599A2961	Cover plate None for Dimmer Turn button with Neon lamp studio white matt - 63x63	6540-884-102	1	sztuka
2CKA006599A2966	Cover plate None for Dimmer Turn button with Neon lamp black matt - 63x63	6540-885-102	1	sztuka
2CKA006599A2882	Cover plate None for Cooling Central cover plate anthracite - 63x63	6541-81	1	sztuka
2CKA006599A2885	Cover plate None for Cooling Central cover plate aluminium silver - 63x63	6541-83	1	sztuka
2CKA006599A2924	Cover plate None for Cooling Central cover plate stainless steel - Pure Stainless Steel	6541-866	1	sztuka
2CKA006599A2962	Cover plate None for Cooling Central cover plate studio white matt - 63x63	6541-884	1	sztuka
2CKA006599A2967	Cover plate None for Cooling Central cover plate black matt - 63x63	6541-885	1	sztuka
2CKA006599A2881	Control Element None for Switch/dimmer Single push button anthracite - 63x63	6543-81-101	1	sztuka

2CKA006599A2887	Control Element None for Switch/dimmer Single push button aluminium silver - 63x63	6543-83-101	1	sztuka
2CKA006599A2926	Control Element None for Switch/dimmer Single push button stainless steel - Pure Stainless Steel	6543-866-101	1	sztuka
2CKA006599A2963	Control Element None for Switch/dimmer Single push button studio white matt - 63x63	6543-884-101	1	sztuka
2CKA006599A2968	Control Element None for Switch/dimmer Single push button black matt - 63x63	6543-885-101	1	sztuka
2CKA006599A2943	Control Element None for Dimmer Two-part button with Neon lamp grey metallic - 63x63	6545-803	1	sztuka
2CKA006599A2906	Control Element None for Dimmer Two-part button with Neon lamp anthracite - 63x63	6545-81	1	sztuka
2CKA006599A2914	Control Element None for Dimmer Two-part button with Neon lamp aluminium silver - 63x63	6545-83	1	sztuka
2CKA006599A2927	Control Element None for Dimmer Two-part button with Neon lamp stainless steel - Pure Stainless Steel	6545-866	1	sztuka
2CKA006599A2964	Control Element None for Dimmer Two-part button with Neon lamp studio white matt - 63x63	6545-884	1	sztuka
2CKA006599A2969	Control Element None for Dimmer Two-part button with Neon lamp black matt - 63x63	6545-885	1	sztuka
2CKA006730A0035	Electronic Controls 1 channel Radio Control aluminium silver - 63x63	6731-83-500	1	sztuka
2CKA006730A0041	WaveLine Electronic Controls 1 channel Radio Control stainless steel - Pure Stainless Steel	6731-866-500	1	sztuka
2CKA006730A0036	Electronic Controls 2 channel Radio Control aluminium silver - 63x63	6732-83-500	1	sztuka
2CKA006730A0042	Wall sensor 2 channel Radio Control stainless steel - Pure Stainless Steel	6732-866-500	1	sztuka
2CKA006730A0037	Electronic Controls 4 channel Radio Control aluminium silver - 63x63	6733-83-500	1	sztuka
2CKA006730A0043	Electronic Controls 4 channel Radio Control stainless steel - Pure Stainless Steel	6733-866-500	1	sztuka
2CKA006730A0141	Control Element None for Dimmer Two-part button black matt - 63x63	6736 FoH-885	1	sztuka
2CKA006800A2832	Electronic Controls aluminium silver - 63x63	6815-83-101-500	1	sztuka
2CKA006800A2843	Electronic Controls stainless steel - Pure Stainless Steel	6815-866-101-500	1	sztuka
2CKA008200A0253	Cover plate with legend Radio 0 gang aluminium silver - 63x63	8252-83-101-500	1	sztuka
2CKA008200A0264	Cover plate with legend Radio 0 gang stainless steel - Pure Stainless Steel	8252-866-101-500	1	sztuka
2CKA008200A0261	Cover plate with legend Radio 0 gang black matt - 63x63	8252-885-101-500	1	sztuka
2CKA008200A0115	Cover plate Loudspeaker grey metallic - 63x63	8253-803	1	sztuka
2CKA008200A0078	Cover plate Loudspeaker anthracite - 63x63	8253-81	1	sztuka
2CKA008200A0080	Cover plate Loudspeaker aluminium silver - 63x63	8253-83	1	sztuka
2CKA008200A0087	Cover plate Loudspeaker stainless steel - Pure Stainless Steel	8253-866	1	sztuka
2CKA008200A0123	Cover plate Loudspeaker studio white matt - 63x63	8253-884	1	sztuka

2CKA008200A0126	Cover plate Loudspeaker black matt - 63x63	8253-885	1	sztuka
2CKA008300A0226	83260-81-515 Cover plates, Indoor St.	83260-81-515	1	sztuka
2CKA006220A0566	CP-FCC-803 C-plate Fan Coil	CP-FCC-803	1	sztuka
2CKA006220A0242	CP-FCC-81 C-plate Fan Coil	CP-FCC-81	1	sztuka
2CKA006220A0243	CP-FCC-83 C-plate Fan Coil	CP-FCC-83	1	sztuka
2CKA006220A0549	CP-FCC-866 C-plate Fan Coil	CP-FCC-866	1	sztuka
2CKA006220A0617	CP-FCC-884 C-plate Fan Coil	CP-FCC-884	1	sztuka
2CKA006220A0634	CP-FCC-885 C-plate Fan Coil	CP-FCC-885	1	sztuka
2CKA006220A0563	CP-RTC-803 C-plate RT sensor unit	CP-RTC-803	1	sztuka
2CKA006220A0179	CP-RTC-81 C-plate RT sensor unit	CP-RTC-81	1	sztuka
2CKA006220A0180	CP-RTC-83 C-plate RT sensor unit	CP-RTC-83	1	sztuka
2CKA006220A0546	CP-RTC-866 C-plate RT sensor unit	CP-RTC-866	1	sztuka
2CKA006220A0614	CP-RTC-884 C-plate RT sensor unit	CP-RTC-884	1	sztuka
2CKA006220A0631	CP-RTC-885 C-plate RT sensor unit	CP-RTC-885	1	sztuka
2CKA006220A0564	MD-F-1.0.1-803 Movement detector	MD-F-1.0.1-803	1	sztuka
2CKA006220A0212	MD-F-1.0.1-81 Movement detector	MD-F-1.0.1-81	1	sztuka
2CKA006220A0213	MD-F-1.0.1-83 Movement detector	MD-F-1.0.1-83	1	sztuka
2CKA006220A0547	MD-F-1.0.1-866 Movement detector	MD-F-1.0.1-866	1	sztuka
2CKA006220A0615	MD-F-1.0.1-884 Movement detector	MD-F-1.0.1-884	1	sztuka
2CKA006220A0632	MD-F-1.0.1-885 Movement detector	MD-F-1.0.1-885	1	sztuka
2CKA006220A0565	MSA-F-1.1.1-803 Mov. detector/actuator 1g	MSA-F-1.1.1-803	1	sztuka
2CKA006220A0215	MSA-F-1.1.1-81 Mov. detector/actuator 1g	MSA-F-1.1.1-81	1	sztuka
2CKA006200A0083	MSA-F-1.1.1-81-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-81-WL	1	sztuka
2CKA006220A0216	MSA-F-1.1.1-83 Mov. detector/actuator 1g	MSA-F-1.1.1-83	1	sztuka
2CKA006200A0085	MSA-F-1.1.1-83-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-83-WL	1	sztuka
2CKA006220A0548	MSA-F-1.1.1-866 Mov. detector/actuator 1g	MSA-F-1.1.1-866	1	sztuka
2CKA006220A0616	MSA-F-1.1.1-884 Mov. detector/actuator 1g	MSA-F-1.1.1-884	1	sztuka
2CKA006200A0097	MSA-F-1.1.1-884-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-884-WL	1	sztuka
2CKA006220A0633	MSA-F-1.1.1-885 Mov. detector/actuator 1g	MSA-F-1.1.1-885	1	sztuka
2CKA006200A0098	MSA-F-1.1.1-885-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-885-WL	1	sztuka
2CKA006220A0550	Electronic Controls grey metallic - 63x63	SR-1-803	1	sztuka
2CKA006220A0137	Electronic Controls anthracite - 63x63	SR-1-81	1	sztuka
2CKA006220A0138	Electronic Controls aluminium silver - 63x63	SR-1-83	1	sztuka
2CKA006220A0533	Electronic Controls stainless steel - solo	SR-1-866	1	sztuka
2CKA006220A0601	Electronic Controls studio white matt - 63x63	SR-1-884	1	sztuka

2CKA006220A0618	Electronic Controls black matt - 63x63	SR-1-885	1	sztuka
2CKA006220A0555	Electronic Controls grey metallic - 63x63	SR-2-803	1	sztuka
2CKA006220A0152	Electronic Controls anthracite - 63x63	SR-2-81	1	sztuka
2CKA006220A0153	Electronic Controls aluminium silver - 63x63	SR-2-83	1	sztuka
2CKA006220A0538	Electronic Controls stainless steel - solo	SR-2-866	1	sztuka
2CKA006220A0606	Electronic Controls studio white matt - 63x63	SR-2-884	1	sztuka
2CKA006220A0623	Electronic Controls black matt - 63x63	SR-2-885	1	sztuka
2CKA006220A0552	Electronic Controls grey metallic - 63x63	SRB-1-803	1	sztuka
2CKA006220A0143	Electronic Controls anthracite - 63x63	SRB-1-81	1	sztuka
2CKA006220A0144	Electronic Controls aluminium silver - 63x63	SRB-1-83	1	sztuka
2CKA006220A0535	Electronic Controls stainless steel - solo	SRB-1-866	1	sztuka
2CKA006220A0603	Electronic Controls studio white matt - 63x63	SRB-1-884	1	sztuka
2CKA006220A0620	Electronic Controls black matt - 63x63	SRB-1-885	1	sztuka
2CKA006220A0557	Electronic Controls grey metallic - 63x63	SRB-2-803	1	sztuka
2CKA006220A0158	Electronic Controls anthracite - 63x63	SRB-2-81	1	sztuka
2CKA006220A0159	Electronic Controls aluminium silver - 63x63	SRB-2-83	1	sztuka
2CKA006220A0540	Electronic Controls stainless steel - solo	SRB-2-866	1	sztuka
2CKA006220A0608	Electronic Controls studio white matt - 63x63	SRB-2-884	1	sztuka
2CKA006220A0625	Electronic Controls black matt - 63x63	SRB-2-885	1	sztuka
2CKA006220A0554	Electronic Controls grey metallic - 63x63	SRD-1-803	1	sztuka
2CKA006220A0149	Electronic Controls anthracite - 63x63	SRD-1-81	1	sztuka
2CKA006220A0150	Electronic Controls aluminium silver - 63x63	SRD-1-83	1	sztuka
2CKA006220A0537	Electronic Controls stainless steel - solo	SRD-1-866	1	sztuka
2CKA006220A0605	Electronic Controls studio white matt - 63x63	SRD-1-884	1	sztuka
2CKA006220A0622	Electronic Controls black matt - 63x63	SRD-1-885	1	sztuka
2CKA006220A0559	Electronic Controls grey metallic - 63x63	SRD-2-L-803	1	sztuka
2CKA006220A0164	Electronic Controls anthracite - 63x63	SRD-2-L-81	1	sztuka
2CKA006220A0165	Electronic Controls aluminium silver - 63x63	SRD-2-L-83	1	sztuka
2CKA006220A0542	Electronic Controls stainless steel - solo	SRD-2-L-866	1	sztuka
2CKA006220A0610	Electronic Controls studio white matt - 63x63	SRD-2-L-884	1	sztuka
2CKA006220A0627	Electronic Controls black matt - 63x63	SRD-2-L-885	1	sztuka
2CKA006220A0560	Electronic Controls grey metallic - 63x63	SRD-2-R-803	1	sztuka
2CKA006220A0258	Electronic Controls anthracite - 63x63	SRD-2-R-81	1	sztuka
2CKA006220A0259	Electronic Controls aluminium silver - 63x63	SRD-2-R-83	1	sztuka
2CKA006220A0543	Electronic Controls stainless steel - solo	SRD-2-R-866	1	sztuka
2CKA006220A0611	Electronic Controls studio white matt - 63x63	SRD-2-R-884	1	sztuka
2CKA006220A0628	Electronic Controls black matt - 63x63	SRD-2-R-885	1	sztuka
2CKA006220A0551	Electronic Controls grey metallic - 63x63	SRL-1-803	1	sztuka
2CKA006220A0140	Electronic Controls anthracite - 63x63	SRL-1-81	1	sztuka
2CKA006220A0141	Electronic Controls aluminium silver - 63x63	SRL-1-83	1	sztuka
2CKA006220A0534	Electronic Controls stainless steel - solo	SRL-1-866	1	sztuka
2CKA006220A0602	Electronic Controls studio white matt - 63x63	SRL-1-884	1	sztuka
2CKA006220A0619	Electronic Controls black matt - 63x63	SRL-1-885	1	sztuka
2CKA006220A0556	Electronic Controls grey metallic - 63x63	SRL-2-L-803	1	sztuka

2CKA006220A0155	Electronic Controls anthracite - 63x63	SRL-2-L-81	1	sztuka
2CKA006220A0156	Electronic Controls aluminium silver - 63x63	SRL-2-L-83	1	sztuka
2CKA006220A0539	Electronic Controls stainless steel - solo	SRL-2-L-866	1	sztuka
2CKA006220A0607	Electronic Controls studio white matt - 63x63	SRL-2-L-884	1	sztuka
2CKA006220A0624	Electronic Controls black matt - 63x63	SRL-2-L-885	1	sztuka
2CKA006220A0561	Electronic Controls grey metallic - 63x63	SRL-2-R-803	1	sztuka
2CKA006220A0167	Electronic Controls anthracite - 63x63	SRL-2-R-81	1	sztuka
2CKA006220A0168	Electronic Controls aluminium silver - 63x63	SRL-2-R-83	1	sztuka
2CKA006220A0544	Electronic Controls stainless steel - solo	SRL-2-R-866	1	sztuka
2CKA006220A0612	Electronic Controls studio white matt - 63x63	SRL-2-R-884	1	sztuka
2CKA006220A0629	Electronic Controls black matt - 63x63	SRL-2-R-885	1	sztuka
2CKA006220A0553	Electronic Controls grey metallic - 63x63	SRS-1-803	1	sztuka
2CKA006220A0146	Electronic Controls anthracite - 63x63	SRS-1-81	1	sztuka
2CKA006220A0147	Electronic Controls aluminium silver - 63x63	SRS-1-83	1	sztuka
2CKA006220A0536	Electronic Controls stainless steel - solo	SRS-1-866	1	sztuka
2CKA006220A0604	Electronic Controls studio white matt - 63x63	SRS-1-884	1	sztuka
2CKA006220A0621	Electronic Controls black matt - 63x63	SRS-1-885	1	sztuka
2CKA006220A0558	Electronic Controls grey metallic - 63x63	SRS-2-L-803	1	sztuka
2CKA006220A0161	Electronic Controls anthracite - 63x63	SRS-2-L-81	1	sztuka
2CKA006220A0162	Electronic Controls aluminium silver - 63x63	SRS-2-L-83	1	sztuka
2CKA006220A0541	Electronic Controls stainless steel - solo	SRS-2-L-866	1	sztuka
2CKA006220A0609	Electronic Controls studio white matt - 63x63	SRS-2-L-884	1	sztuka
2CKA006220A0626	Electronic Controls black matt - 63x63	SRS-2-L-885	1	sztuka
2CKA006220A0562	Electronic Controls grey metallic - 63x63	SRS-2-R-803	1	sztuka
2CKA006220A0173	Electronic Controls anthracite - 63x63	SRS-2-R-81	1	sztuka
2CKA006220A0174	Electronic Controls aluminium silver - 63x63	SRS-2-R-83	1	sztuka
2CKA006220A0545	Electronic Controls stainless steel - solo	SRS-2-R-866	1	sztuka
2CKA006220A0613	Electronic Controls studio white matt - 63x63	SRS-2-R-884	1	sztuka
2CKA006220A0630	Electronic Controls black matt - 63x63	SRS-2-R-885	1	sztuka
2CKA001731A1922	Cover Busch-Infolicht® ivory white - 63x63	1716-82	1	sztuka
2CKA001753A0308	Cover plate for Pull-cord switch, Pull cord anthracite - 63x63	1796-81	1	sztuka
2CKA001799A0895	Mounting Box 1 gang anthracite - future linear	1701-81	1	sztuka
2CKA001799A0896	Mounting Box 1 gang ivory white - future linear	1701-82	1	sztuka
2CKA001799A0905	Mounting Box 1 gang aluminium silver - future linear	1701-83	1	sztuka
2CKA001799A0921	Mounting Box 1 gang studio white matt - future linear	1701-884	1	sztuka
2CKA001799A0923	Mounting Box 1 gang black matt - future linear	1701-885	1	sztuka
2CKA001799A0900	Mounting Box 2 gang anthracite - future linear	1702-81	1	sztuka
2CKA001799A0901	Mounting Box 2 gang ivory white - future linear	1702-82	1	sztuka
2CKA001799A0906	Mounting Box 2 gang aluminium silver - future linear	1702-83	1	sztuka
2CKA001799A0922	Mounting Box 2 gang studio white matt - future linear	1702-884	1	sztuka
2CKA001799A0924	Mounting Box 2 gang black matt - future linear	1702-885	1	sztuka

2CKA001799A0915	Mounting Box 3 gang anthracite - future linear	1703-81	1	sztuka
2CKA001799A0916	Mounting Box 3 gang ivory white - future linear	1703-82	1	sztuka
2CKA001799A0917	Mounting Box 3 gang aluminium silver - future linear	1703-83	1	sztuka
2CKA001799A0955	Mounting Box 3 gang studio white matt - future linear	1703-884	1	sztuka
2CKA001799A0956	Mounting Box 3 gang black matt - future linear	1703-885	1	sztuka
2CKA001751A3122	Mechanical Controls None for Switch/push button, Two-part rocker anthracite - 63x63	1785 K-81-500	1	sztuka
2CKA001751A3124	Mechanical Controls None for Switch/push button, Two-part rocker ivory white - carat	1785 K-82-500	1	sztuka
2CKA001751A3135	Mechanical Controls None for Switch/push button, Two-part rocker studio white matt - 63x63	1785 K-884-500	1	sztuka
2CKA001751A3137	Mechanical Controls None for Switch/push button, Two-part rocker black matt - 63x63	1785 K-885-500	1	sztuka
2CKA001751A3215	Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang grey metallic - 63x63	1785/11 K-803	1	sztuka
2CKA001751A3212	Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang anthracite - 63x63	1785/11 K-81	1	sztuka
2CKA001751A3214	Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang ivory white - 63x63	1785/11 K-82	1	sztuka
2CKA001751A3210	Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang aluminium silver - 63x63	1785/11 K-83	1	sztuka
2CKA001751A3216	Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang stainless steel - Pure Stainless Steel	1785/11 K-866	1	sztuka
2CKA001751A3211	Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang studio white matt - 63x63	1785/11 K-884	1	sztuka
2CKA001751A3213	Rocker with legend DND, MUR for Switch/push button Two-part rocker 1gang black matt - 63x63	1785/11 K-885	1	sztuka
2CKA001751A3206	Rocker DND for Switch/push button, Single rocker grey metallic - 63x63	1786/11-803	1	sztuka
2CKA001710A4133	Cover plate with legend Symbol "card" for Card switch RFID Hotel card grey metallic - 63x63	1792 RFID-803	1	sztuka
2CKA001710A4130	Cover plate with legend Card, Symbol "arrows" Hotel card anthracite - 63x63	1792 RFID-81	1	sztuka
2CKA001710A4132	Cover plate with legend Card, Symbol "arrows" Hotel card ivory white - 63x63	1792 RFID-82	1	sztuka
2CKA001710A4128	Cover plate with legend Card, Symbol "arrows" Hotel card aluminium silver - 63x63	1792 RFID-83	1	sztuka
2CKA001710A4134	Cover plate with legend Card, Symbol "arrows" Hotel card stainless steel - Pure Stainless Steel	1792 RFID-866	1	sztuka
2CKA001710A4129	Cover plate with legend Card, Symbol "arrows" Hotel card studio white matt - 63x63	1792 RFID-884	1	sztuka
2CKA001710A4131	Cover plate with legend Card, Symbol "arrows" Hotel card black matt - 63x63	1792 RFID-885	1	sztuka
2CKA001710A4198	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button anthracite - 63x63	1794 R-81	1	sztuka
2CKA001710A4199	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button white - 63x63	1794 R-82	1	sztuka

2CKA001710A4200	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button aluminium - future linear	1794 R-83	1	sztuka
2CKA001710A4203	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button stainless steel - Pure Stainless Steel	1794 R-866	1	sztuka
2CKA001710A4204	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white matt - 63x63	1794 R-884	1	sztuka
2CKA001710A4205	Cover plate with legend Characters 1 ... 6 for Thermostat Turn button black matt - 63x63	1794 R-885	1	sztuka
2CKA002011A6268	Socket insert None Protective contact (SCHUKO) 20 with USB AA anthracite - 63x63	EUCB2USB -81-500	1	sztuka
2CKA002011A6270	Socket insert None Protective contact (SCHUKO) 20 with USB AA ivory white - 63x63	EUCB2USB -82-500	1	sztuka
2CKA002011A6272	Socket insert None Protective contact (SCHUKO) 20 with USB AA aluminium silver - 63x63	EUCB2USB -83-500	1	sztuka
2CKA002011A6284	Socket insert None Protective contact (SCHUKO) 20 with USB AA stainless steel - Pure Stainless Steel	EUCB2USB -866-500	1	sztuka
2CKA002011A6278	Socket insert None Protective contact (SCHUKO) 20 with USB AA studio white matt - 63x63	EUCB2USB -884-500	1	sztuka
2CKA002011A6280	Socket insert None Protective contact (SCHUKO) 20 with USB AA black matt - 63x63	EUCB2USB -885-500	1	sztuka
2CKA002018A1549	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid ivory white - 63x63	20 EUKNBL-82	1	sztuka
2CKA002018A1550	SCHUKO® Socket insert with labelling field Without imprint Safety Shutter with Hinged Lid aluminium silver - 63x63	20 EUKNBL-83	1	sztuka
2CKA002018A1555	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with different locking grey metallic - 63x63	20 EUKNBSL- 803	1	sztuka
2CKA002018A1556	SCHUKO® socket insert Without imprint Safety Shutter with Hinged Lid and Cylinder Lock with simultaneous locking grey metallic - 63x63	20 EUKNBSL- 803-101	1	sztuka
2CKA002017A1892	Socket with USB AA grey metallic - Busch-axcent	20 MUCB2USB- 803-500	1	sztuka
2CKA002017A1903	Socket with USB AA anthracite - Busch-axcent	20 MUCB2USB- 81-500	1	sztuka
2CKA002017A1889	Socket None Earthing pin with USB AA ivory white - 63x63	20 MUCB2USB- 82-500	1	sztuka
2CKA002017A1890	Socket None Earthing pin with USB AA aluminium silver - 63x63	20 MUCB2USB- 83-500	1	sztuka
2CKA002017A1897	Socket with USB AA stainless steel - Pure Stainless Steel	20 MUCB2USB- 866-500	1	sztuka
2CKA002017A1893	Socket None Earthing pin with USB AA studio white matt - 63x63	20 MUCB2USB- 884-500	1	sztuka
2CKA002017A1894	Socket None Earthing pin with USB AA black matt - 63x63	20 MUCB2USB- 885-500	1	sztuka
2CKA002017A0884	Flush Mounted Inserts CSN-Norm 250 V	2017-0-0884	1	sztuka

2CKA001751A3166	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO grey metallic - 63x63	2029 UC-803	1	sztuka
2CKA001751A3167	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO anthracite - 63x63	2029 UC-81	1	sztuka
2CKA001751A3168	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO ivory white - 63x63	2029 UC-82	1	sztuka
2CKA001751A3169	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO aluminium silver - 63x63	2029 UC-83	1	sztuka
2CKA001751A3171	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO stainless steel - Pure Stainless Steel	2029 UC-866	1	sztuka
2CKA001751A3172	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO studio white matt - 63x63	2029 UC-884	1	sztuka
2CKA001751A3173	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, 1NO black matt - 63x63	2029 UC-885	1	sztuka
2CKA001751A3237	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, grey metallic - 63x63	2029/12 UC-803	1	sztuka
2CKA001751A3234	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, anthracite - 63x63	2029/12 UC-81	1	sztuka
2CKA001751A3236	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, ivory white - 63x63	2029/12 UC-82	1	sztuka
2CKA001751A3232	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, aluminium silver - 63x63	2029/12 UC-83	1	sztuka
2CKA001751A3238	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, stainless steel - Pure Stainless Steel	2029/12 UC-866	1	sztuka
2CKA001751A3233	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, studio white matt - 63x63	2029/12 UC-884	1	sztuka
2CKA001751A3235	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1 pole, black matt - 63x63	2029/12 UC-885	1	sztuka
2CKA001751A3226	Rocker with legend DND, MUR for Switch/push button Two-part rocker grey metallic - solo	2058-24-803	1	sztuka
2CKA001751A3223	Rocker with legend DND, MUR for Switch/push button Two-part rocker anthracite - 63x63	2058-24-81	1	sztuka
2CKA001751A3225	Rocker with legend DND, MUR for Switch/push button Two-part rocker ivory white - 63x63	2058-24-82	1	sztuka
2CKA001751A3221	Rocker with legend DND, MUR for Switch/push button Two-part rocker aluminium silver - 63x63	2058-24-83	1	sztuka
2CKA001751A3227	Rocker with legend DND, MUR for Switch/push button Two-part rocker stainless steel - Pure Stainless Steel	2058-24-866	1	sztuka
2CKA001751A3222	Rocker with legend DND, MUR for Switch/push button Two-part rocker studio white matt - 63x63	2058-24-884	1	sztuka
2CKA001751A3224	Rocker with legend DND, MUR for Switch/push button Two-part rocker black matt - 63x63	2058-24-885	1	sztuka

2CKA001751A3246	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang grey metallic - solo	2059 UC-803	1	sztuka
2CKA001751A3243	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang anthracite - 63x63	2059 UC-81	1	sztuka
2CKA001751A3245	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang ivory white - 63x63	2059 UC-82	1	sztuka
2CKA001751A3241	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang aluminium silver - 63x63	2059 UC-83	1	sztuka
2CKA001751A3247	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang stainless steel - Pure Stainless Steel	2059 UC-866	1	sztuka
2CKA001751A3242	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang studio white matt - 63x63	2059 UC-884	1	sztuka
2CKA001751A3244	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" for Switch/push button Single push button with LED 3gang black matt - 63x63	2059 UC-885	1	sztuka
2CKA001761A1493	Cable Entry anthracite - future linear	2087-81	1	sztuka
2CKA001761A1494	Cable Entry ivory white - future linear	2087-82	1	sztuka
2CKA001761A1504	Cable Entry aluminium silver - future linear	2087-83	1	sztuka
2CKA001761A1498	Cable Entry anthracite - future linear	2088-81	1	sztuka
2CKA001761A1499	Cable Entry ivory white - future linear	2088-82	1	sztuka
2CKA001761A1505	Cable Entry aluminium silver - future linear	2088-83	1	sztuka
2CKA002495A0097	Socket insert Equipotential compensation Socket outlet 2-position grey metallic - 63x63	2095 UC-803	1	sztuka
2CKA002013A5473	SCHUKO® socket insert Without imprint Safety Shutter grey metallic - 63x63	23 EUCB-803	1	sztuka
2CKA001719A0216	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring grey metallic - 63x63	2518-WD-803	1	sztuka
2CKA001719A0217	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring anthracite - 63x63	2518-WD-81	1	sztuka
2CKA001719A0219	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring aluminium silver - 63x63	2518-WD-83	1	sztuka
2CKA001719A0221	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring stainless steel - Pure Stainless Steel	2518-WD-866	1	sztuka
2CKA001719A0222	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring studio white matt - 63x63	2518-WD-884	1	sztuka
2CKA001719A0223	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring black matt - 63x63	2518-WD-885	1	sztuka
2CKA001751A3264	Rocker for Switch/push button Single rocker grey metallic - solo	2570-10-803	1	sztuka
2CKA001751A3261	Rocker for Switch/push button Single rocker anthracite - 63x63	2570-10-81	1	sztuka

2CKA001751A3263	Rocker for Switch/push button Single rocker ivory white - 63x63	2570-10-82	1	sztuka
2CKA001751A3259	Rocker for Switch/push button Single rocker aluminium silver - 63x63	2570-10-83	1	sztuka
2CKA001751A3265	Rocker for Switch/push button Single rocker stainless steel - Pure Stainless Steel	2570-10-866	1	sztuka
2CKA001751A3260	Rocker for Switch/push button Single rocker studio white matt - 63x63	2570-10-884	1	sztuka
2CKA001751A3262	Rocker for Switch/push button Single rocker black matt - 63x63	2570-10-885	1	sztuka
2CKA001751A3275	Rocker for Switch/push button Two-part rocker grey metallic	2570-20-803	1	sztuka
2CKA001751A3272	Rocker for Switch/push button Two-part rocker anthracite - 63x63	2570-20-81	1	sztuka
2CKA001751A3274	Rocker for Switch/push button Two-part rocker ivory white - 63x63	2570-20-82	1	sztuka
2CKA001751A3270	Rocker for Switch/push button Two-part rocker aluminium silver - 63x63	2570-20-83	1	sztuka
2CKA001751A3276	Rocker for Switch/push button Two-part rocker stainless steel - Pure Stainless Steel	2570-20-866	1	sztuka
2CKA001751A3271	Rocker for Switch/push button Two-part rocker studio white matt - 63x63	2570-20-884	1	sztuka
2CKA001751A3273	Rocker for Switch/push button Two-part rocker black matt - 63x63	2570-20-885	1	sztuka
2CKA001751A3286	Rocker for Switch/push button Three-part rocker grey metallic - solo	2570-30-803	1	sztuka
2CKA001751A3283	Rocker for Switch/push button Three-part rocker anthracite - 63x63	2570-30-81	1	sztuka
2CKA001751A3285	Rocker for Switch/push button Three-part rocker ivory white - 63x63	2570-30-82	1	sztuka
2CKA001751A3281	Rocker for Switch/push button Three-part rocker aluminium silver - 63x63	2570-30-83	1	sztuka
2CKA001751A3287	Rocker for Switch/push button Three-part rocker stainless steel - Pure Stainless Steel	2570-30-866	1	sztuka
2CKA001751A3282	Rocker for Switch/push button Three-part rocker studio white matt - 63x63	2570-30-884	1	sztuka
2CKA001751A3284	Rocker for Switch/push button Three-part rocker black matt - 63x63	2570-30-885	1	sztuka
2CKA006132A0256	6122/01-815 Watchdog 180 Standard FM	6122/01-815	1	sztuka
2CKA006132A0280	6122/01-815-500 Watchdog 180 Standard FM	6122/01-815-500	1	sztuka
2CKA006132A0290	Solo Horizontal 0 ... 180 ° grey metallic	6122/02-803-500	1	sztuka
2CKA006132A0269	6122/02-815 Watchdog 180 comfort FM	6122/02-815	1	sztuka
2CKA006132A0283	Solo Horizontal 0 ... 180 ° anthracite	6122/02-81-500	1	sztuka
2CKA006132A0291	6122/02-815-500 Watchdog 180 comfort FM	6122/02-815-500	1	sztuka
2CKA006132A0284	Solo Horizontal 0 ... 180 ° ivory white	6122/02-82-500	1	sztuka
2CKA006132A0285	Solo Horizontal 0 ... 180 ° aluminium silver	6122/02-83-500	1	sztuka

2CKA006132A0289	Solo Horizontal 0 ... 180 ° stainless steel	6122/02-866-500	1	sztuka
2CKA006132A0292	Solo Horizontal 0 ... 180 ° studio white matt	6122/02-884-500	1	sztuka
2CKA006132A0293	Solo Horizontal 0 ... 180 ° black matt	6122/02-885-500	1	sztuka
2CKA006132A0371	6122/10-896 BW standard	6122/10-896	1	sztuka
2CKA006134A0253	6124/01-803 Room Thermostat	6124/01-803	1	sztuka
2CKA006134A0280	6124/01-803-500 Room Thermostat	6124/01-803-500	1	sztuka
2CKA006134A0244	6124/01-81 Room Thermostat	6124/01-81	1	sztuka
2CKA006134A0254	6124/01-815 Room Thermostat	6124/01-815	1	sztuka
2CKA006134A0295	6124/01-81-500 Room Thermostat	6124/01-81-500	1	sztuka
2CKA006134A0281	6124/01-815-500 Room Thermostat	6124/01-815-500	1	sztuka
2CKA006134A0245	6124/01-82 Room Thermostat	6124/01-82	1	sztuka
2CKA006134A0274	6124/01-82-500 Room Thermostat	6124/01-82-500	1	sztuka
2CKA006134A0275	6124/01-83-500 Room Thermostat	6124/01-83-500	1	sztuka
2CKA006134A0279	6124/01-866-500 Room Thermostat	6124/01-866-500	1	sztuka
2CKA006134A0255	6124/01-884 Room Thermostat	6124/01-884	1	sztuka
2CKA006134A0256	6124/01-885 Room Thermostat	6124/01-885	1	sztuka
2CKA006134A0283	6124/01-885-500 Room Thermostat	6124/01-885-500	1	sztuka
2CKA006134A0303	6124/01-896 Room Thermostat	6124/01-896	1	sztuka
2CKA006134A0304	6124/01-896-500 Room Thermostat	6124/01-896-500	1	sztuka
2CKA006134A0221	6124-83-101 Room Thermostat with Display	6124-83-101	1	sztuka
2CKA006134A0229	6124-866-101 Room Thermostat with Display	6124-866-101	1	sztuka
2CKA006134A0226	6124-87-101 Room Thermostat with Display	6124-87-101	1	sztuka
2CKA006134A0291	6128/01-803-500 RTC Control element 2/4g	6128/01-803-500	1	sztuka
2CKA006134A0257	6128/01-81 RTC Control element 2/4g	6128/01-81	1	sztuka
2CKA006134A0267	6128/01-815 RTC Control element 2/4g	6128/01-815	1	sztuka
2CKA006134A0284	6128/01-81-500 RTC Control element 2/4g	6128/01-81-500	1	sztuka
2CKA006134A0292	6128/01-815-500 RTC Control element 2/4g	6128/01-815-500	1	sztuka
2CKA006134A0258	6128/01-82 RTC Control element 2/4g	6128/01-82	1	sztuka
2CKA006134A0286	6128/01-83-500 RTC Control element 2/4g	6128/01-83-500	1	sztuka
2CKA006134A0293	6128/01-884-500 RTC Control element 2/4g	6128/01-884-500	1	sztuka
2CKA006134A0269	6128/01-885 RTC Control element 2/4g	6128/01-885	1	sztuka
2CKA006134A0294	6128/01-885-500 RTC Control element 2/4g	6128/01-885-500	1	sztuka
2CKA006134A0305	6128/01-896 RTC Control element 2/4g	6128/01-896	1	sztuka

2CKA006134A0306	6128/01-896-500 RTC Control element 2/4g	6128/01-896-500	1	sztuka
2CKA006134A0208	6128-81-101 RoomThermostat/Switch Sensor	6128-81-101	1	sztuka
2CKA006134A0209	6128-82-101 RoomThermostat/Switch Sensor	6128-82-101	1	sztuka
2CKA006134A0218	6128-866-101 RoomThermostat/Switch Sensor	6128-866-101	1	sztuka
2CKA006135A0152	6129/01-815 Control element 3/6g w. IR	6129/01-815	1	sztuka
2CKA006135A0164	6129/01-815-500 Control element 3/6g w. IR	6129/01-815-500	1	sztuka
2CKA006135A0169	6129/01-896 Control element 3/6g w. IR	6129/01-896	1	sztuka
2CKA006220A0479	6215/1.1-896 Mov. detector/actuator 1g	6215/1.1-896	1	sztuka
2CKA006220A0478	6225/1.0-896 Movement detector	6225/1.0-896	1	sztuka
2CKA006200A0166	62762-81-WL-500 WD 180 flex comf. sens. WL	62762-81-WL-500	1	sztuka
2CKA006200A0178	62762-885-WL-500 WD 180 flex comf. sens. WL	62762-885-WL-500	1	sztuka
2CKA006800A2929	Busch-Watchdog Electronic Controls Movement sensor grey metallic - 63x63	64761-803-500	1	sztuka
2CKA006800A2921	Busch-Watchdog Electronic Controls Movement sensor anthracite - 63x63	64761-81-500	1	sztuka
2CKA006800A2923	Busch-Watchdog Electronic Controls Movement sensor ivory white - 63x63	64761-82-500	1	sztuka
2CKA006800A2925	Busch-Watchdog Electronic Controls Movement sensor aluminium silver - 63x63	64761-83-500	1	sztuka
2CKA006800A2936	Busch-Watchdog Electronic Controls Movement sensor stainless steel - Pure Stainless Steel	64761-866-500	1	sztuka
2CKA006800A2931	Busch-Watchdog Electronic Controls Movement sensor studio white matt - 63x63	64761-884-500	1	sztuka
2CKA006800A2933	Electronic Controls Movement sensor black matt - 63x63	64761-885-500	1	sztuka
2CKA006800A2966	Busch-Watchdog Cover plate Movement sensor grey metallic - 63x63	64762-803-500	1	sztuka
2CKA006800A2958	Busch-Watchdog Cover plate Movement sensor anthracite - 63x63	64762-81-500	1	sztuka
2CKA006800A2960	64762-82-500 WD 180 flex comfort sensor	64762-82-500	1	sztuka
2CKA006800A2962	Busch-Watchdog Cover plate Movement sensor aluminium silver - 63x63	64762-83-500	1	sztuka
2CKA006800A2973	Busch-Watchdog Cover plate Movement sensor stainless steel - Pure Stainless Steel	64762-866-500	1	sztuka
2CKA006800A2968	Busch-Watchdog Cover plate Movement sensor studio white matt - 63x63	64762-884-500	1	sztuka
2CKA006800A2970	Busch-Watchdog Cover plate Movement sensor black matt - 63x63	64762-885-500	1	sztuka
2CKA006800A3003	Electronic Controls Movement sensor grey metallic - 63x63	64764-803-500	1	sztuka
2CKA006800A2995	Electronic Controls Movement sensor anthracite - 63x63	64764-81-500	1	sztuka
2CKA006800A2999	Electronic Controls Movement sensor aluminium silver - 63x63	64764-83-500	1	sztuka
2CKA006800A3005	Electronic Controls Movement sensor studio white matt - 63x63	64764-884-500	1	sztuka
2CKA006800A3007	Electronic Controls Movement sensor black matt - 63x63	64764-885-500	1	sztuka

2CKA006800A2883	Electronic Controls Movement sensor anthracite - 63x63	64765-81-500	1	sztuka
2CKA006800A2885	64765-82-500 Comfort switch flex sensor	64765-82-500	1	sztuka
2CKA006800A2887	Electronic Controls Movement sensor aluminium silver - 63x63	64765-83-500	1	sztuka
2CKA006800A2893	Electronic Controls Movement sensor studio white matt - 63x63	64765-884-500	1	sztuka
2CKA006800A2895	Electronic Controls Movement sensor black matt - 63x63	64765-885-500	1	sztuka
2CKA006710A0015	Control element insert Smart switch 4 chan. Bluetooth white - 63x63	6716 UBT	1	sztuka
2CKA006730A0155	Smart switch set 4 channel Bluetooth black matt - future linear	6716/01 UJ-885	1	sztuka
2CKA006730A0157	Kits 4 channel Bluetooth black matt - future linear	6716/01 UJ-885-500	1	sztuka
2CKA006730A0159	Kits 4 channel Bluetooth black matt - future linear	6716/01 UJ-885-510	1	sztuka
2CKA006730A0142	Rocker None for Dimmer Single rocker anthracite - 63x63	6735 BT-81	1	sztuka
2CKA006730A0143	Rocker None for Dimmer Single rocker beige - 63x63	6735 BT-82	1	sztuka
2CKA006730A0144	Rocker None for Dimmer Single rocker aluminium - 63x63	6735 BT-83	1	sztuka
2CKA006730A0148	Rocker None for Dimmer Single rocker stainless steel - Pure Stainless Steel	6735 BT-866	1	sztuka
2CKA006730A0149	Rocker None for Dimmer Single rocker studio white matt - 63x63	6735 BT-884	1	sztuka
2CKA006730A0150	Rocker None for Dimmer Single rocker black matt - 63x63	6735 BT-885	1	sztuka
2CKA006730A0117	Wall sensor for ZigBee Light Link 1 channel 1gang Radio Control grey metallic - 63x63	6735/01-803	1	sztuka
2CKA006730A0079	Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control anthracite - 63x63	6735/01-81	1	sztuka
2CKA006730A0080	Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control ivory white - 63x63	6735/01-82	1	sztuka
2CKA006730A0081	Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control aluminium silver - 63x63	6735/01-83	1	sztuka
2CKA006730A0116	Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control stainless steel - Pure Stainless Steel	6735/01-866	1	sztuka
2CKA006730A0118	Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control studio white matt - 63x63	6735/01-884	1	sztuka
2CKA006730A0119	Wall sensor with labelling field for ZigBee Light Link 1 channel 1gang Radio Control black matt - 63x63	6735/01-885	1	sztuka
2CKA006730A0099	Control Element for Switch/dimmer 1gang Radio Control grey metallic - 63x63	6735-803	1	sztuka
2CKA006730A0067	Control Element for Switch/dimmer 1gang Radio Control anthracite - 63x63	6735-81	1	sztuka
2CKA006730A0068	Control Element for Switch/dimmer 1gang Radio Control ivory white - 63x63	6735-82	1	sztuka

2CKA006730A0069	Control Element for Switch/dimmer 1gang Radio Control aluminium silver - 63x63	6735-83	1	sztuka
2CKA006730A0098	Control Element for Switch/dimmer 1gang Radio Control stainless steel - Pure Stainless Steel	6735-866	1	sztuka
2CKA006730A0100	Control Element for Switch/dimmer 1gang Radio Control studio white matt - 63x63	6735-884	1	sztuka
2CKA006730A0101	Control Element for Switch/dimmer 1gang Radio Control black matt - 63x63	6735-885	1	sztuka
2CKA006730A0137	Control Element None for Dimmer Two-part button grey metallic - 63x63	6736 FoH-803	1	sztuka
2CKA006730A0133	Control Element None for Dimmer Two-part button anthracite - 63x63	6736 FoH-81	1	sztuka
2CKA006730A0135	Control Element None for Dimmer Two-part button aluminium - 63x63	6736 FoH-83	1	sztuka
2CKA006730A0139	Control Element None for Dimmer Two-part button stainless steel - Pure Stainless Steel	6736 FoH-866	1	sztuka
2CKA006730A0140	Control Element None for Dimmer Two-part button studio white matt - 63x63	6736 FoH-884	1	sztuka
2CKA006730A0121	Wall sensor 2 channel 2gang Radio Control grey metallic - 63x63	6736/01-803	1	sztuka
2CKA006730A0083	Wall sensor 2 channel 2gang Radio Control anthracite - 63x63	6736/01-81	1	sztuka
2CKA006730A0084	Wall sensor 2 channel 2gang Radio Control ivory white - 63x63	6736/01-82	1	sztuka
2CKA006730A0085	Wall sensor 2 channel 2gang Radio Control aluminium silver - 63x63	6736/01-83	1	sztuka
2CKA006730A0122	Wall sensor 2 channel 2gang Radio Control stainless steel - Pure Stainless Steel	6736/01-866	1	sztuka
2CKA006730A0124	Wall sensor 2 channel 2gang Radio Control studio white matt - 63x63	6736/01-884	1	sztuka
2CKA006730A0125	Wall sensor 2 channel 2gang Radio Control black matt - 63x63	6736/01-885	1	sztuka
2CKA006730A0105	Control Element for Switch/dimmer 2gang Radio Control grey metallic - 63x63	6736-803	1	sztuka
2CKA006730A0071	Control Element for Switch/dimmer 2gang Radio Control anthracite - 63x63	6736-81	1	sztuka
2CKA006730A0072	Control Element for Switch/dimmer 2gang Radio Control ivory white - 63x63	6736-82	1	sztuka
2CKA006730A0073	Control Element for Switch/dimmer 2gang Radio Control aluminium silver - 63x63	6736-83	1	sztuka
2CKA006730A0104	Control Element for Switch/dimmer 2gang Radio Control stainless steel - Pure Stainless Steel	6736-866	1	sztuka
2CKA006730A0106	Control Element for Switch/dimmer 2gang Radio Control studio white matt - 63x63	6736-884	1	sztuka
2CKA006730A0107	Control Element for Switch/dimmer 2gang Radio Control black matt - 63x63	6736-885	1	sztuka
2CKA006730A0127	Wall sensor for ZigBee Light Link 4 channel 4gang Radio Control grey metallic - 63x63	6737/01-803	1	sztuka
2CKA006730A0087	Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control anthracite - 63x63	6737/01-81	1	sztuka
2CKA006730A0088	Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control ivory white - 63x63	6737/01-82	1	sztuka

2CKA006730A0089	Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control aluminium silver - 63x63	6737/01-83	1	sztuka
2CKA006730A0128	Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control stainless steel - Pure Stainless Steel	6737/01-866	1	sztuka
2CKA006730A0130	Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control studio white matt - 63x63	6737/01-884	1	sztuka
2CKA006730A0131	Wall sensor with labelling field for ZigBee Light Link 4 channel 4gang Radio Control black matt - 63x63	6737/01-885	1	sztuka
2CKA006730A0111	Control Element for Switch/dimmer 4gang Radio Control grey metallic - 63x63	6737-803	1	sztuka
2CKA006730A0075	Control Element for Switch/dimmer 4gang Radio Control anthracite - 63x63	6737-81	1	sztuka
2CKA006730A0076	Control Element for Switch/dimmer 4gang Radio Control ivory white - 63x63	6737-82	1	sztuka
2CKA006730A0077	Control Element for Switch/dimmer 4gang Radio Control aluminium silver - 63x63	6737-83	1	sztuka
2CKA006730A0110	Control Element for Switch/dimmer 4gang Radio Control stainless steel - Pure Stainless Steel	6737-866	1	sztuka
2CKA006730A0112	Control Element for Switch/dimmer 4gang Radio Control studio white matt - 63x63	6737-884	1	sztuka
2CKA006730A0113	Control Element for Switch/dimmer 4gang Radio Control black matt - 63x63	6737-885	1	sztuka
2CKA006800A2325	Electronic Controls aluminium silver - 63x63	6800-83-104	1	sztuka
2CKA006800A2327	6800-83-104M Watchdog Comfort Sensor 180	6800-83-104M	1	sztuka
2CKA006800A2343	Electronic Controls stainless steel - Pure Stainless Steel	6800-866-104	1	sztuka
2CKA006800A2506	6800-885-104 Watchdog Comfort Sensor 180	6800-885-104	1	sztuka
2CKA008200A0257	Cover plate with legend Radio 0 gang grey metallic - 63x63	8252-803-101-500	1	sztuka
2CKA008200A0249	Cover plate with legend Radio 0 gang anthracite - 63x63	8252-81-101-500	1	sztuka
2CKA008200A0251	Cover plate with legend Radio 0 gang ivory white - 63x63	8252-82-101-500	1	sztuka
2CKA008200A0259	Cover plate with legend Radio 0 gang studio white matt - 63x63	8252-884-101-500	1	sztuka
2CKA008200A0230	Cover plate Multimedia 3 gang grey metallic - solo	8256-803	1	sztuka
2CKA008200A0227	Cover plate Multimedia 3 gang anthracite - 63x63	8256-81	1	sztuka
2CKA008200A0229	Cover plate Multimedia 3 gang ivory white - 63x63	8256-82	1	sztuka
2CKA008200A0225	Cover plate Multimedia 3 gang aluminium silver - 63x63	8256-83	1	sztuka
2CKA008200A0231	Cover plate Multimedia 3 gang stainless steel - Pure Stainless Steel	8256-866	1	sztuka
2CKA008200A0226	Cover plate Multimedia 3 gang studio white matt - 63x63	8256-884	1	sztuka
2CKA008200A0228	Cover plate Multimedia 3 gang black matt - 63x63	8256-885	1	sztuka

Kategorie

Produkty niskiego napięcia i systemy → Wiring Accessories - Light Switch Ranges → Frames

