


Opis produktu

2025 U

Card switch insert with legend 1-pole push switch 1 NO



Ogólne informacje

Typ produktu	2025 U
Kod zamówieniowy	2CKA001012A1713
Numer EAN	4011395656808
Opis katalogowy	Card switch insert with legend 1-pole push switch 1 NO
Opis	Illuminable. With N terminal.

Installation

Instrukcje i podręczniki	No document needed
Typ montażu	Flush Mounted
Rodzaj mocowania	Mounting with Claw Mounting with Screw

Dane techniczne

Arkusze danych, informacja techniczna	No document needed
Konfiguracja styków	1 NO, 0 NC
Liczba biegunów	1
Konfiguracja okablowania	1-pole push switch

Typ dźwigni	Hotel card
Podświetlenie	Illuminated

Electrical

Napięcie znamionowe (U_r)	250 V
Prąd znamionowy (I_n)	10 A
Ilość styków normalnie otwartych	1

Design

Design Range	63x63 Busch-art linear future linear Busch-axcent Busch-axcent pur solo carat future Busch-Dynasty Pure Stainless Steel
Wykończenie pokrywy	Untreated
Zapewnione miejsce na etykiety	No

Material Compliance

Dane RoHS	2CKA200000E0119
Status RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Deklaracja REACH	2CKA309999E9999
REACH Information	False - does not contains substances > 0.1 mass percentage
Szablon raportowania CMRT	9AKK108468A3363

Normy środowiskowe

Stopień ochrony	IP20
-----------------	------

Wymiary

Szerokość netto	71 mm
Wysokość netto	71 mm
Głębokość / długość netto	40.1 mm
Masa netto	56 g
Głębokość zabudowy (t_2)	32 mm

Certyfikaty i deklaracje (Numer dokumentu)

Deklaracja zgodności UE	2CKA100000E0022
Deklaracja zgodności - UKCA	2CKA400000E0419

Klasyfikacje

ETIM 9	EC000029 - Push button
eClass	V11.0 : 27144044
Kategoria WEEE	5. Small Equipment (No External Dimension More Than 50 cm)
WEEE B2C / B2B	Business To Consumer

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA001710A4124	Cover plate with legend Card, Symbol "arrows" for Switch/push button, Hotel card grey metallic - 63x63	1792-803	1	sztuka
2CKA001710A3639	Cover plate with legend Card, Symbol "arrows" Hotel card anthracite - 63x63	1792-81	1	sztuka
2CKA001710A3640	Cover plate with legend Card, Symbol "arrows" Hotel card ivory white - 63x63	1792-82	1	sztuka
2CKA001710A3670	Cover plate with legend Card, Symbol "arrows" Hotel card aluminium silver - 63x63	1792-83	1	sztuka
2CKA001710A3757	Cover plate with legend Card, Symbol "arrows" Hotel card stainless steel - Pure Stainless Steel	1792-866	1	sztuka
2CKA001710A3928	Cover plate with legend Card, Symbol "arrows" Hotel card studio white matt - 63x63	1792-884	1	sztuka
2CKA001710A3905	Cover plate with legend Card, Symbol "arrows" Hotel card black matt - 63x63	1792-885	1	sztuka
2CKA001710A3294	Cover plate with legend Card, Symbol "arrows" Hotel card bronze - alpha	1792-21-101	1	sztuka
2CKA001710A3297	Cover plate with legend Card, Symbol "arrows" Hotel card studio white - alpha	1792-24G-101	1	sztuka
2CKA001710A3305	Cover plate with legend Card, Symbol "arrows" for Switch/push button, Hotel card palladium - alpha	1792-260-101	1	sztuka
2CKA001710A3331	Cover plate with legend Card, Symbol "arrows" Hotel card titanium - alpha	1792-266-101	1	sztuka
2CKA001753A0079	Cover plate with legend Card, Symbol "arrows" for Switch/push button, Hotel card ivory - impuls	1792-72	1	sztuka
2CKA001753A6703	Cover plate with legend Card, Symbol "arrows" for Switch/push button, Hotel card alpine white - impuls	1792-74	1	sztuka
2CKA001753A0190	Cover plate with legend Card, Symbol "arrows" for Switch/push button, Hotel card studio white matt - impuls	1792-774	1	sztuka
2CKA001753A0159	Cover plate with legend Card, Symbol "arrows" for Switch/push button, Hotel card black matt - impuls	1792-775	1	sztuka
2CKA001753A0080	Cover plate with legend Card, Symbol "arrows" for Switch/push button, Hotel card aluminium silver - impuls	1792-783	1	sztuka
2CKA001753A6737	Cover plate with legend Card, Symbol "arrows" for Switch/push button, Hotel card champagne metallic - impuls	1792-79	1	sztuka
2CKA001710A3865	Mechanical Controls Card, Symbol "arrows" for Switch/push button, Hotel card white - Basic55	1792-92-507	1	sztuka
2CKA001710A3929	Mechanical Controls Card, Symbol "arrows" for Switch/push button, Hotel card champagne - Basic55	1792-93-507	1	sztuka
2CKA001710A3864	Mechanical Controls Card, Symbol "arrows" for Switch/push button, Hotel card alpine white - Basic55	1792-94-507	1	sztuka

2CKA001710A3933	Mechanical Controls Card, Symbol "arrows" for Switch/push button, Hotel card château-black - Basic55	1792-95-507	1	sztuka
2CKA001710A3293	Cover plate with legend Card, Symbol "arrows" Hotel card platinum - alpha	1792-20-101	1	sztuka
2CKA001784A0057	Illumination set Switch/push button Orange Neon lamp 230 V	8338-1	1	sztuka
2CKA001784A0164	Illumination set Switch/push button White Incandescent lamp 8 V	8344-1	1	sztuka
2CKA001784A0289	Illumination set Switch/push button White Incandescent lamp 12 V	8345-1	1	sztuka
2CKA001784A0032	Illumination set Switch/push button White Incandescent lamp 24 V	8337-1	1	sztuka
2CKA001784A0313	Illumination set Switch/push button Orange LED 8 ... 15 V	8327-1	1	sztuka
2CKA001784A0545	Illumination set Switch/push button Orange Neon lamp 230 V	8350	1	sztuka
2CKA001784A0552	Illumination set Switch/push button Orange Neon lamp 230 V red	8360	1	sztuka
2CKA001784A0560	Illumination set Switch/push button Orange Neon lamp 230 V	8352	1	sztuka
2CKA001784A0586	Illumination set Switch/push button Orange Neon lamp 230 V yellow	8362	1	sztuka
2CKA001784A0578	Illumination set Switch/push button Orange Neon lamp 230 V	8353	1	sztuka
2CKA001784A0594	Illumination set Switch/push button Orange Neon lamp 230 V white	8363	1	sztuka
2CKA001784A0651	Illumination set Switch/push button White Incandescent lamp 8 V red	8367	1	sztuka
2CKA001784A0636	Illumination set Switch/push button White Incandescent lamp 12 V red	8366	1	sztuka
2CKA001784A0610	Illumination set Switch/push button White Incandescent lamp 24 V red	8365	1	sztuka
2CKA001784A0779	Illumination set Switch/push button White LED 230 V red	8380-10	1	sztuka
2CKA001784A0788	Illumination set Switch/push button White LED 230 V red	8390-10	1	sztuka
2CKA001784A0782	Illumination set Switch/push button Red LED 230 V red	8380-12	1	sztuka
2CKA001784A0791	Illumination set Switch/push button Red LED 230 V red	8390-12	1	sztuka
2CKA001784A0785	Illumination set Switch/push button Blue LED 230 V red	8380-17	1	sztuka
2CKA001784A0794	Illumination set Switch/push button Blue LED 230 V red	8390-17	1	sztuka
2CKA001784A0780	Illumination set Switch/push button White LED 230 V yellow	8382-10	1	sztuka
2CKA001784A0789	Illumination set Switch/push button White LED 230 V yellow	8392-10	1	sztuka
2CKA001784A0783	Illumination set Switch/push button Red LED 230 V yellow	8382-12	1	sztuka
2CKA001784A0792	Illumination set Switch/push button Red LED 230 V yellow	8392-12	1	sztuka
2CKA001784A0786	Illumination set Switch/push button Blue LED 230 V yellow	8382-17	1	sztuka
2CKA001784A0795	Illumination set Switch/push button Blue LED 230 V yellow	8392-17	1	sztuka
2CKA001784A0781	Illumination set Switch/push button White LED 230 V white	8383-10	1	sztuka
2CKA001784A0790	Illumination set Switch/push button White LED 230 V white	8393-10	1	sztuka

2CKA001784A0784	Illumination set Switch/push button Red LED 230 V white	8383-12	1	sztuka
2CKA001784A0793	Illumination set Switch/push button Red LED 230 V white	8393-12	1	sztuka
2CKA001784A0787	Illumination set Switch/push button Blue LED 230 V white	8383-17	1	sztuka
2CKA001784A0796	Illumination set Switch/push button Blue LED 230 V white	8393-17	1	sztuka

Kategorie

Produkty niskiego napięcia i systemy → Wiring Accessories - Light Switch Ranges → Flush Mounted Inserts → Mechanical Inserts

