

Opis produktu

2513-95-507

Cover frame 3gang château-black - Basic55



Ogólne informacje

Typ produktu	2513-95-507
Kod zamówieniowy	2CKA001725A1508
Oznaczenie typu ABB	Cover Frame 3gang xxx - Basic55
Numer EAN	4011395160411
Opis katalogowy	Cover frame 3gang château-black - Basic55
Opis	For vertical or horizontal installation.

Installation

Instrukcje i podręczniki	No document needed
Typ montażu	Flush Mounted
Rodzaj mocowania	Clamp
Orientacja montażu	Horizontal Vertical

Dane techniczne

Arkusze danych, informacja techniczna	No document needed
Liczba	3

Design

Design Range	Basic55
Wykończenie pokrywy	Lacquered Glossy
Materiał	Thermoplastic
Zapewnione miejsce na etykiety	No
Kolor	château-black

Material Compliance

Dane RoHS	2CKA200000E1473
Status RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Deklaracja REACH	2CKA309999E9999
REACH Information	False - does not contains substances > 0.1 mass percentage
Szablon raportowania CMRT	9AKK108468A3363

Normy środowiskowe

Stopień ochrony	IP20
-----------------	------

Wymiary

Szerokość netto	84 mm
Wysokość netto	225 mm
Głębokość / długość netto	12 mm
Masa netto	58 g

Certyfikaty i deklaracje (Numer dokumentu)

Deklaracja zgodności UE	No declaration needed
-------------------------	-----------------------

Klasyfikacje

ETIM 9	EC000007 - Cover frame for domestic switching devices
eClass	V11.0 : 27144001
Kategoria WEEE	Product Not in WEEE Scope

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA001012A2173	Mechanical Controls Off switch 3x1-pole château-106/3/1 black - Basic55	UC-95-507	1	sztuka
2CKA001012A2183	Mechanical Controls Off switch 3x1-pole chalet 106/3/1 white - Basic55	UC-96-507	1	sztuka

2CKA001724A4313	Data / Telecommunication / Antenna SAT 1 gang château-black - Basic55	1743-01-95- 507	1	sztuka
2CKA001724A4317	Data / Telecommunication / Antenna SAT 1 gang chalet white - Basic55	1743-01-96- 507	1	sztuka
2CKA001724A4314	Data / Telecommunication / Antenna SAT 3 gang château-black - Basic55	1743-95-507	1	sztuka
2CKA001724A4316	Data / Telecommunication / Antenna SAT 3 gang chalet white - Basic55	1743-96-507	1	sztuka
2CKA001726A0231	Data / Telecommunication / Antenna Telecommunication inserts 0 gang château-black - Basic55	1746-95-507	1	sztuka
2CKA001753A0208	Light & Signalization chalet white - Basic55	1756-96-507	1	sztuka
2CKA001710A3933	Mechanical Controls Card, Symbol "arrows" for Switch/push button, Hotel card château-black - Basic55	1792-95-507	1	sztuka
2CKA001710A3934	Electronic Controls Turn button château-black - Basic55	1794-95-507	1	sztuka
2CKA001710A3938	Electronic Controls Various symbols for Thermostat Turn button white - Basic55	1794-96-507	1	sztuka
2CKA001710A3935	Electronic Controls Various symbols Turn button château-black - Basic55	1795-95-507	1	sztuka
2CKA001710A3942	Data / Telecommunication / Antenna Modular Jack 2 gang château-black - Basic55	1800-95-507	1	sztuka
2CKA001753A0206	Data / Telecommunication / Antenna UAE/IAE (ISDN) 2 gang château-black - Basic55	1803-02-95- 507	1	sztuka
2CKA001753A0209	Data / Telecommunication / Antenna UAE/IAE (ISDN) 2 gang chalet white - Basic55	1803-02-96- 507	1	sztuka
2CKA001753A0207	Data / Telecommunication / Antenna UAE/IAE (ISDN) 1 gang château-black - Basic55	1803-95-507	1	sztuka
2CKA001753A0210	Data / Telecommunication / Antenna UAE/IAE (ISDN) 1 gang chalet white - Basic55	1803-96-507	1	sztuka
2CKA002011A6143	Socket Outlets Data château-black - Basic55	20 EUC/DV-95- 507	1	sztuka
2CKA002011A6142	Socket Outlets Without imprint château-black - Basic55	20 EUC-95- 507	1	sztuka
2CKA002011A6144	Socket Outlets Without imprint chalet white - Basic55	20 EUC-96- 507	1	sztuka
2CKA002018A1502	Socket Outlets Without imprint with Hinged Lid château-black - Basic55	20 EUCKD-95- 507	1	sztuka
2CKA002013A5338	Socket Outlets Without imprint château-black - Basic55	20 EUCKS-95- 507	1	sztuka
2CKA002013A5339	Socket Outlets Without imprint chalet white - Basic55	20 EUCKS-96- 507	1	sztuka
2CKA002018A1499	Socket Outlets Without imprint with Hinged Lid château-black - Basic55	20 EUK-95-507	1	sztuka
2CKA002018A1500	Socket Outlets Without imprint with Hinged Lid chalet white - Basic55	20 EUK-96-507	1	sztuka
2CKA002111A0655	Socket Outlets Without imprint with Hinged Lid château-black - Basic55	20 EUKB-95- 507	1	sztuka
2CKA001012A2174	Mechanical Controls Off switch 1-pole château- black - Basic55	2006/1 UC-95- 507	1	sztuka
2CKA001012A2184	Mechanical Controls Off switch 1-pole chalet white - Basic55	2006/1 UC-96- 507	1	sztuka
2CKA001012A2175	Mechanical Controls Off switch 1-pole with Neon lamp château-black - Basic55	2006/1 UCGL- 95-507	1	sztuka
2CKA001012A2176	Mechanical Controls château-black - Basic55	2006/4 UC-95- 507	1	sztuka
2CKA001012A2177	Mechanical Controls Series switch château-black - Basic55	2006/5 UC-95- 507	1	sztuka
2CKA001012A2187	Mechanical Controls Series switch chalet white - Basic55	2006/5 UC-96- 507	1	sztuka

2CKA001012A2178	Mechanical Controls Series switch with Neon lamp château-black - Basic55	2006/5 UCGL-95-507	1	sztuka
2CKA001012A2188	Mechanical Controls Series switch with Neon lamp chalet white - Basic55	2006/5 UCGL-96-507	1	sztuka
2CKA001012A2179	Mechanical Controls Two-way switch château-black - Basic55	2006/6 UC-95-507	1	sztuka
2CKA001012A2189	Mechanical Controls Two-way switch chalet white - Basic55	2006/6 UC-96-507	1	sztuka
2CKA001012A2180	Mechanical Controls Two-way switch with Neon lamp château-black - Basic55	2006/6 UCK-95-507	1	sztuka
2CKA001012A2190	Mechanical Controls Two-way switch with Neon lamp chalet white - Basic55	2006/6 UCK-96-507	1	sztuka
2CKA001012A2181	Mechanical Controls Alternating-/alternating switch château-black - Basic55	2006/6/6 UC-95-507	1	sztuka
2CKA001012A2182	Mechanical Controls Intermediate switch château-black - Basic55	2006/7 UC-95-507	1	sztuka
2CKA001012A2192	Mechanical Controls Intermediate switch chalet white - Basic55	2006/7 UC-96-507	1	sztuka
2CKA001413A1095	Mechanical Controls None Single push button 1 pole, château-black - Basic55	2026 UC-95-507	1	sztuka
2CKA001413A1099	Mechanical Controls None Single push button 1 pole, chalet white - Basic55	2026 UC-96-507	1	sztuka
2CKA001413A1097	Mechanical Controls Symbol "bell" 1 pole, château-black - Basic55	2026 UCN/KL-95-507	1	sztuka
2CKA001413A1101	Mechanical Controls Symbol "bell" Single push button 1 pole, chalet white - Basic55	2026 UCN/KL-96-507	1	sztuka
2CKA001413A1096	Mechanical Controls None Single push button 1 pole, château-black - Basic55	2026 UCN-95-507	1	sztuka
2CKA001413A1100	Mechanical Controls None Single push button 1 pole, chalet white - Basic55	2026 UCN-96-507	1	sztuka
2CKA001413A1098	Mechanical Controls Symbol "venetian blind" Single push button 1 pole, château-black - Basic55	2026/4 UC-95-507	1	sztuka
2CKA006599A2991	Electronic Controls Without imprint for Dimmer Turn button château-black - Basic55	2115-95-507	1	sztuka
2CKA006599A2992	Electronic Controls Without imprint for Dimmer Turn button chalet white - Basic55	2115-96-507	1	sztuka
2CKA006515A0847	Electronic Controls chalet white - Basic55	2251 UCGL-96-507	1	sztuka
2CKA002011A6147	Socket Outlets Without imprint château-black - Basic55	2300 EUC-95-507	1	sztuka
2CKA002099A0260	Socket Outlets Without imprint château-black - Basic55	2399 UCKS-95-507	1	sztuka
2CKA001710A3936	Cable Outlet / Blank Plate / Adapter Ring Cable outlet 0 gang château-black - Basic55	2527-95-507	1	sztuka
2CKA001715A0315	Cable Outlet / Blank Plate / Adapter Ring Blind cap 0 gang château-black - Basic55	2538-95-507	1	sztuka
2CKA001715A0316	Cable Outlet / Blank Plate / Adapter Ring Blind cap 0 gang chalet white - Basic55	2538-96-507	1	sztuka
2CKA001724A4315	Data / Telecommunication / Antenna TAE 0 gang château-black - Basic55	2539-95-507	1	sztuka
2CKA001724A4318	Data / Telecommunication / Antenna TAE 0 gang chalet white - Basic55	2539-96-507	1	sztuka
2CKA001753A0214	Data / Telecommunication / Antenna Modular Jack 2 gang château-black - Basic55	2561-95-507	1	sztuka
2CKA001101A0928	Mechanical Controls 1-pole switch and push switch 0 1 pole, château-black - Basic55	2713 UCDR-95-507	1	sztuka
2CKA001101A0930	Mechanical Controls 1-pole switch and push switch 0 1 pole, chalet white - Basic55	2713 UCDR-96-507	1	sztuka
2CKA001101A0929	Mechanical Controls 1-pole push button 0 1 pole, château-black - Basic55	2723 UCDR-95-507	1	sztuka

2CKA001101A0931	Mechanical Controls 1-pole push button 0 1 pole, 2723 UCDR-96 chalet white - Basic55	2723 UCDR-96-507	1	sztuka
2CKA006132A0387	6122/10-95-500 BW standard	6122/10-95-500	1	sztuka
2CKA006132A0388	6122/10-96-500 BW standard	6122/10-96-500	1	sztuka
2CKA006430A0393	Electronic Controls Various symbols for Time switch Central cover plate château-black - Basic55	6435-95-507	1	sztuka
2CKA006599A2994	Electronic Controls Without imprint for Switch/dimmer Single push button château-black - Basic55	6543-95-507	1	sztuka
2CKA008200A0161	Multimedia Devices Loudspeaker château-black - Basic55	8253-95-507	1	sztuka
2CKA006220A0702	CP-FCC-95 C-plate Fan Coil	CP-FCC-95	1	sztuka
2CKA006220A0719	CP-FCC-96 C-plate Fan Coil	CP-FCC-96	1	sztuka
2CKA006220A0699	CP-RTC-95 C-plate RT sensor unit	CP-RTC-95	1	sztuka
2CKA006220A0716	CP-RTC-96 C-plate RT sensor unit	CP-RTC-96	1	sztuka
2CKA006220A0700	MD-F-1.0.1-95 Movement detector	MD-F-1.0.1-95	1	sztuka
2CKA006220A0717	MD-F-1.0.1-96 Movement detector	MD-F-1.0.1-96	1	sztuka
2CKA006220A0701	MSA-F-1.1.1-95 Mov. detector/actuator 1g	MSA-F-1.1.1-95	1	sztuka
2CKA006220A0718	MSA-F-1.1.1-96 Mov. detector/actuator 1g	MSA-F-1.1.1-96	1	sztuka
2CKA006220A0686	Electronic Controls château-black - Basic55	SR-1-95	1	sztuka
2CKA006220A0703	Electronic Controls chalet white - Basic55	SR-1-96	1	sztuka
2CKA006220A0691	Electronic Controls château-black - Basic55	SR-2-95	1	sztuka
2CKA006220A0708	Electronic Controls chalet white - Basic55	SR-2-96	1	sztuka
2CKA006220A0688	Electronic Controls château-black - Basic55	SRB-1-95	1	sztuka
2CKA006220A0705	Electronic Controls chalet white - Basic55	SRB-1-96	1	sztuka
2CKA006220A0693	Electronic Controls château-black - Basic55	SRB-2-95	1	sztuka
2CKA006220A0710	Electronic Controls chalet white - Basic55	SRB-2-96	1	sztuka
2CKA006220A0690	Electronic Controls château-black - Basic55	SRD-1-95	1	sztuka
2CKA006220A0707	Electronic Controls chalet white - Basic55	SRD-1-96	1	sztuka
2CKA006220A0695	Electronic Controls château-black - Basic55	SRD-2-L-95	1	sztuka
2CKA006220A0712	Electronic Controls chalet white - Basic55	SRD-2-L-96	1	sztuka
2CKA006220A0696	Electronic Controls château-black - Basic55	SRD-2-R-95	1	sztuka
2CKA006220A0713	Electronic Controls chalet white - Basic55	SRD-2-R-96	1	sztuka
2CKA006220A0687	Electronic Controls château-black - Basic55	SRL-1-95	1	sztuka
2CKA006220A0704	Electronic Controls chalet white - Basic55	SRL-1-96	1	sztuka
2CKA006220A0692	Electronic Controls château-black - Basic55	SRL-2-L-95	1	sztuka
2CKA006220A0709	Electronic Controls chalet white - Basic55	SRL-2-L-96	1	sztuka
2CKA006220A0697	Electronic Controls château-black - Basic55	SRL-2-R-95	1	sztuka
2CKA006220A0714	Electronic Controls chalet white - Basic55	SRL-2-R-96	1	sztuka
2CKA006220A0689	Electronic Controls château-black - Basic55	SRS-1-95	1	sztuka
2CKA006220A0706	Electronic Controls chalet white - Basic55	SRS-1-96	1	sztuka
2CKA006220A0694	Electronic Controls château-black - Basic55	SRS-2-L-95	1	sztuka
2CKA006220A0711	Electronic Controls chalet white - Basic55	SRS-2-L-96	1	sztuka
2CKA006220A0698	Electronic Controls château-black - Basic55	SRS-2-R-95	1	sztuka
2CKA006220A0715	Electronic Controls chalet white - Basic55	SRS-2-R-96	1	sztuka
2CKA001726A0222	Decorative Styling Frame attica / pigeon blue - Basic55	2516-901-507	1	sztuka
2CKA001726A0223	Decorative Styling Frame silver metallic - Basic55	2516-902-507	1	sztuka

2CKA001726A0224	Decorative Styling Frame light green - Basic55	2516-903-507	1	sztuka
2CKA001726A0225	Decorative Styling Frame orange - Basic55	2516-904-507	1	sztuka
2CKA001726A0226	Decorative Styling Frame yellow - Basic55	2516-905-507	1	sztuka
2CKA001726A0227	Decorative Styling Frame apricot - Basic55	2516-906-507	1	sztuka
2CKA001726A0228	Decorative Styling Frame luminous - Basic55	2516-907-507	1	sztuka
2CKA001726A0220	Decorative Styling Frame white - Basic55	2516-92-507	1	sztuka
2CKA001726A0230	Decorative Styling Frame champagne - Basic55	2516-93-507	1	sztuka
2CKA001726A0218	Decorative Styling Frame alpine white - Basic55	2516-94-507	1	sztuka
2CKA001726A0232	Decorative Styling Frame château-black - Basic55	2516-95-507	1	sztuka
2CKA001726A0234	Decorative Styling Frame chalet white - Basic55	2516-96-507	1	sztuka

Kategorie

Produkty niskiego napięcia i systemy → Wiring Accessories - Light Switch Ranges → Frames

